

IO-LINK MASTER

EtherNet/IP and Modbus/TCP

Library



Trademark Notices

Microsoft and Windows are registered trademarks of Microsoft Corporation.

Other product names mentioned herein may be trademarks and/or registered trademarks of their respective owners.

First Edition, May 30, 2018

Copyright © 2013-2018. Control Corporation.

All Rights Reserved.

Control Corporation makes no representations or warranties with regard to the contents of this document or to the suitability of the Control product for any particular purpose. Specifications subject to change without notice. Some software or features may not be available at the time of publication. Contact your reseller for current product information.

Document Number: 2000655 Rev. A

Replaces:

- 2000582 (*IOLM 4-EIP User Guide*)
- 2000601 (*IOLM DR-EIP User Guide*)
- 2000604 (*IOLM EtherNet/IP and Modbus/TCP User Guide*)
- 2000589 (*IOLM EtherNet/IP Reference Manual*)
- 2000590 (*IOLM Modbus/TCP Reference Manual*)

Table of Contents

Chapter 1. Introduction	9
1.1. Installation and Configuration Overview	9
1.2. Locating the Latest Software and Documentation	10
Chapter 2. Hardware Installation	13
2.1. IOLM 4-EIP Hardware Installation.....	13
2.1.1. Setting the Rotary Switch	13
2.1.2. Connecting to the Network	14
2.1.3. Connecting the Power.....	15
2.1.4. Mounting the IOLM 4-EIP	16
2.2. IOLM 8-EIP Hardware Installation.....	17
2.2.1. Setting the Rotary Switch	17
2.2.2. Connecting to the Network	18
2.2.3. Connecting the Power.....	19
2.2.4. Mounting the IOLM 8-EIP	20
2.3. IOLM DR-8-EIP Hardware Installation.....	21
2.3.1. Connecting to the Network	21
2.3.2. Connecting the Power.....	21
2.3.3. Mounting	22
Chapter 3. Configuring the Network Information	23
3.1. Network Configuration Overview	23
3.2. Using the Web Interface to Program the Network.....	24
Chapter 4. Connecting Devices	27
4.1. Connecting Devices to IO-Link Ports	27
4.1.1. IOLM 4-EIP IO-Link Ports	27
4.1.2. IOLM 8-EIP IO-Link Ports	28
4.1.3. IOLM DR-8-EIP IO-Link Ports.....	30
4.1.3.1. Tips When Connecting Devices to the IOLM DR-8-EIP	31
4.1.3.2. Connecting IO-Link Devices	31
4.1.3.3. Connecting Digital Input Devices to IO-Link Ports	32
4.1.3.4. Connecting DIO Devices to IO-Link Ports.....	32
4.2. Connecting Devices to the Digital IO Ports (IOLM DR-8-EIP)	33
4.2.1. Connecting to DI	34
4.2.2. Connecting to DIO	34
Chapter 5. Updating Images and Applications	35
5.1. Images and Application Subassemblies Overview	35
5.1.1. Images	36
5.1.2. Application Subassemblies.....	36
5.2. Using the Web Interface to Update Software	37
5.2.1. Updating Images.....	37
5.2.2. Updating Application Subassemblies	38

Chapter 6. IO-Link Port Configuration.....	39
6.1. Preparing for Port Configuration	39
6.2. IO-Link Configuration Page	41
6.2.1. Editing IO-Link Port Settings.....	42
6.2.2. IO-Link Settings Parameters.....	43
6.3. EtherNet/IP Settings Configuration Page.....	46
6.3.1. Editing EtherNet/IP Settings	47
6.3.2. EtherNet/IP Settings Parameters	48
6.4. Modbus/TCP Settings Configuration Page.....	54
6.4.1. Editing Modbus/TCP Settings.....	55
6.4.2. Modbus/TCP Settings Parameters.....	56
6.5. OPC UA Settings Configuration Page	59
6.5.1. Edit OPC UA Settings	60
6.5.2. OPC UA Settings Parameters.....	60
Chapter 7. Dedicated Digital I/O Port Configuration (IOLM-DR-8-EIP)	61
7.1. Digital I/O Settings Page.....	61
7.2. Editing Digital I/O Settings.....	62
7.3. Digital I/O Setting Parameters.....	63
Chapter 8. Loading and Managing IODD Files	65
8.1. IO-Link Device Description Files Page	65
8.1.1. Preparing IODD Files to Upload	66
8.1.2. Uploading IODD Zip Files.....	66
8.1.3. Uploading xml Files or Supporting Files	68
8.1.4. Viewing and Saving IODD Files	70
8.1.5. Deleting IODD Files	71
8.2. IO-Link Device Configuration Summary Page.....	72
Chapter 9. Configuring IO-Link Devices	73
9.1. Port Pages Overview	73
9.2. Editing Parameters - IO-Link Device - Port Table	76
9.3. Resetting IO-Link Device Parameters to Factory Defaults	77
9.4. Editing Parameters - IO-Link Device ISDU Interface - Port	79
Chapter 10. Utilizing IOLM Features	83
10.1. Setting User Accounts and Passwords.....	83
10.2. Data Storage	86
10.2.1. Uploading Data Storage to the IOLM	86
10.2.2. Downloading Data Storage to the IO-Link Device	86
10.2.3. Automatic Device Configuration.....	87
10.2.4. Automatic Device Configuration Backup	89
10.3. Device Validation	90
10.4. Data Validation	92
10.5. IOLM Configuration Files	93
10.5.1. Saving Configuration Files (Web Interface).....	93
10.5.2. Loading Configuration Files (Web Interface).....	94
10.5.3. Saving Configuration Files (PortVision DX).....	95
10.5.4. Loading Configuration Files (PortVision DX).....	95

10.6. Configuring Miscellaneous Settings	97
10.6.1. Using the Menu Bar Hover Shows Submenu Option	97
10.6.2. Enable PDO Write From Attached Devices Port Page	98
10.6.3. IO-Link Test Event Generator	100
10.7. Clearing Settings	103
Chapter 11. Using the Diagnostics Pages	105
11.1. IO-Link Port Diagnostics.....	106
11.2. Digital I/O Diagnostics (IOLM DR-8-EIP)	109
11.3. EtherNet/IP Diagnostics	110
11.4. Modbus/TCP Diagnostics.....	114
11.5. OPC UA Diagnostics Page	117
Chapter 12. EtherNet/IP Interface	119
12.1. Introduction	119
12.1.1. Functionality Summary	119
12.1.2. Data Type Definitions	120
12.1.3. Terms and Definitions	121
12.2. Data Transfer Methods	122
12.2.1. Receive Process Data Methods.....	122
12.2.1.1. Polling-PLC Requests Data	122
12.2.1.2. Write-to-Tag/File-IOLM Writes Data Directly Into PLC Memory	122
12.2.1.3. Class 1 Connection (Input Only)-PLC and IOLM Utilize an I/O Connection.....	123
12.2.2. Transmit Process Data Methods.....	123
12.2.2.1. PLC-Writes	123
12.2.2.2. Read-from-Tag/File-IOLM Reads Data from PLC Memory	124
12.2.2.3. Class 1 Connection (Input and Output)-PLC and IOLM Utilize an I/O Connection....	124
Chapter 13. Functionality Descriptions.....	125
13.1. Process Data Block Descriptions.....	125
13.1.1. Input Process Data Block Description.....	125
13.1.1.1. Input Process Data Block-8 Bit Data Format.....	126
13.1.1.2. Input Process Data Block-16 Bit Data Format.....	127
13.1.1.3. Input Process Data Block-32 Bit Data Format.....	127
13.1.2. Output Process Data Block Description	127
13.1.2.1. Output Process Data Block-8 Bit (SINT) Data Format	128
13.1.2.2. Output Process Data Block-16 Bit (INT) Data Format.....	129
13.1.2.3. Output Process Data Block-32 Bit (DINT) Data Format.....	129
13.2. Event Handling	130
13.2.1. Clear Event After Hold Time Process.....	131
13.2.2. Clear Event in PDO Block Process	132
13.2.3. Clear Event Code in PDO Block and Clear Event After Hold Time Process-PDO Block First....	133
13.2.4. Clear Event Code in PDO Block and Clear Event After Hold Time Process-Hold Time Expires	134
13.3. ISDU Handling	134
13.3.1. ISDU Request/Response Structure.....	135
13.3.1.1. Single ISDU Command Request	135
13.3.1.2. Multiple ISDU Command Structure.....	136
13.3.2. ISDU Request Message Format-From PLC to IOLM.....	138
13.3.2.1. Standard ISDU Request Command Format.....	138
13.3.2.2. Integer (16-Bit Word) ISDU Request Command Format.....	139
13.3.3. ISDU Response Message Format.....	140
13.3.3.1. Standard ISDU Response Command Format.....	140
13.3.3.2. Integer (16-Bit Word) ISDU Response Command Format	141

13.3.4. ISDU Blocking and Non-Blocking Methods	142
13.3.4.1. Single Command Blocking.....	142
13.3.4.2. Multiple Command Blocking.....	143
13.3.4.3. Single Command Non-Blocking.....	144
13.3.4.4. Multiple Command Non-Blocking.....	145
Chapter 14. EtherNet/IP CIP Object Definitions	147
14.1. IO-Link Port Information Object Definition (71 hex)	147
14.1.1. Class Attributes	147
14.1.2. Instance Attributes.....	148
14.1.3. Common Services.....	148
14.1.4. Instance Attribute Definitions	149
14.1.4.1. Attribute 1-Vendor Name	149
14.1.4.2. Attribute 2-Vendor Text	149
14.1.4.3. Attribute 3-Product Name	149
14.1.4.4. Attribute 4-Product ID	149
14.1.4.5. Attribute 5-Product Text	149
14.1.4.6. Attribute 6-Serial Number	149
14.1.4.7. Attribute 7-Hardware Revision	150
14.1.4.8. Attribute 8-Firmware Revision	150
14.1.4.9. Attribute 9-Device PDI Length	150
14.1.4.10. Attribute 10-Device PDO Length	150
14.1.4.11. Attribute 11-PDI Data Block Length.....	150
14.1.4.12. Attribute 12-PDO Data Block Length.....	150
14.1.4.13. Attribute 13-Input Assembly PDI Offset.....	151
14.1.4.14. Attribute 14-Input Assembly PDO Offset.....	151
14.1.4.15. Attribute 15-Output Assembly PDO Offset.....	151
14.1.4.16. Attribute 16-Control Flags	152
14.2. PDI (Process Data Input) Transfer Object Definition (72 hex)	153
14.2.1. Class Attributes	153
14.2.2. Instance Attributes.....	153
14.2.3. Common Services.....	153
14.2.4. Instance Attribute Definitions - Attribute 1 to 4-PDI Data Blocks	153
14.3. PDO (Process Data Output) Transfer Object Definition (73 hex)	154
14.3.1. Class Attributes	154
14.3.2. Instance Attributes.....	154
14.3.3. Common Services.....	154
14.3.4. Instance Attribute Definitions - Attribute 1 to 4-PDO Data Blocks.....	155
14.4. ISDU Read/Write Object Definition (74 hex).....	155
14.4.1. Class Attributes	155
14.4.2. Instance Attributes.....	155
14.4.3. Common Services.....	156
14.4.4. Object Specific Services	156
14.4.5. Instance Attribute Definitions	156
14.4.5.1. Attribute 1-ISDU Read/Write Response (Non-Blocking only).....	156
14.4.5.2. Attribute 2-ISDU Read/Write Request (Non-blocking only).....	156
14.5. Identity Object (01hex, 1 instance).....	157
14.5.1. Class Attributes	157
14.5.2. Instance Attributes.....	157
14.5.3. Status Word	158
14.5.4. Common Services.....	159
14.6. Message Router Object (02 hex)	159
14.6.1. Class Attributes	159
14.6.2. Instance Attributes.....	159
14.6.3. Common Services.....	160

14.7. Connection Manager Object (06 hex)	160
14.7.1. Class Attributes Object (06 hex)	160
14.7.2. Instance Attributes (02 hex)	160
14.7.3. Common Services Object (06 hex).....	161
14.8. Port Object (F4 hex-1 instance)	161
14.8.1. Class Attributes	161
14.8.2. Instance Attributes.....	162
14.8.3. Common Services.....	162
14.9. TCP Object (F5 hex-1 instance)	163
14.9.1. Class Attributes	163
14.9.2. Instance Attributes.....	163
14.9.3. Common Services.....	165
14.10. Ethernet Link Object (F6 hex-1 instance)	165
14.10.1. Class Attributes	165
14.10.2. Instance Attributes.....	166
14.10.3. Common Services.....	166
14.11. PCCC Object (67 hex-1 instance)	167
14.11.1. Instances	167
14.11.2. Common Services.....	167
14.11.3. Message Structure Execute_PCCC: Request Message	167
14.11.4. Message Structure Execute_PCCC: Response Message.....	168
14.11.5. Supported PCCC Command Types.....	168
14.12. Assembly Object (For Class 1 Interface)	169
14.12.1. Class Attributes	169
14.12.2. Instance Definitions (4-Port Models).....	169
14.12.3. Instance Definitions (8-Port Models).....	170
14.12.4. Instance Attributes.....	172
14.12.5. Common Services.....	173
14.12.6. Instance Attribute Definitions: Attribute 3-Request/Write Data	173
14.12.7. Instance Attribute Definitions: Attribute 4-Data Length	173
14.12.8. Overview of Assembly Interface	174
14.12.9. Grouping of Assembly Instances.....	176
14.12.9.1. In order to minimize the number of required I/O connections, the input and output assembly instances are organized as follows. The Input Assembly instances are grouped into one continuous array with no gaps between the instances. The same is also true for Output Assembly Instances.4-Port Models	176
14.12.9.2. 8-Port Models.....	177

Chapter 15. ControlLogix Family - Example PLC Programs	181
15.1. Import the PLC program into RSLogix 5000	181
15.2. Configure the Controller	181
15.3. Add the EtherNet/IP Module Interface	183
15.4. Configure the Ethernet Module	185
15.5. Example PLC Program Operation	190
15.6. User Defined Data Structures	193
15.6.1. User Defined Structure Example 1.....	194
15.6.2. User Defined Structure Example 2.....	194
15.6.3. User Defined Structure Example 3.....	195
15.6.4. User Defined Structure Example 4.....	195
15.7. Example PLC Program Tag Definitions.....	196
15.7.1. PrtN_DeviceInformation Definition	198
15.7.2. PrtN_RxPdiData Definition	199
15.7.3. PrtN_MiscISDUReqs	200
15.7.4. PrtN_MiscISDUResp	201
15.7.5. Using Other ISDU Request/Response Command Formats	201
Chapter 16. SLC/PLC-5/MicroLogix Interface	203
16.1. Requirements	203
16.2. PLC-5 and SLC 5/05 PLC Requirements	204
16.2.1. SLC 5/05	204
16.2.2. PLC-5.....	204
16.3. PLC-5 and SLC Messages.....	205
16.4. Process Data (PDI and PDO) Access via PCCC Messages	207
Chapter 17. EDS Files	209
17.1. Overview.....	209
17.2. Downloading the Files	209
17.3. Configuring RSLinx	209
17.4. Adding EDS Files to Rockwell Software.....	210
Chapter 18. Modbus/TCP Interface	211
18.1. Modbus Function Codes	212
18.2. Modbus Address Definitions.....	212
18.2.1. 8-Port Models	213
18.3. Multiple Port Process Data (PDI/PDO) Access via Modbus/TCP	215
Chapter 19. Troubleshooting and Technical Support	219
19.1. Troubleshooting.....	219
19.2. IOLM LEDs.....	220
19.2.1. IOLM 4-EIP.....	220
19.2.2. IOLM 8-EIP.....	221
19.2.3. IOLM DR-8-EIP	222
19.3. Contacting Technical Support	223
19.4. Using Log Files.....	224
19.4.1. View a Log File	224
19.4.2. Export a Log File	225
19.4.3. Clear a Log File.....	226

Chapter 1. Introduction

This document provides installation, configuration, and embedded web interface information for the Control IO-Link Master (IOLM). In addition, it includes detailed information about EtherNet/IP and Modbus/TCP.

The web interface provides a platform so that you can easily configure, review diagnostic pages, and access advanced features, such as the ability to:

- Upload the latest IOLM images or applications
- Set up user accounts with different user levels and passwords
- Load IODD files and configure IO-Link device parameters
- Implement manual or automatic data storage (upload or download)
- Implement device and/or data validation

1.1. Installation and Configuration Overview





The IOLM installation includes the following procedures.





1. Connect the power and Ethernet cable ([Page 13](#)).
2. Configure the IP address using the embedded web interface or PortVision DX ([Page 23](#)).
Note: IOLM 4-EIP ([Page 13](#)) and IOLM 8-EIP ([Page 17](#)): If desired you can use the rotary switch to set the IP address.
3. Configure IOLM device features such as passwords or miscellaneous settings ([Page 83](#)).
4. If necessary, upload the latest images to support the latest features ([Page 35](#)).
5. Connect the IO-Link and digital I/O devices ([Page 27](#)).
6. Use the web interface to configure the Modbus/TCP and OPC UA settings following:
 - a. IOLM ports for your environment using the web interface ([Page 39](#)):
 - IO-Link settings, such as the **Port Mode**, which by default is set to IO-Link but depending on the device, you may need to set it to Digital In or Digital Out.
 - EtherNet/IP settings
 - Modbus/TCP settings
 - OPC UA settings (on select models)
 - b. If necessary, configure the dedicated digital I/O ports on applicable models ([Page 61](#)).
 - c. If desired, upload the appropriate IODD files for your IO-Link devices ([Page 65](#)) to simplify IO-Link device configuration.
 - d. If desired, implement IOLM features or options ([Page 83](#)), such as:
 - Data storage, automatic or manual - upload or download
 - Device validation
 - Data validation
 - IOLM configuration files (save and load)
 - e. Use the **Diagnostic** pages to monitor or troubleshoot your devices.





7. Connect to a PLC and configure the PLC or HMI/SCADA (depending on your protocol)
- **EtherNet/IP** configuration is discussed in detail in the following chapters:
 - [EtherNet/IP Interface](#) on Page 119 provides a functionality summary, data type definitions, terms and definition, and data transfer methods.
 - [Chapter 13. Functionality Descriptions](#) on Page 125 (for EtherNet/IP and Modbus/TCP) details process data block descriptions, event handling, and ISDU handling.
 - [Chapter 14. EtherNet/IP CIP Object Definitions](#) on Page 147 discusses the vendor specific CIP definitions.
 - If applicable, use [Chapter 15. ControlLogix Family - Example PLC Programs](#) on Page 181 to get your PLCs operating quicker.
 - If applicable, use [Chapter 16. SLC/PLC-5/MicroLogix Interface](#) on Page 203 to get your PLCs operating quicker.
 - [Chapter 17. EDS Files](#) on Page 209, which provides procedures on how to add EDS files to RSLinx for normal IOLM to PLC communications.
 - **Modbus/TCP**: connect PLCs or HMI/ SCADA devices, which is discussed in detail in these two supporting sections:
 - [Chapter 13. Functionality Descriptions](#) on Page 125 details process data block descriptions, event handling, and ISDU handling.
 - [Chapter 18. Modbus/TCP Interface](#) on Page 211 discusses Modbus Function codes, address definition and multiple port process data (PDI/PDO).

1.2. Locating the Latest Software and Documentation


You can use the links in the following tables to locate the latest images, utilities, and documentation. For information about images and updating the IOLM, see [Chapter 5. Updating Images and Applications](#) on Page 35.


IOLM 4-EIP (IP67) Latest Images	
U-Boot Bootloader	
FPGA	
System uImage (Primary/Backup)	
Application Base	



IOLM DR-EIP (DIN Rail) Latest Images	
U-Boot Bootloader	
FPGA	
System uImage (Primary/Backup)	
Application Base	

IOLM 8-EIP (IP67) Latest Images	
U-Boot Bootloader	
FPGA	
System uImage (Primary/Backup)	
Application Base	

Note: The Application Base image contains all of the latest applications. If a feature enhancement or bug fix is required, the application will be available on the [Download](#) page.

Latest Configuration Utility		
PortVision DX (Windows 7 through Windows 10)	PortVision DX automatically detects Control Ethernet attached products physically attached to the local network segment so that you can quickly configure the network address, upload firmware, access IOLM embedded web interface, and download the latest product documentation. PortVision DX also provides these features: <ul style="list-style-type: none"> • Telnet/SSH interface • PuTTY • Ability to save and load IOLM configuration files • Save Device Diagnostics Data, in the event you have a support issue • LED Tracker feature 	

Latest EDS Files	
You do not need to add the IOLM to RSLinx for normal IOLM-to-PLC communications. However, you can easily add the IOLM and its associated Electronic Data Sheet (EDS) files to RSLinx to support Class 1. See Chapter 17. EDS Files on Page 209 for more information.	

Product Documentation		
<i>IOLM EtherNet/IP and Modbus/TCP Library</i>	This contains all information to support the latest released application base.	
<i>PortVision DX User Guide</i>	<p>This discusses the following topics:</p> <ul style="list-style-type: none"> • Installing PortVision DX • User interface overview • Managing the view • Network configuration • Firmware • Software settings • Accessing Control configuration web pages • Configuration files • Telnet SSH sessions • Accessing other applications • Changing PortVision DX options • Logging events 	

Chapter 2. Hardware Installation

Use the appropriate hardware installation for your IOLM model:

- [IOLM 4-EIP Hardware Installation](#)
- [IOLM 8-EIP Hardware Installation](#) on Page 17
- [IOLM DR-8-EIP Hardware Installation](#) on Page 21

2.1. IOLM 4-EIP Hardware Installation

Use the following subsections to install the hardware and verify operation.

- [Setting the Rotary Switch](#) on Page 13
- [Connecting to the Network](#) on Page 14
- [Connecting the Power](#) on Page 15
- [Mounting the IOLM 4-EIP](#) on Page 16

2.1.1. Setting the Rotary Switch

You can use the rotary switches under the configuration window on the IOLM to set the lower 3-digits (8 bits) of the static IP address. Optionally, you can leave the rotary switch set to the default and use the web interface or PortVision DX to set the network address.

If the rotary switches are set to a non-default position, the upper 9-digits (24 bits) of the IP address are then taken from the static network address. The switches only take effect during startup, but the current position is always shown on **Help | SUPPORT** page.

Using the rotary switches to set the IP address may be useful in the following situations:

- A permanent method to assign IP addresses while setting machines for a special application where a PC or laptop is not available.
- A temporary method to assign IP addresses to several IOLMs so that they do not have duplicate addresses to make setting the IP addresses using software easier. After using PortVision DX or the web page to change the IP address, reset the rotary switches back to 000.
- An emergency method to return the IOLM back to factory defaults, so that software can be used to program the appropriate IP address, and then return the switches back to 000.

Note: *If you set the network address using the rotary switches, the Rotary Switch setting overrides the network settings in the web interface when the IOLM is initially powered on or after cycling the power.*


Switch Setting	Node Address
000 (Default setting)	<p>Use the network configuration stored in the flash. The default network configuration values are:</p> <ul style="list-style-type: none">• IP address = 192.168.1.250• Subnet mask = 255.255.255.0• IP gateway = 0.0.0.0 <p>After completing the hardware installation, see Chapter 3. Configuring the Network Information on Page 23 to set the network address.</p>

Switch Setting	Node Address
001-254	This is the last three digits in the IP address. This uses the first three numbers from the configured static address, which defaults to 192.168.1.xxx. Note: <i>If software is used to change the IP address to another range before setting the rotary switches, the IOLM uses that IP address range. For example, if the IOLM is set to 10.0.0.250 and the first rotary switch is set to 2, the IP address would be 10.0.0.200.</i>
255-887	Reserved.
888	Reset to factory defaults. If the IOLM is set to 888 and the IP address is changed using other methods, the IP address is returned to the default IP address if the IOLM is rebooted or power cycled.
889-997	Use the network configuration values stored in the flash (reserved).
998	Setting the rotary switches to 998 configures the IOLM to use DHCP addressing.
999	Use the default IP address. If the IOLM is set to 999 and the IP address is changed using other methods, the IP address is returned to the default IP address if the IOLM is rebooted or power cycled.

Use the following steps if you want to change the default rotary switch settings.

1. Remove the two Phillips screws securing the switch window.
2. Gently swing open the switch window from the left to the right, allowing it to pivot on the hinge on the right side.
3. Turn each dial to the appropriate position using a small flathead screwdriver.

Note: *If you are using the rotary switch to assign a temporary IP address, you may want to leave the door open until you use software to set a permanent IP address. After doing so, you can close and seal the window.*



The default setting is 000 as shown above.


4. Carefully close the window making sure that it is properly aligned. *The arrow points to the switch location. 0 is located at the 3:00*
5. Reinsert and hand-tighten the two screws making sure that the window is securely sealed.

Note: *Failure to reassemble the configuration window properly may compromise IP67 integrity.*

2.1.2. Connecting to the Network

The IOLM provides two Fast Ethernet (10/100BASE-TX) M12, 4-pin female /D-coded connectors.

Pin	Signal
1	Tx+
2	Rx+
3	Tx-
4	Rx-



You can use this procedure to connect the IOLM to the network.

1. Securely connect one end of a shielded twisted-pair (Cat 5 or higher) M12 Ethernet cable to either Ethernet port.
2. Connect the other end of the cable to the network.
3. Optionally, use the other Ethernet port to daisy-chain to another Ethernet device.

- If you did not connect both Ethernet ports, make sure that the unused port is covered with a connector cap to keep dust and liquids from getting in the connector.


Note: Ethernet ports must have an approved cable or protective cover attached to the connector to guarantee IP67 integrity.

2.1.3. Connecting the Power

The IOLM 4-EIP provides dual M12 (A-coded) power connectors.

Note: Power connectors must have an approved cable or protective cover attached to the port guarantee to IP67 compliance.

Pin	Input - Male	Output - Female
1	L+	L+
2	L2+	L2+
3	L-	L-
4	L2-	L2-
5	Not connected	Not connected



The IOLM 4-EIP requires a UL LPS listed power supply with an output rating of 24VDC.


Power Supply	Values
Power Supply In - Maximum (U_S)	4A
IO-Link Connectors (Ports 1 - 4) C/Q (Pin 4) V_S (Pins 1 and 3)	200 mA (Maximum) 500 mA (Maximum)
IOLM Power	100mA @ 24VDC (V_S)
Power Supply Out (U_S)	4A † (Maximum)
† U_S output available is determined by subtracting the following from the available input current.	
<ul style="list-style-type: none"> - IO-Link Mode module power - Actual C/Q current for each IO-Link port - Actual V_S current for each IO-Link port 	

You can use this procedure to connect the IOLM 4-EIP to a power supply.

Note: Power should be disconnected from the power supply before connecting it to the IOLM 4-EIP. Otherwise, your screwdriver blade can inadvertently short your power supply terminal connections to the grounded enclosure.

- Securely attach the power cable between the male power connector (**PWR In**) and the power supply.
- Either attach a power cable between the female power connector and another device to which you want to provide power or securely attach a connector cap to prevent dust or liquids from getting into the connector.
- Apply the power and verify that the following LEDs are lit indicating that you are ready to attach your IO-Link or digital I/O devices.
 - **PWR** - green lit LED indicates the IOLM 4-EIP is receiving power.
 - **MOD**, first the flashing green and red LEDs display that it is in self-test mode. After self-test mode, depending on whether you set the IP address with the rotary switch one of the following occurs:
 - The green LED is flashing to indicate that the IOLM is in standby mode.
 - The green LED is lit to indicate that the IOLM is operational.
 - **NET**, first it flashes green and red indicating that it is in self-test mode. After self-test mode, depending on whether you set the IP address with the rotary switch one of the following occurs:
 - Off indicates there is no IP address.

- Steady red indicates a duplicate IP address on the network.
- LINK should be lit (green) to indicate a valid network connection.
- ACT blinks if there is network traffic between the IOLM and the network.
- EIP 1/2 should be lit (green) indicating that the link is up if both connectors are connected.
- Port LEDs should display in this manner if there is no device attached:



- IO-Link port LED should be flashing green indicating that it is searching for an IO-Link device.
- DI should be off to indicate that there is no device attached to the port.

If the LEDs indicate that you are ready to go to the next installation step:


- Program the IP address using PortVision DX or the web interface. Refer to [Chapter 3. Configuring the Network Information](#) on Page 23 for configuring the network information.
- If using the rotary switches to set the IP address, then you are ready to attach devices using [Chapter 4. Connecting Devices](#) on Page 27.

If the LEDs do not meet the above conditions, you can refer to the *IOLM LEDs* table on [Page 220](#) in the [Troubleshooting and Technical Support](#) chapter.

2.1.4. Mounting the IOLM 4-EIP

Use the following procedure to mount the IOLM. You can mount the IOLM on a mounting panel or a machine.

1. Verify that the mounting surface is level (flat) to prevent mechanical stress to the IOLM.
2. Attach the IOLM to the surface with two 6mm screws and washers, torque down to 8Nm.



2.2. IOLM 8-EIP Hardware Installation

Use the following subsections to install the hardware and verify operation.

- [Setting the Rotary Switch](#)
- [Connecting to the Network](#) on Page 18
- [Connecting the Power](#) on Page 19
- [Mounting the IOLM 8-EIP](#) on Page 20

2.2.1. Setting the Rotary Switch

You can use the rotary switches under the configuration window on the IOLM to set the lower 3-digits (8 bits) of the static IP address. Optionally, you can leave the rotary switch set to the default and use the web interface or PortVision DX to set the network address.

If the rotary switches are set to a non-default position, the upper 9-digits (24 bits) of the IP address are then taken from the static network address. The switches only take effect during startup, but the current position is always shown on **Help | SUPPORT** page.

Using the rotary switches to set the IP address may be useful in the following situations:

- A permanent method to assign IP addresses while setting machines for a special application where a PC or laptop is not available.
- A temporary method to assign IP addresses to several IOLMs so that they do not have duplicate addresses to make setting the IP addresses using software easier. After using PortVision DX or the web page to change the IP address, reset the rotary switches back to 000.
- An emergency method to return the IOLM back to factory defaults, so that software can be used to program the appropriate IP address, and then return the switches back to 000.

Note: *If you set the network address using the rotary switches, the Rotary Switch setting overrides the network settings in the web interface when the IOLM is initially powered on or after cycling the power.*

Switch Setting	Node Address
000 (Default setting)	Use the network configuration stored in the flash. The default network configuration values are: <ul style="list-style-type: none"> • IP address = 192.168.1.250 • Subnet mask = 255.255.255.0 • IP gateway = 0.0.0.0 After completing the hardware installation, see Chapter 3. Configuring the Network Information on Page 23 to set the network address using the web interface or PortVision DX.
001-254	This is the last three digits in the IP address. This uses the first three numbers from the configured static address, which defaults to 192.168.1.xxx. Note: <i>If software is used to change the IP address to another range before setting the rotary switches, the IOLM uses that IP address range. For example, if the IOLM is set to 10.0.0.250 and the first rotary switch is set to 2, the IP address would be 10.0.0.200.</i>
255-887	Reserved.
888	Reset to factory defaults. If the IOLM is set to 888 and the IP address is changed using other methods, the IP address is returned to the default IP address if the IOLM is rebooted or power cycled.
889-997	Use the network configuration values stored in the flash (reserved).
998	Setting the rotary switches to 998 configures the IOLM to use DHCP addressing.

Switch Setting	Node Address
999	Use the default IP address. If the IOLM is set to 999 and the IP address is changed using other methods, the IP address is returned to the default IP address if the IOLM is rebooted or power cycled.

Use the following steps if you want to change the default rotary switch settings.

1. Gently pop open the window using a small flathead screwdriver.
2. Gently swing open the switch window from the top to the bottom, allowing it to pivot on the hinge on the bottom of the window.
3. Turn each dial to the appropriate position using a small flathead screwdriver.



The default setting is 000 as shown above.

The arrow points to the switch location. 0 is located at the 3:00 position. Turn the dial clockwise to the appropriate setting.


4. Close the window and make sure that it snaps shut tightly.

Note: Failure to close the configuration window properly may compromise IP67 integrity.

2.2.2. Connecting to the Network

The IOLM provides two Fast Ethernet (10/100BASE-TX) M12, 4-pin female /D-coded connectors.

Pin	Signal
1	Tx+
2	Rx+
3	Tx-
4	Rx-



You can use this procedure to connect the IOLM to the network.

1. Securely connect one end of a shielded twisted-pair (Cat 5 or higher) M12 Ethernet cable to either Ethernet port.
2. Connect the other end of the cable to the network.
3. Optionally, use the other Ethernet port to daisy-chain to another Ethernet device.
4. If you did not connect both Ethernet ports, make sure that the unused port is covered with a connector cap to keep dust and liquids from getting in the connector.


Note: Ethernet ports must have an approved cable or protective cover attached to the connector to guarantee IP67 integrity.

2.2.3. Connecting the Power

The IOLM 8-EIP provides dual M12 (T-coded) power connectors.

Note: Power connectors must have an approved cable or protective cover attached to the port guarantee to IP67 compliance.

Pin	Input Male	Output Female
1	US+	US+
2	UA-	UA-
3	US-	US-
4	UA+	UA+
5	Not Connected	



Note: The IOLM requires a UL LPS listed power supply with an output rating of 24VDC.


Power Supply	Values
Power Supply In - Maximum V_S and V_A	12A (Maximum)
IO-Link Connector Port 1 C/Q (Pin 4) V_S (Pins 1 and 3)	200 mA (Maximum) 1.6A (Maximum)
IO-Link Connectors Ports 2 - 8 C/Q (Pin 4) V_S (Pins 1 and 3)	200 mA (Maximum) 500 mA (Maximum)
IOLM Power	100mA @ 24VDC (V_S)
Power Supply Out V_S V_A	12A † (Maximum) 12A †† (Maximum)
† V_S output available is determined by subtracting the following from the available input current. <ul style="list-style-type: none"> - IO-Link Mode module power - Actual C/Q current for each IO-Link port - Actual V_S current for each IO-Link port 	
†† V_A output available is the same as the available V_A input current.	

You can use this procedure to connect the IOLM to a power supply.

Note: Power should be disconnected from the power supply before connecting it to the IOLM. Otherwise, your screwdriver blade can inadvertently short your power supply terminal connections to the grounded enclosure.

1. Securely attach the power cable between the male power connector (**PWR In**) and the power supply.
2. Either attach a power cable between the female power connector and another device to which you want to provide power or securely attach a connector cap to prevent dust or liquids from getting into the connector. Connector caps are shipped with the IOLM 8-EIP.
3. Apply the power and verify that the following LEDs are lit indicating that you are ready to attach your IO-Link or digital I/O devices.
 - **PWR** - green lit LED indicates the IOLM 8-EIP is receiving power.
 - **MS**, first the flashing green and red LEDs display that it is in self-test mode. After the self-test mode, depending on whether you set the IP address with the rotary switch one of the following occurs:
 - The green LED is flashing to indicate that the IOLM is in standby mode.
 - The green LED is lit to indicate that the IOLM is operational.
 - **NS**, first it flashes green and red indicating that it is in self-test mode. After self-test mode, depending

on whether you set the IP address with the rotary switch one of the following occurs:

- Off indicates there is no IP address.
- Steady red indicates a duplicate IP address on the network.
- LINK should be lit (green) to indicate a valid network connection.
- ACT blinks if there is network traffic between the IOLM and the network.
- EIP 1/2 should be lit (green) indicating that the link is up if both connectors are connected.
- Port LEDs should display in this manner if there is no device attached:
 - IO-Link port  LED should be flashing green indicating that it is searching for an IO-Link device.
 - DI should be off to indicate that there is no device attached to the port.



If the LEDs indicate that you are ready to go to the next installation step:


- Program the IP address using PortVision DX or the web interface. Refer to [Chapter 3. Configuring the Network Information](#) on Page 23 for configuring the network information.
- If using the rotary switches to set the IP address, then you are ready to attach devices using [Chapter 4. Connecting Devices](#) on Page 27.

If the LEDs do not meet the above conditions, you can refer to the *IOLM LEDs* table on [Page 220](#) in the [Troubleshooting and Technical Support](#) chapter.

2.2.4. Mounting the IOLM 8-EIP

Use the following procedure to mount the IOLM. You can mount the IOLM on a mounting panel or a machine.

1. Verify that the mounting surface is level (flat) to prevent mechanical stress to the IOLM.
2. Attach the IOLM to the surface with two 6mm screws and washers, torque down to 8Nm.



2.3. IOLM DR-8-EIP Hardware Installation

Use the following information to install the hardware for the IOLM DR-8-EIP.

- [Connecting to the Network](#)
- [Connecting the Power](#) on Page 21
- [Mounting](#) on Page 22

Note: The IOLM DR-8-EIP must be installed in a suitable fire, electrical, mechanical enclosure.

2.3.1. Connecting to the Network

The IOLM provides two Fast Ethernet (10/100BASE-TX) standard RJ45 connectors.

Pin	Signal
1	Tx+
2	Tx-
3	Rx+
6	Rx-

You can use this procedure to connect the IOLM to the network.


1. Securely connect one end of the RJ45 Ethernet cable to either Ethernet port.
2. Connect the other end to the network.
3. Optionally, use the other Ethernet port to daisy-chain to another Ethernet device.

2.3.2. Connecting the Power

The IOLM DR-8-EIP provides two redundant power inputs with screw terminals on the top and bottom of the unit.

Note: Use either power terminal (top or bottom) but **DO NOT** use both to supply power to the IOLM.

Signal	Description
V-	24VDC Power Supply Return
V-	24VDC Power Supply Return
V+	Primary +24VDC Supply
V+	Secondary +24VDC Supply



Note: The IOLM DR-8-EIP must be installed in a suitable fire, electrical, mechanical enclosure.

Power Supply	Values
Power Supply In V+	4A (Maximum) †
IO-Link Connectors Ports 1 - 8 C/Q L+	200 mA (Maximum) 200 mA (Maximum)
Digital IO (D1 and D2 D3 and D4) D2, D4 L+	200 mA (Maximum) 200 mA (Maximum)

Power Supply	Values
IO-Link Master Power	100mA @ 24VDC (V _S)
† The sum of the following must not exceed V+ maximum input current:	
<ul style="list-style-type: none"> - IO-Link Mode module power - Actual C/Q current for each IO-Link port and for D2 and D4 output - Actual U_S current for each IO-Link port 	

You can use this procedure to connect the IOLM to a UL Listed power supply and UL Listed power cord.

Note: Power should be disconnected from the power supply before connecting it to the IOLM. Otherwise, your screwdriver blade can inadvertently short your terminal connections to the grounded enclosure.


1. Insert positive and negative wires (12-24AWG) into the V+ and V- contacts.

Note: Use either power terminal (top or bottom) but **DO NOT** use both to supply power to the IOLM.

2. Tighten the wire-clamp screws to prevent the wires from coming loose.

3. Apply the power and verify that the following LEDs are lit indicating that you are ready to program the IP address and then attach your IO-Link or digital I/O devices.

- **PWR** - green lit LED indicates the IOLM DR-8-EIP is receiving power.
- **MS**, first the flashing green and red LEDs display that it is in self-test mode. After the self-test mode, depending on whether you set the IP address with the rotary switch one of the following occurs:
 - The green LED is flashing to indicate that the IOLM is in standby mode.
 - The green LED is lit to indicate that the IOLM is operational.
- **NS**, first it flashes green and red indicating that it is in self-test mode. After self-test mode, depending on whether you set the IP address with the rotary switch one of the following occurs:
 - Off indicates there is no IP address.
 - Steady red indicates a duplicate IP address on the network.
- **LINK** should be lit (green) to indicate a valid network connection.
- **ACT** blinks if there is network traffic between the IOLM and the network.
- **EIP 1/2** should be lit (green) indicating that the link is up if both connectors are connected.
- Port LEDs should display in this manner if there is no device attached:
 - IO-Link port LED should be flashing green indicating that it is searching for an IO-Link device.
 - **DI** should be off to indicate that there is no device attached to the port.



If the LEDs indicate that you are ready to go to the next installation step, Refer to [Chapter 3. Configuring the Network Information](#) on Page 23 to configure the network information.

If the LEDs do not meet the above conditions, you can refer to the *IOLM LEDs* table on [Page 220](#) in the [Troubleshooting and Technical Support](#) chapter.

2.3.3. Mounting

You may want to mount the IOLM after programming the IP address and connecting the IO-Link and digital input/output devices.

1. Slide the metal latch down, hook the top of IOLM DR-8-EIP to the DIN rail and release the latch.
2. Verify that is tightly mounted.

Note: You may want to connect the IO-Link devices before attaching the IOLM DR-8-EIP to the DIN rail. Use [Chapter 4. Connecting Devices](#) on Page 27 if you require IO-Link cabling information.

Chapter 3. Configuring the Network Information

The following topics are discussed in this chapter.

- *Network Configuration Overview*
- [Using the Web Interface to Program the Network](#) on Page 24

3.1. Network Configuration Overview

If you used the rotary switch (applicable models) to set the IP address ([Chapter 2. Hardware Installation](#) on Page 13), may want to configure the upper 9 digits (24 bits) of the IP address using the embedded web interface or PortVision DX. In addition, you may want to install PortVision DX to access and manage your IOLMs.

Note: *If you set the network address using the rotary switches, the Rotary Switch setting overrides the network settings in the web interface when the IOLM is initially powered on or after cycling the power.*

You can use one of the following methods to configure the IP address.

- [Web interface](#) (Page 24)

Note: *If you do not use PortVision DX to configure the IP address, you will need to change your PC or laptop address to the same subnet as the IOLM.*

The IOLM default IP address is: **192.168.1.250** and the Subnet Mask is: **255.255.255.0**.

You may want to use the **Advanced | Network** page, if you need to configure the following:

- Host name
- DNS servers
- Syslog Server IP/Host name
- Syslog Port
- SSH Server Enable

Note: *You can use PortVision DX to configure the IP address information (**Properties**) and then use the web interface to configure the options not configurable in PortVision DX.*

- [PortVision DX](#) automatically detects Control Ethernet attached products physically attached to the local network segment so that you can quickly configure the network address, upload firmware, access the IOLM web interface, and download the latest product documentation.

PortVision DX also provides these features:

- Telnet/SSH interface
- PuTTY
- Ability to save and load IOLM configuration files
- **Save Device Diagnostics Data**, which can be sent to Control in the event you have a support issue
- **LED Tracker** feature to identify the IOLM with the LEDs flashing

You can download PortVision DX from Control using this path: http://downloads.control.com/IO_Link_Master/PortVision_DX. If you need information about using PortVision DX, you can use the PortVision DX help system or download the [PortVision DX User Guide](#).

3.2. Using the Web Interface to Program the Network

This subsection discusses using the web interface to configure the IP address. The default IP address is **192.168.1.250** and the Subnet Mask is: **255.255.255.0**.

Note: *The rotary switch settings (applicable models) override the lower 3 digits (8 bits) of static IP address configured on the **Configuration | Network** page. The default rotary switch setting uses the settings configured in the flash. Optionally, you can use the web interface to configure the upper 9 digits (24 bits) and the rotary switch to configure the lower 3 digits (8 bits) of the static IP address. You can also refer to [Chapter 2. Hardware Installation](#) on Page 13 for additional information.*

You may need to change your host system IP address so that it can communicate with the IOLM default IP address: 192.168.1.250. The IOLM is shipped from the factory with the Admin account enabled without a password. You can configure the Admin, Operator, and User [passwords](#).

1. Open the IOLM web interface using one of these method:
 - Open your browser and enter the IP address of the IOLM.
 - From PortVision DX, highlight the IOLM and click the **Webpage** button or right-click the IOLM in the *Device List* pane (lower pane) and click **Webpage**.
2. Click **Configuration | NETWORK**.
3. Click the **EDIT** button.


CONTROL Home Diagnostics Configuration Advanced Attached Devices Help IO-Link Master 4-EIP Logout

IO-LINK ETHERNET/IP MODBUS/TCP OPC UA **NETWORK** MISC LOAD/SAVE CLEAR SETTINGS

Network Settings Click EDIT to make configuration changes


NETWORK CONFIGURATION	
Status	
Current IP Address	10.0.0.171
Current Netmask	255.255.0.0
Current Gateway	
Current DNS	
Configuration	
Host Name	4-EIP#1
IP Type	static
Static IP Address (xxx.xxx.xxx.xxx)	10.0.0.171
Static Subnet Mask (xxx.xxx.xxx.xxx)	255.255.0.0
Static Gateway Address (xxx.xxx.xxx.xxx)	0.0.0.0
DNS 1 (xxx.xxx.xxx.xxx)	
DNS 2 (xxx.xxx.xxx.xxx)	
IP Address Conflict Detection	enable
NTP Server IP/Hostname	
Syslog Server IP/Hostname	
Syslog Server Port (0 - 65535)	514
SSH Server Enable	disable

- Click the **CONTINUE** button.



- Optionally, enter a host name to identify this IOLM.
- Select the IP type, **Static** or **DHCP**.
 - If using a static IP address, enter the static IP address, subnet mask and IP gateway address.
 - If using DNS:
 - Enter the DNS primary server IP address.
 - Optionally, enter the DNS secondary server IP address.
- If desired, enter the NTP server IP or host name.
- If you want the IOLM to send syslog messages to a syslog server:
 - Enter the syslog server's IP address (or host name if using DNS).
 - Enter the syslog server's port number (default is 514).
- If you want to enable the SSH server, click **Enable**.

10. Click SAVE to save the changes.



11. If the IOLM does not redirect you to the new page, open a session using the new IP address.

Note: *The IOLM does not need to be rebooted.*

You should verify that you have the latest software installed on the IOLM and if necessary, update the software. Refer to [Chapter 5. Updating Images and Applications](#) on Page 35 for information about locating the latest files and uploading the software.

After verifying that you have the latest software, you are ready to configure the IOLM port characteristics.

Chapter 4. Connecting Devices

This chapter discusses connecting devices to the IOLM.

- [Connecting Devices to IO-Link Ports](#)
- [Connecting Devices to the Digital IO Ports \(IOLM DR-8-EIP\)](#) on Page 33

4.1. Connecting Devices to IO-Link Ports

Use the appropriate discussion for your IOLM model.


- [IOLM 4-EIP IO-Link Ports](#)
- [IOLM 8-EIP IO-Link Ports](#) on Page 28
- [IOLM DR-8-EIP IO-Link Ports](#) on Page 30

4.1.1. IOLM 4-EIP IO-Link Ports

The IOLM 4-EIP provides four IO-Link ports (depending on the model) with M12, 5-pin female/A coded connectors.

This table provides signal information for the IO-Link connectors.

Pin	Signal	Description
1	L+	Power supply (+)
2	DI	Digital input
3	L-	Power supply (-)
4	C/Q	Communication signal, which supports SDCI (IO-Link) or SIO (standard input/output)
5	N/A	Not connected



The standard SDCI (IO-Link) transmission rates are supported:

- COM1 4.8Kbps
- COM2 38.4Kbps
- COM3 230.4Kbps

This table provides current and power information that you may need regarding the IO-Link ports.

Current and Power	IOLM 4-EIP
Maximum C/Q Current	200mA
Maximum L+/L- Current Output	500mA
C/Q & DI Input: Maximum (L+) Minimum (L-)	Power Input +0.5VDC -0.5VDC

Use the following procedure to attach IO-Link or digital input/output devices to the ports.

1. Securely attach the IO-link cable between the IO-Link or digital IO device and the IO-Link port.

Note: Make sure that you tighten the cables properly to maintain IP67 integrity.

2. If necessary, securely attach a connector cap to prevent dust or liquids from getting into any unused ports. Connector caps were shipped with the IOLM.

Note: IO-Link ports must have an approved cable or protective cover attached to the port to guarantee IP67 compliance.

3. If necessary, configure IO-Link port parameters using the **Configuration | IO-Link Settings** page to configure the port mode.
- If an IO-Link device is attached to the port, the IO-Link LED should now be lit green and the device is receiving power.
 - If a digital input or output device is attached to the IO-Link port, after the port is configured for digital input or output on the **IO-Link Settings** page, the IO-Link LED does not light but when an event occurs:
 - Digital input causes the DI LED to flash.
 - Digital output causes the IO-Link LED to flash


You can refer to the help system or [6.2. IO-Link Configuration Page](#) on Page 41 for configuration information.

4.1.2. IOLM 8-EIP IO-Link Ports

The IOLM 8-EIP provides eight IO-Link ports with M12, 5-pin female/A coded connectors. Each port has robust over-current protection and short circuit protection on its L+/L- power output and C/Q IO-Link signal. The pin-out for each IO-Link port is per the IO-Link standard and is provided in the following table:

This table provides signal information for the IO-Link connectors.

Pin	Signal	Description
1	L+	Power supply (+)
2	DI	Digital input
3	L-	Power supply (-)
4	C/Q	Communication signal, which supports SDCI (IO-Link) or SIO (standard input/output)
5	N/A	Not connected



The standard SDCI (IO-Link) transmission rates are supported:

- COM1 4.8Kbps
- COM2 38.4Kbps
- COM3 230.4Kbps

There are active over-current limiter electronics for each port in the IOLM 8-EIP that detects the overload/short-circuit condition within a few milliseconds and shuts off the output power to protect the port and the devices connected to it. The port’s power output self-recovers and restores to normal immediately after the overload or short-circuit condition is removed.

The over-current limiter circuit for L+/L- pins is separate circuits than the over-current limiter circuit for the C/Q output pin. When a port is affected by overload/short-circuit condition, it does not affect the operation of the other ports. All other ports will continue to operate normally without any glitch or interruption. The current output capacity, cutoff current, and power sharing/budgeting for L+/L- and C/Q signal for the ports on the IOLM 8-EIP are as follows.

Port	L+/L-			C/Q		
	Output Current Capacity (max.)	Overload Cutoff Current	Short-Circuit Protection	Output Current Capacity (max.)	Overload Cutoff Current	Short-Circuit Protection
Port 1: Independent over-current limiter circuits/IC for L+/L- and C/Q pins	1.6A	1.65A	Yes	200mA	400mA	Yes
Port 3: Independent over-current limiter circuits/IC for L+/L- and C/Q pins	500mA	550mA	Yes	200mA	400mA	Yes
Ports 2 and 4 (Pair) Ports 5 and 7 (Pair) Ports 6 and 8 (Pair) There's one independent over-current limiter that protects L+/L- pins on each pair of ports, for example: Port 2 and 4. This allows you to do power budgeting on pair of ports that allows flexibility in the application. The combined overload cutoff current on a pair of ports is 1.05A for the L+/L- pins. As long as the cutoff current of 1.05A is not exceeded, the current output could be budgeted between a pair of ports such as, Port 2 and 4 any way you want. For example, Port 2 output can be at 900mA and Port 4 output can be at 100mA. Or, Port 2 could be left open and Port 4 output can be at 1A.	500mA	1.05A	Yes	200mA*	400mA*	Yes
* Each port's C/Q pin has its own independent over-current limiter circuit and are not combined. The current output of C/Q pin for each port is also independently controlled and cannot be budgeted with other ports.						

Use the following procedure to attach IO-Link or digital input/output devices to the ports.

- Securely attach the IO-link cable between the IO-Link or digital input/output device and the IO-Link port.
Note: Make sure that you tighten the cables properly to maintain IP67 integrity.
- If necessary, securely attach a connector cap to prevent dust or liquids from getting into any unused ports. Connector caps were shipped with the IOLM.
Note: IO-Link ports must have an approved cable or protective cover attached to the port to guarantee IP67 compliance.
- If necessary, configure IO-Link port parameters using the **Configuration | IO-Link Settings** page to configure the port mode.
 - If an IO-Link device is attached to the port, the IO-Link LED should now be lit green and the device is receiving power.

- If a digital input or output device is attached to the IO-Link port, after the port is configured for digital input or output on the **IO-Link Settings** page, the IO-Link LED does not light but when an event occurs:
 - Digital input causes the DI LED to flash.
 - Digital output causes the IO-Link LED to flash

You can refer to the help system or [6.2. IO-Link Configuration Page](#) on Page 41 for configuration information.

4.1.3. IOLM DR-8-EIP IO-Link Ports

The following provides information about the IO-Link ports.


Label	Signal	Description	Value
1	L+	Power Supply Output (+)	200mA @ 24V (Maximum)
2	L-	Power Supply Output (-)	
3	DI	Digital Input	Not applicable.
4	C/Q	Communication signal, which supports SDCI (IO-Link) or SIO (standard input/output)	200mA @ 24V (Maximum)



Note: Depending on your model, the terminal blocks may be labeled numerically or with the signal abbreviations.

Use the appropriate procedure to connect devices to the IO-Link ports.

- [Connecting IO-Link Devices](#) on Page 31
- [Connecting Digital Input Devices to IO-Link Ports](#) on Page 32



4.1.3.1. Tips When Connecting Devices to the IOLM DR-8-EIP


The following tips may be useful when connecting devices to the IOLM DR-8-EIP because it may be difficult to manipulate the wire-clamp screws on the adjacent ports.

- If you are going to connect devices to Digital I/O ports (**D1** through **D4**), connect the digital devices before connecting devices to IO-Link ports.
- Connect a device to IO-Link Port 1 before IO-Link Port 2
- Connect a device to IO-Link Port 4 before IO-Link Port 3
- Connect a device to IO-Link Port 5 before IO-Link Port 6
- Connect a device to IO-Link Port 8 before IO-Link Port 7

4.1.3.2. Connecting IO-Link Devices

Use the following procedure to connect IO-Link devices to the IO-Link ports.


1. Insert the IO-Link device negative wire into the **L-** contact and tighten the wire-clamp screws to prevent the wire from coming loose.
2. Insert the IO-Link device positive wire into the **L+** contact and tighten the wire-clamp screws to prevent the wire from coming loose.
3. If applicable, insert the DI wire into the **DI** contact and tighten the wire-clamp screws to prevent the wire from coming loose.
4. Insert the IO-Link wire into the **C/Q** contact and tighten the wire-clamp screws to prevent the wire from coming loose.
5. If necessary, configure IO-Link parameters for each port. Refer to [6.1. Preparing for Port Configuration](#) on Page 39 or the help system for detailed port configuration information.



4.1.3.3. Connecting Digital Input Devices to IO-Link Ports

You can use an IO-Link port as a digital in port if you wish to do so.

1. Insert the IO-Link device negative wire into the **L-** contact and tighten the wire-clamp screws to prevent the wire from coming loose.
2. Insert the IO-Link device positive wire into the **L+** contact and tighten the wire-clamp screws to prevent the wire from coming loose.
3. If applicable, insert the DI wire into the **DI** contact and tighten the wire-clamp screws to prevent the wire from coming loose.
4. Refer to the help system for detailed port configuration information.



4.1.3.4. Connecting DIO Devices to IO-Link Ports

You can use an IO-Link port to connect and operate a digital input or output device.

1. Insert the IO-Link device negative wire into the **L-** contact and tighten the wire-clamp screws to prevent the wire from coming loose.
2. Insert the IO-Link device positive wire into the **L+** contact and tighten the wire-clamp screws to prevent the wire from coming loose.
3. If applicable, insert the DI or DO wire into the **C/Q** contact and tighten the wire-clamp screws to prevent the wire from coming loose.
4. Refer to the help system for detailed port configuration information.

4.2. Connecting Devices to the Digital IO Ports (IOLM DR-8-EIP)

The IOLM DR-8-EIP provides two digital input (DI) ports and two digital IO ports.


Label	Signal	Description	Specifications
1	L+	Power Supply (+)	200mA @ 24V (maximum)
2	L-	Power Supply (-)	
3	DI	Digital Input	
4	DIO	Digital I/O	200mA @ 24V (maximum)
Note: Depending on your model, the terminal blocks maybe labeled numerically or with the signal abbreviations.			



You can connect a digital input device to DI and/or DIO. DIO supports digital out.

Top (DIN Rail End)

Front Panel Edge



Front Panel Edge

Top (DIN Rail End)

4.2.1. Connecting to DI

Use this procedure to connect a digital input device using the **DI** terminal on a DIO port.

1. Insert the IO-Link device negative wire into the **L-** contact and tighten the wire-clamp screws to prevent the wire from coming loose.
2. Insert the IO-Link device positive wire into the **L+** contact and tighten the wire-clamp screws to prevent the wire from coming loose.
3. Insert the DI wire into the **DI** contact and tighten the wire-clamp screws to prevent the wire from coming loose.
4. Go to the **Configuration | Digital I/O Settings** page to configure the port. If necessary, refer to the help system or [6.2. IO-Link Configuration Page](#) on Page 41.



D1 or D3 LEDs

4.2.2. Connecting to DIO

1. Insert the IO-Link device negative wire into the **L-** contact and tighten the wire-clamp screws to prevent the wire from coming loose.
2. Insert the IO-Link device positive wire into the **L+** contact and tighten the wire-clamp screws to prevent the wire from coming loose.
3. Insert the DI wire into the **DIO** contact and tighten the wire-clamp screws to prevent the wire from coming loose.
4. Go to the **Configuration | Digital I/O Settings** page to configure the port. If necessary, refer to the help system or [Chapter 7. Dedicated Digital I/O Port Configuration \(IOLM-DR-8-EIP\)](#) on Page 61.



D2 or D4 LEDs

Chapter 5. Updating Images and Applications

This chapter provides an overview of the software (images and applications) on the IOLM. In addition it contains procedures to update images ([Page 37](#)) and application subassemblies ([Page 38](#)).

After verifying that the IOLM contains the latest software, the next step is to configure the port characteristics using [Chapter 6. IO-Link Port Configuration](#) on Page 39 and/or [Chapter 7. Dedicated Digital I/O Port Configuration \(IOLM-DR-8-EIP\)](#) on Page 61 (on applicable models).

5.1. Images and Application Subassemblies Overview

The IOLM is loaded with the latest images at the factory but you may need to update images or application subassemblies to have access to the latest features. You can view all image and application versions in the IOLM ADVANCED | Software page.

The screenshot shows the 'Software' page in the IOLM ADVANCED interface. The page has a navigation bar with 'CONTROL' logo and links for Home, Diagnostics, Configuration, Advanced, Attached Devices, Help, Logout, and a language selector. Below the navigation bar are tabs for SOFTWARE, ACCOUNTS, LOG FILES, and LICENSES. The main content area is titled 'Software' and contains two sections: 'IMAGES' and 'APPLICATIONS'. Each section has a table listing the component name and version, with an 'UPDATE' button for each row. At the bottom, there is an 'Update Application' section with a 'Browse...' button, an 'Install' button, and a 'REBOOT' button.

IMAGES		
U-Boot Bootloader	1.23	UPDATE
FPGA	1.02	UPDATE
System - Primary	1.30	UPDATE
System - Backup	1.30	UPDATE
Application Base	1.5.8	UPDATE

APPLICATIONS	
application-manager	1.5.0.2
configuration-manager	1.5.0.1
discovery-protocol	1.5.0.0
ethernetip	1.5.0.8
event-log	1.5.0.1
iolink-driver	1.5.0.3
iothub-client	1.5.0.0
libiolinkutils	1.5.0.13
modbus	1.5.0.9
opcua-server	1.5.0.5
web-help	1.5.0.0
web-user-interface	1.5.0.13

Update Application

Browse... Install REBOOT

Optionally, you can use PortVision DX to load all images or application subassemblies.

Note: PortVision DX displays the main application base version, which in this case is EtherNet/IP. Use the Software page to determine other image or application versions.

5.1.1. Images

The following table discusses IOLM images.

IOLM Images	
U-Boot Bootloader	<p>U-Boot is a high-level Bootloader that has networking and console command line capabilities. Among other things, it implements a TFTP server and Comtrol Corporation's new discovery protocol.</p> <p>This verifies that a Linux kernel image exists in NAND, then copies it to RAM and starts the IOLM. The U-Boot version is displayed after the image name.</p>
FPGA	<p>The FPGA partition/image contains configuration data used by programmable hardware within the IOLM unit.</p> <p>FPGA images are unique to the hardware and protocol type. Make sure you download the correct image for your platform.</p>
uImage - Primary/Backup	<p>The uImage contains the Linux kernel and the RAM-resident root file system. It does not contain industrial protocol support or application-specific features.</p> <p>There is a Primary and Backup version loaded on the IOLM. The IOLM automatically reloads the Backup uImage if the file system corrupted.</p> <p>The uImage version is displayed after the Primary/Backup uImage.</p>
Application Base	<p>The Application Base image comprises a flash-resident file system containing applications and protocol support.</p> <p>The Application Base is built from a collection of application subassemblies -- each of which may be updated individually between releases of the application base as a whole.</p> <p>The application subassemblies in the Application Base image are displayed in the lower portion of the SOFTWARE page.</p> <p>The Application Base assembly has a 3-tuple version number: (for example, 1.3.18).</p>

5.1.2. Application Subassemblies

Application subassemblies are the components of the Application Base image. Application subassemblies have a 4-tuple version number (for example, 1.3.18.3). The first two values in a subassembly version correspond to the version of the application base assembly for which it was built and tested.

For example, a subassembly with version 1.3.18.3 was tested with application base version 1.3.18. When using the **Software** page or PortVision DX, an application subassembly can install only if its version number matches that of the installed application base assembly. A subassembly with a version of 1.20.2.4 only installs if the application base version is 1.20.2. It will not install on a device with application base version 1.21.5.

IOLM Application Subassemblies	
application-manager	The Application Manager version loaded on the IOLM.
configuration-manager	The Configuration Manager version loaded on the IOLM.
discovery-protocol	The Discovery Protocol version loaded on the IOLM.
ethernetip	The EtherNet/IP interfaces version loaded on the IOLM.
event-log	The Event log version loaded on the IOLM.
iolink-driver	The IO-Link driver version loaded on the IOLM.
modbus	If applicable, the Modbus/TCP interface version loaded on the IOLM.
opcua-server	If applicable, the opcua-server interface version loaded on the IOLM.
web-help	The web interface help version loaded on the IOLM.

IOLM Application Subassemblies (Continued)	
web-user-interface	The web interface version loaded on the IOLM.

5.2. Using the Web Interface to Update Software

The upper portion of the **Advanced | Software** page is used to update the IOLM images. The lower portion of this page is used for updating application subassemblies that are integrated in the Application Base.

Typically, the latest application subassemblies are available in the Application Base image. There may times when a feature enhancement or bug fix is available in an application subassembly and not yet available in the Application Base image.


5.2.1. Updating Images

Use this procedure to upload images using the **SOFTWARE** page.

1. Download the latest image from the [Control web site](#).

Note: Make sure that you download the appropriate software for your model. For example, the FPGA images are unique for different hardware models and protocol.

2. Open your browser and enter the IP address of the IOLM.
3. Click **Advanced | SOFTWARE**.
4. Click the **UPDATE** button next to the image you want to update.
5. Click the **Browse** button, navigate to the file location, highlight the image, and click **Open**.
6. Click the **Install** button.



7. Click the **CONTINUE** button to the *Update Image* message.

8. Click **OK** to close the *Update Image Successful* message.
Note: Some images may require the IOLM web server to restart.

5.2.2. Updating Application Subassemblies

Use this procedure to upload applications using the **Software** page.

1. Download the latest application from the [Control web site](#).
2. Open your browser and enter the IP address of the IOLM.
3. Click **Advanced** and **SOFTWARE**.
4. Click the **Browse** button under **Update Application** navigate to the file location, highlight the application, and click **Open**.
5. Click the **Install** button.
6. Click the **CONTINUE** button to the *Update Application* message.

The screenshot shows the Control web interface. The top navigation bar includes 'CONTROL', 'Home', 'Diagnostics', 'Configuration', 'Advanced', 'Attached Devices', and 'Help'. The user is logged in as 'IO-Link Master DR-8-EIP'. The main content area is titled 'Software' and contains two sections: 'IMAGES' and 'APPLICATIONS'. The 'IMAGES' section has a table with columns for name, version, and an 'UPDATE' button. The 'APPLICATIONS' section has a table with columns for name and version. A modal dialog box titled 'Update Application In Progress' is overlaid on the page. The dialog contains the text: 'You are about to install configuration-manager_1.3.0.2_arm.ipk. It will replace any existing version of that package or image. Do NOT disconnect power during the installation process.' There are 'CONTINUE' and 'CANCEL' buttons in the dialog. At the bottom of the page, there is a 'REBOOT' button and a 'Update Application' section with 'Browse...' and 'Install' buttons. The footer shows the URL 'http://10.0.0.199/index.php/advanced_tab/software/app_save/current' and the copyright notice '© Copyright Control Corp.'

7. Click **OK** to close the *Update Application Successful* message.

Chapter 6. IO-Link Port Configuration

This chapter discusses port configuration, which includes these topics:

- *Preparing for Port Configuration*
- [IO-Link Configuration Page](#) on Page 41
- [EtherNet/IP Settings Configuration Page](#) on Page 46
- [Modbus/TCP Settings Configuration Page](#) on Page 54
- [OPC UA Settings Configuration Page](#) on Page 59 (not supported on all models)

Note: See [Chapter 7. Dedicated Digital I/O Port Configuration \(IOLM-DR-8-EIP\)](#) on Page 61 for information about configuring dedicated digital I/O ports (IOLM DR-8-EIP).

Depending on your environment, the IO-Link Master you may not need to change many of the default options.

6.1. Preparing for Port Configuration

Before beginning port configuration, you may want to verify that the connected device is functioning.

1. If necessary, log into the IO-Link Master.
2. Click **Diagnostics | IO-Link Diagnostics**.
3. Review the **Port Status** and **IOLink State**.

Port Status	Operational, PDI Valid	An IO-Link device is operating on the port that has received valid PDI data.
	Operational	An IO-Link device is operating on the port that has not received valid PDI data.
	Inactive	One of the following conditions exists: <ul style="list-style-type: none"> • A valid IO-Link device is not connected to the port. • A digital input or output device is connected to the port but the configured Port Mode is not correct.
IOLink State	Operate	Port is functioning correctly in IO-Link mode but has not received valid PDI data. This may also display during a data storage upload or download.
	Init	The port is attempting initialization.
	Reset	One of the following conditions exists: <ul style="list-style-type: none"> • The Port Mode configuration is set to Reset. • The Port Mode configuration is set to DigitalIn or DigitalOut.
	DS: Wrong Sensor	Hardware failure (IO-Link LED also flashes red) because there is Data Storage on this port, which does not reflect the attached device.
	DV: Wrong Sensor	Hardware failure (IO-Link LED also flashes red) because Device Validation is configured for this port and the wrong device is attached.
	DS: Wrong Size	Hardware failure (IO-Link LED also flashes red) because the size of the configuration on the device does not match the size of the configuration stored on the port.
	Comm Lost	Temporary state after a device is disconnected and before the port is re-initialized.
Pre-operate	Temporary status displayed when the device: <ul style="list-style-type: none"> • Is starting up after connection or power-up. • Uploading or downloading automatic data storage. 	

Note: If a digital input or output device is connected to an IO-Link port, there is no valid data until the port is set to the correct **Port Mode**.

4. Review the **Device IO-Link Version**.
 - If the field is blank, it is not a valid IO-Link device, which could mean that it is a digital device and the port has not been configured for digital input or digital output.
 - The field displays the Device IO-Link version.
5. Optionally, review the following to see if you need to change the **Configured Minimum Cycle Time**:
 - **Actual Cycle Time**
 - **Device Minimum Cycle Time**
 - **Configured Minimum Cycle Time**

The **Configured Minimum Cycle Time** is the minimum cycle time that the IO-Link Master allows the port to operate at. The **Actual Cycle Time** is negotiated between the IO-Link Master and the device and will be at least as long as the greater of the **Configured Minimum Cycle Time** and the **Device Minimum Cycle Time**.

6. Verify that the **Auxiliary Input Bit Status** field displays **On**, if the device is connected to DI (Pin 2 with M12 connectors).

The screenshot shows the 'IO-Link Diagnostics' page in a web browser. The page has a navigation bar with 'COMTROL' logo and menu items: Home, Diagnostics, Configuration, Advanced, Attached Devices, Help. The user is logged in as 'IO-Link Master 4-EIP'. Below the navigation bar are tabs for 'IO-LINK', 'ETHERNET/IP', 'MODBUS/TCP', and 'OPC UA'. The main content area is titled 'IO-Link Diagnostics' and includes buttons for 'UPDATE', 'STOP LIVE UPDATES', and 'RESET STATISTICS'. A table displays the status and configuration for four IO-Link ports (PORT 1 to PORT 4). The 'Port Status' and 'IOLink State' rows for PORT 1, 2, and 3 are highlighted in yellow. The footer of the page says 'Welcome Admin' and '© Copyright Control Corp.'.

IO-LINK PORT STATUS	PORT 1	PORT 2	PORT 3	PORT 4
Port Name	IO-Link Port 1	IO-Link Port 2	IO-Link Port 3	IO-Link Port 4
Port Mode	IOLink	IOLink	IOLink	IOLink
Port Status	Operational, PDI Valid	Operational	Operational, PDI Valid	Inactive
IOLink State	Operate	Operate	Operate	Init
Device Vendor Name	Leuze electronic GmbH + Co. KG	ifm electronic gmbh	wenglor sensoric gmbh	
Device Product Name	HRTR 46B/L4.23-S12	LR8000	OY1P303P0102	
Device Serial Number	1111C000485	d0033151013	540003706	
Device Hardware Version	C	AF	Version V01.00.00	
Device Firmware Version	01.15	354	Version V01.01.00	
Device IO-Link Version	1.1	1.1	1.1	
Actual Cycle Time	0.0ms	4.0ms	4.0ms	
Device Minimum Cycle Time	7.2ms	2.3ms	2.3ms	
Configured Minimum Cycle Time	4ms	4ms	4ms	
Data Storage Capable	No	Yes	No	

For additional information about the **IO-Link Diagnostics** page, see the help system or [11.1. IO-Link Port Diagnostics](#) on Page 106.

6.2. IO-Link Configuration Page

You can use the **Configuration | IO-Link Settings** page to configure IO-Link port settings. When the IO-Link device is attached to a port, it begins operating without requiring any configuration. The IOLM and attached IO-Link device automatically negotiate the **Minimum Cycle Time**. If required by an application, you can set a specific **Minimum Cycle Time**.

This page provides special features such as Data Storage, Device Validation, and Data Validation.

Note: *Data Storage, Device Validation, and Data Validation are discussed in [Chapter 10. Utilizing IOLM Features](#) on Page 83.*

This subsection discusses:

- [Editing IO-Link Port Settings](#) on Page 42
- [IO-Link Settings Parameters](#) on Page 43.

IO-LINK PORT CONFIG	PORT 1	PORT 2	PORT 3	PORT 4	PORT 5	PORT 6	PORT 7	PORT 8
Port Name	IO-Link Port 1	IO-Link Port 2	IO-Link Port 3	IO-Link Port 4	IO-Link Port 5	IO-Link Port 6	IO-Link Port 7	IO-Link Port 8
Port Mode	IOLink	IOLink	IOLink	IOLink	IOLink	IOLink	IOLink	IOLink
Invert SIO	false	false	false	false	false	false	false	false
Invert Auxiliary Input	false	false	false	false	false	false	false	false
Default Digital Output	Off	Off	Off	Off	Off	Off	Off	Off
Minimum Cycle Time (4 - 538)	4 ms	4 ms	4 ms	4 ms	4 ms	4 ms	4 ms	4 ms
Auxiliary Input Settling Time (0 - 10000)	0 ms	0 ms	0 ms	0 ms	0 ms	0 ms	0 ms	0 ms
Auxiliary Input Hold Time (0 - 10000)	0 ms	0 ms	0 ms	0 ms	0 ms	0 ms	0 ms	0 ms
SIO Input Settling Time (0 - 10000)	0 ms	0 ms	0 ms	0 ms	0 ms	0 ms	0 ms	0 ms
SIO Input Hold Time (0 - 10000)	0 ms	0 ms	0 ms	0 ms	0 ms	0 ms	0 ms	0 ms
Data Storage Config								
Storage Contents	empty	empty	empty	empty	empty	empty	empty	empty
Automatic Upload Enable	Off	Off	Off	Off	Off	Off	Off	Off
Automatic Download Enable	Off	Off	Off	Off	Off	Off	Off	Off
Data Storage Manual Ops								
	CLEAR	CLEAR	CLEAR	CLEAR	CLEAR	CLEAR	CLEAR	CLEAR
Validation Config								
Device Validation Mode	None	None	None	None	None	None	None	None
Vendor Id (0 - 65535)	0	0	0	0	0	0	0	0
Device Id (0 - 16777215)	0	0	0	0	0	0	0	0
Serial Num								
Data Validation Mode	None	None	None	None	None	None	None	None
PDI Length (0 - 32)	0 byte	0 byte	0 byte	0 byte	0 byte	0 byte	0 byte	0 byte
PDO Length (0 - 32)	0 byte	0 byte	0 byte	0 byte	0 byte	0 byte	0 byte	0 byte
	GET ATTACHED	GET ATTACHED	GET ATTACHED	GET ATTACHED	GET ATTACHED	GET ATTACHED	GET ATTACHED	GET ATTACHED

Note: *This image shows the IOLM DR-8-EIP, which provides dedicated Digital I/O ports and a Configuration page.*

6.2.1. Editing IO-Link Port Settings

You can use this procedure to configure IO-Link settings for each IO-Link port.

If an IO-Link device is attached to the port, no configuration is required for operation. If a digital input or output device is attached, it is necessary to change the **Port Mode**.

1. If necessary, open the IO-Link Master web interface with your web browser using the IP address.
2. Click **Configuration | IO-Link Settings**.
3. Click the **EDIT** button for the port or ports that you want to configure.

The screenshot shows the 'IO-Link Settings' page with a navigation menu at the top. The main content area is titled 'IO-Link Settings' and contains a table with columns for 'PORT 6', 'PORT 7', and 'PORT 8'. Each column has an 'EDIT' button. The 'SAVE' button for Port 6 is highlighted with a red box. A red text overlay says 'Click SAVE after changing the settings'. The table contains various configuration parameters such as Port Name, Port Mode, Invert SIO, Invert Auxiliary Input, Default Digital Output, Minimum Cycle Time, Auxiliary Input Setting Time, Auxiliary Input Hold Time, SIO Input Setting Time, SIO Input Hold Time, Data Storage Config, and Validation Config.

Note: This illustrates an 8-Port, where Port 6 is now configured for DigitalIn.

Note: You can click each **EDIT** button and open all ports to quickly configure port parameters.

4. Make appropriate selections for the device that you connected to that port.

Make sure you select the **DigitalIn** option for a digital input device and the **DigitalOut** option for a digital output device for the **Port Mode**.

The IOLM negotiates the **Minimum Cycle Time** so it is not necessary to set a cycle time unless you need a specific cycle time.

You can use the help system if you require definitions or values for the options or refer to the following subsection (*IO-Link Settings Parameters*).

Note: Do not enable **Automatic Download** and then attempt device configuration as **Automatic Download** changes the settings back to what is stored on the IOLM. **Data Storage**, **Device Validation**, and **Data Validation** are discussed in [Chapter 10. Utilizing IOLM Features](#) on Page 83.

5. Click the **SAVE** button for each port.
6. Return to the **IO-Link Diagnostics** page to verify that your changes have taken affect.

Note: Port 6 now indicates that it is functioning as a valid digital input device and the friendly port names are displaying.

6.2.2. IO-Link Settings Parameters

The **Configuration | IO-Link Settings** page supports the following options.

IO-LINK Settings Page	
Port Name	User defined port or device description. <ul style="list-style-type: none"> Standard ASCII characters Max length = 80 characters
Port Mode <i>Default: IO-Link</i>	Selected IO-Link port mode. Valid settings are: <ul style="list-style-type: none"> Reset - Select to disable a port or to reset/restart an IO-Link port. IO-Link - Select to connect and operate an IO-Link device on the port. Digital In - Select if a DI device is attached to the port. Digital Out - Select if a DO device is attached to the port.
Invert SIO <i>Default: False</i>	If enabled and the Port Mode is Digital In or Digital Out , this option inverts the SIO value. <ul style="list-style-type: none"> False (Disabled - Do not invert SIO) True (Enabled - Invert SIO) <p><i>Note: This option does not affect the Auxiliary Input.</i></p>
Invert Auxiliary Input	If this option is enabled, the Auxiliary bit is inverted.
Default Digital Output <i>Default: Off</i>	If the port mode is Digital Out , defines the default digital output value that is used at startup and when there is no active PDO controller. <ul style="list-style-type: none"> Off (low voltage) - 0 On (high voltage) - 24V
Minimum Cycle Time <i>Default: 4</i>	The minimum, or fastest, cycle time at which the IO-Link device may operate. The valid range is 4-538 ms. You can leave the Minimum Cycle Time set to the default value and the IO-Link Master negotiates with the IO-Link device for its minimum cycle time. The IO-Link Diagnostics page displays the Actual Cycle Time , which is the negotiated cycle time.
Auxiliary Input Settling Time (0 - 10000)	The auxiliary input settling time that remains constant before that input is considered/accepted
Auxiliary Input Hold Time (0 - 10000)	This is how long the IO-Link Master keeps the input at its present value. For example, if the IO-Link Master detects the input to go to high, and the hold time is X milliseconds, then the IO-Link Master reports the input as high for X milliseconds, even though the input itself may have gone away already. If X is zero, then you get the behavior currently in the field.
SIO Input Settling Time (0 - 10000)	The SIO input settling time that remains constant before that input is considered/accepted.
SIO Input Hold Time (0 - 10000)	This is how long the IO-Link Master keeps the input at its present value. For example, if the IO-Link Master detects the input to go to high, and the hold time is X milliseconds, then the IO-Link Master reports the input as high for X milliseconds, even though the input itself may have gone away already. If X is zero, then you get the behavior currently in the field.

IO-LINK Settings Page (Continued)	
Data Storage Config	
Storage Contents	Indicates that the data storage for the port is empty or displays the Vendor ID and Product ID of the data stored on that port.
Automatic Data Storage Upload Enable <i>Default: Off</i>	<p>When this option is initially set to On, the IOLM saves the data storage parameters (if the data storage is empty) from the IO-Link device to the IOLM.</p> <p>Automatic upload occurs when the Automatic Upload Enable option is set to On and one of these conditions exists:</p> <ul style="list-style-type: none"> • There is no upload data stored on the gateway and the IO-Link device is connected to the port. • The IO-Link device has the DS_upload bit on (generally because you have changed the configuration via Teach buttons or web page). <p>When a port contains data storage for an IO-Link device and if you attach a device whose Vendor and Device ID do not match, the IO-Link LED on the IOLM flashes red to indicate a wrong device is attached. In addition, the <i>IO-Link Diagnostics</i> page displays DS: Wrong Sensor in the IOLink State field.</p> <p>Note: <i>Not all device parameters are sent to data storage, this is determined by the IO-Link device manufacturer.</i></p>
Automatic Data Storage Download Enable <i>Default: Off</i>	<p>The data storage parameters on the IOLM are downloaded to the connected IO-Link device if:</p> <ol style="list-style-type: none"> 1. The Automatic Download option is enabled. 2. The data stored on the IOLM port contains the same Vendor ID and Product ID as the IO-Link device connected to the port. 3. Data storage parameters are also downloaded to the IO-Link device if configuration changes are made on the device causing the DS_upload bit to turn on and automatic upload is not enabled. 4. The IO-Link device requests an upload and the Automatic Upload Enable option is set to Off. <p>If you change configuration parameters on the IO-Link device and want the parameters to remain loaded on the IO-Link device, you must disable the Automatic Download option because otherwise the IOLM will reload the data storage on the port down to the IO-Link device.</p>
Data Storage Manual Ops	<p>The Manual Data Storage Ops option provides the following functionality, if data storage is supported by the IO-Link device.</p> <ul style="list-style-type: none"> • CLEAR - this clears any stored data for an IO-Link device on this port. • UPLOAD - this uploads and stores the IO-Link device configuration on the IOLM. • DOWNLOAD - this downloads the stored IO-Link device configuration from the IOLM to the IO-Link device attached to this port if the Vendor ID and Device ID match.

IO-LINK Settings Page (Continued)	
Validation Config	
Device Validation Mode (Default: None)	<p>Device Validation Mode provides these options:</p> <ul style="list-style-type: none"> • None - this disables Device Validation Mode. • Compatible - permits a compatible IO-Link device (same Vendor ID and Device ID) to function on the corresponding port. • Identical - only permits an IO-Link device to function on the corresponding port as defined in the following fields. <ul style="list-style-type: none"> - Vendor ID - Device ID - Serial Number <p>Note: <i>Connecting an IO-Link device that is different than the configured with Data Validation enabled will generate a DV: wrong sensor error.</i></p>
Vendor Id (0-65535)	<p>This is required if you select a Device Validation Mode other than <i>None</i>.</p> <p>The Vendor ID can be manually entered in this field or click the GET ATTACHED button and the IO-Link Master populates the Vendor ID in this field.</p>
Device Id (0-16777215)	<p>This is required if you select a Device Validation Mode other than <i>None</i>.</p> <p>The Device ID can be manually entered in this field or click the GET ATTACHED button and the IO-Link Master populates the Device ID in this field.</p>
Serial Num	<p>This is required if you select Identical for the Device Validation Mode.</p> <p>The Serial Number can be manually entered in this field or click the GET ATTACHED button and the IO-Link Master populates the serial number in this field.</p>
Data Validation Mode (Default: None)	<p>There are three Data Validation Modes:</p> <ul style="list-style-type: none"> • None - no data validation is performed on the port. • Loose - the slave device's PDI/PDO lengths must be less than or equal to the user-configured values. • Strict - the slave device's PDI/PDO lengths must be the same as the user-configured values.
PDI Length (0-32)	<p>This is input length of the PDI data field.</p> <p>This is required if you select a Data Validation Mode other than <i>None</i>.</p> <p>The PDI Length can be manually entered in this field or click the GET ATTACHED button and the IO-Link Master populates the PDI length in this field.</p>
PDO Length (0-32)	<p>This is input length of the PDO data field.</p> <p>This is required if you select a Data Validation Mode other than <i>None</i>.</p> <p>The PDO Length can be manually entered in this field or click the GET ATTACHED button and the IO-Link Master populates the PDO length in this field.</p>
GET ATTACHED (Button)	<p>After opening a port for editing, you can click the GET ATTACHED button to automatically populate the following fields with data from the IO-Link device:</p> <ul style="list-style-type: none"> • Vendor Id • Device Id • Serial Num • PDI Length • PDO Length

6.3. EtherNet/IP Settings Configuration Page

Use the EtherNet/IP Settings page to configure EtherNet/IP options.


You may want to refer to the following sections for additional information:

- [Chapter 12. EtherNet/IP Interface](#) on Page 119 provides a functionality summary, data type definitions, terms and conditions, and data transfer methods.
- [Chapter 13. Functionality Descriptions](#) on Page 125 discusses process data block descriptions, event handling, and ISDU handling.
- [Chapter 14. EtherNet/IP CIP Object Definitions](#) on Page 147, which explains vendor specific CIP object definitions.
- [Chapter 15. ControlLogix Family - Example PLC Programs](#) on Page 181, which provides is intended to provide basic working functionality.
- [Chapter 16. SLC/PLC-5/MicroLogix Interface](#) on Page 203 lists requirements and discusses PLC-5 and SLC messages, and PDI and PDO access via PCCC messages.
- [Chapter 17. EDS Files](#) on Page 209 provides installation instructions to add the EDS files to RSLinx.

This subsection includes the following topics:

- [Editing EtherNet/IP Settings](#) on Page 47
- [EtherNet/IP Settings Parameters](#) on Page 48

Note: The IO-Link Master may work out of the box for ControlLogix PLCs



Note: This illustrates a partial screen shot, scroll through the settings table to view all of the available settings.

6.3.1. Editing EtherNet/IP Settings

You can use this procedure to configure EtherNet/IP characteristics for each port.

1. If necessary, open the IO-Link Master web interface with your web browser using the IP address.
2. Click **Configuration | EtherNet/IP**.
3. Click the **EDIT** button for each port that you want to configure.

Click SAVE after making changes **Click EDIT to make changes**

ETHERNET/IP PORT CONFIG	PORT 1	PORT 2	PORT 3	PORT 4
	CANCEL SAVE EDIT		EDIT	EDIT
ISDU Data Settings:				
ISDU Response Timeout (1 - 10000)	20 sec	20 sec	20 sec	20 sec
Process Data Settings:				
PDI Data Block Size (To PLC)	16 bytes	36 bytes	36 bytes	36 bytes
PDI Data Block Format (To PLC)	byte (8 bit)	word (16 bit)	word (16 bit)	word (16 bit)
PDI Data Byte-Swap Method	no byte-swap	word (16 bit) byte-swap	word (16 bit) byte-swap	word (16 bit) byte-swap
PDO Data Block Size (From PLC)	16 bytes	32-bytes	32-bytes	32-bytes
PDO Data Block Format (From PLC)	byte (8 bit)	word (16 bit)	word (16 bit)	word (16 bit)
PDO Data Byte-Swap Method	word (16 bit) byte-swap	word (16 bit) byte-swap	word (16 bit) byte-swap	word (16 bit) byte-swap
ETHERNET/IP CONFIGURATION	EDIT			
TTL (Time To Live) Network Value (1 - 255)	1 hop(s)			
Multicast IP Address Allocation Control	Automatic			
User-Defined Number of Multicast IP Addresses (1 - 32)	32			
User-Defined Multicast Start IP Address (239.192.1.0 - 239.255.255.255)	239.192.1.0			
Session Encapsulation Timeout (0=disable; 1-3600 sec) (0 - 3600)	120			

Welcome Admin © Copyright Control Corp.

Note: You can click each **EDIT** button and open all ports to quickly configure port parameters.

4. Make appropriate selections for the device that is connected to the port.

You can use the help system if you require definitions or values for the options or refer to *EtherNet/IP Settings Parameters* in the next subsection.

5. Scroll to the top of the page and click the **SAVE** button.
Make sure that the port now displays the **EDIT** button.

6.3.2. EtherNet/IP Settings Parameters

The Configuration | EtherNet/IP Settings page supports the following options.

EtherNet/IP Settings Page	
<i>ISDU Data Settings</i>	
ISDU Response Timeout <i>Default: 20 seconds</i>	The time that the IO-Link Master’s EtherNet/IP interface waits for a response to an ISDU request. The timeout needs to set long enough to allow all commands within the ISDU request to be processed. Valid range: 1-10,000 seconds
<i>Process Data Settings</i>	
PDI Data Block Size (To PLC) <i>Default: 36-bytes</i>	The configurable PDI data block length. Supported optional lengths are: <ul style="list-style-type: none"> • 4-bytes (header only) • 8-bytes (4 bytes data) • 10-bytes (6 bytes data) • 16-bytes (12 bytes data) • 20-bytes (16 bytes data) • 24-bytes (20 bytes data) • 36-bytes (32 bytes data)
PDI Data Block Format (To PLC) <i>Default: Word-16</i>	Data format of PDI data block to be transferred to the PLC(s) in Class 1 and/or Write-to-Tag/File PDI Transfer Modes. Supported formats are: <ul style="list-style-type: none"> • Byte-8 (8-bit or SINT) • Word-16 (16-bit or INT) • Dword-32 (32-bit or DINT) <p>Note: <i>The Data Block Format is independent of the PDI Data Byte-Swap Method.</i></p> <p><i>This setting is not used for the SLC, PLC-5 and MicroLogix PLCs which are always Word-16.</i></p>
PDI Data Byte-Swap Method <i>Default: Work (16-bit) byte swap</i>	If enabled, the IO-Link Master swaps the data bytes in word (2 byte) format or dword (4 byte) format. Supported values are: <ul style="list-style-type: none"> • No byte-swap – data passed through as received • Word (16-bit) byte-swap – data is byte-swapped in word format • Dword (32-bit) byte-swap – data is byte-swapped in dword format • Reverse byte order – data passed through after being reversed <p>Note: <i>The byte swapping must be set correctly in order to convert from IO-Link (big-endian byte order), to EtherNet/IP (little-endian byte order).</i></p>
Include Digital I/O in PDI Data Block <i>Default: False</i> (IOLM DR-8-EIP, Only)	If enabled, the IO-Link Master includes the current digital I/O pins D1 to D4 status in the PDI data block header. <ul style="list-style-type: none"> • False – Do not include the digital I/O pins status • True (enable check box) – Include the digital I/O pins status in PDI data block header <p>Note: <i>Does not affect the Auxiliary Input.</i></p>

EtherNet/IP Settings Page (Continued)	
<p>PDO Data Block Size (From PLC) <i>Default: 32-bytes</i></p>	<p>The configurable PDO data block length. Supported optional lengths are:</p> <ul style="list-style-type: none"> • Event code not included: <ul style="list-style-type: none"> - 4-bytes = all data - 8-bytes = all data - 10-bytes = all data - 16-bytes = all data - 20-bytes = all data - 24-bytes = all data - 32-bytes = all data - 34-bytes = 32 bytes data, 2 pad bytes - 36-bytes = 32 bytes data, 4 pad bytes • Event code included - PDO Data Format = Byte8: <ul style="list-style-type: none"> - 4-bytes = 2 byte event code, 2 data bytes - 8-bytes = 2 byte event code, 6 data bytes - 10-bytes = 2 byte event code, 8 data bytes - 16-bytes = 2 byte event code, 14 data bytes - 20-bytes = 2 byte event code, 18 data bytes - 24-bytes = 2 byte event code, 22 data bytes - 32-bytes = 2 byte event code, 30 data bytes - 34-bytes = 2 byte event code, 32 data bytes - 36-bytes = 2 byte event code, 32 data bytes, 2 byte pad • Event code included - PDO Data Format = word (16-bit): <ul style="list-style-type: none"> - 4-bytes = event code word, data word - 8-bytes = event code word, 3 data words - 10-bytes = event code word, 4 data words - 16-bytes = event code word, 7 data words - 20-bytes = event code word, 9 data words - 24-bytes = event code word, 11 data words - 32-bytes = event code word, 15 data words - 34-bytes = event code word, 16 data words - 36-bytes = event code word, 16 data words, pad word • Event code included - PDO Data Format = dword (32-bit): <ul style="list-style-type: none"> - 4-bytes = event code dword - 8-bytes = event code dword, data dword - 10-bytes = event code dword, data dwords - 16-bytes = event code dword, 3 data dwords - 20-bytes = dword event code, 4 data dwords - 24-bytes = dword event code, 5 data dwords - 32-bytes = dword event code, 7 data dwords - 34-bytes = dword event code, 7 data dwords, 2 data bytes - 36-bytes = dword event code, 8 data dwords

EtherNet/IP Settings Page (Continued)	
PDO Data Block Format (From PLC) <i>Default: Word-16</i>	Data format of PDO data block received from the PLC(s) in Class 1 or Read from TagOrFile PDO Transfer Modes. Formats include: <ul style="list-style-type: none"> • Byte-8 (8-bit) • Word-16 (16-bit) • Dword-32 (32-bit) <p>Note: <i>The Data Block Format is independent of the PDO Data Byte-Swap Method.</i></p> <p style="text-align: center;"><i>This setting is not used for the SLC, PLC-5 and MicroLogix PLCs which are always Word-16.</i></p>
PDO Data Byte-Swap Method <i>Default: Word (16-bit) byte-swap</i>	If enabled, the IO-Link Master swaps the data bytes in word (2 byte) format or dword (4 byte) format. Supported values are: <ul style="list-style-type: none"> • No byte-swap – data passed through as received • Word (16-bit) byte-swap – data is byte-swapped in word format • Dword (32-bit) byte-swap – data is byte-swapped in dword format • Reverse byte order – data passed through after being reversed <p>Note: <i>The byte swapping must be set correctly in order to convert from EtherNet/IP (little-endian byte order), to IO-Link (big-endian byte order).</i></p>
Clear Event Code in PDO Block <i>Default: False</i>	If enabled, the IO-Link Master expects the first 2 bytes, word, or dword of the PDO block to be used for event code handling. Supported values are: <ul style="list-style-type: none"> • True (enable check box) = expect event code • False = no event code, expect only PDO data
Clear Event Code After Hold Time <i>Default: True</i>	If enabled, the IO-Link Master clears any event code reported in the PDI data block after the Event Active Hold Time . Supported values are: <ul style="list-style-type: none"> • True (enable check box) = clear event code after hold time • False = do not clear event code after hold time
Active Event Hold Time <i>Default: 1000 ms</i>	If Clear Event Code After Hold time is enabled, the time period an event code is reported in the PDI block before it is cleared. <ul style="list-style-type: none"> • Valid range: 1-65535 • Valid units: <ul style="list-style-type: none"> - ms (milliseconds) - sec (seconds) - min (minutes) - hours - days
Event Hold Time Units <i>Default: ms</i>	Valid units: <ul style="list-style-type: none"> • ms (milliseconds) • sec (seconds) • min (minutes) • hours • days

EtherNet/IP Settings Page (Continued)	
<p>Clear Event Hold Time <i>Default: 500 ms</i></p>	<p>Once an event code has been cleared, the time an event code stays cleared in the PDI block before another event code can be reported.</p> <ul style="list-style-type: none"> • Valid range: 1-65535 • Valid units: <ul style="list-style-type: none"> - ms (milliseconds) - sec (seconds) - min (minutes) - hours - days
<p>Event Clear Time Units <i>Default: ms</i></p>	<p>Once an event code has been cleared, the time an event code stays cleared in the PDI block before another event code can be reported.</p> <p>Valid units:</p> <ul style="list-style-type: none"> • ms (milliseconds) • sec (seconds) • min (minutes) • hours • days
<p>Include Digital Output(s) in PDO Data Block <i>Default: False</i></p>	<p>If enabled, the IO-Link Master expects the digital output settings to be included in the PDO data block.</p> <p>False – The digital pin setting(s) are not included in the PDO data block.</p> <p>True (enable check box) – The digital pin setting(s) are included in the PDO data block.</p>
<i>Transfer Mode Settings</i>	
<p>PDI Receive Mode(s) to PLC <i>Default: Polling, Class1</i></p>	<p>Determines which PDI Receive (To PLC) Modes are enabled. Supported modes are:</p> <ul style="list-style-type: none"> • Polling • Class1 • Write-to-TagOrFile
<p>PDO Transmit Mode from PLC <i>Default: Class 1</i></p>	<p>Supported modes are:</p> <ul style="list-style-type: none"> • Off • PLC-Writes • Class1 • Read-from-TagOrFile
<i>Read / Write Tag / File Settings</i>	
<p>PLC IP Address (xxx.xxx.xxx.xxx) <i>Default: 0.0.0.0</i></p>	<p>The PLC IP Address is required if either Write-to-TagOrFile or Read-from-TagOrFile mode are enabled.</p> <p>Format: xxx.xxx.xxx.xxx</p>
<p>PLC Controller Slot Number <i>Default: 0</i></p>	<p>The PLC Controller Slot Number is required if either Write-to-TagOrFile or Read-from-TagOrFile mode are enabled.</p> <p>Valid range: 0-64</p>

EtherNet/IP Settings Page (Continued)	
PLC Type <i>Default: ControlLogix</i>	Indicates the type of PLC that the tag(s) or file(s) are written to and/or read from. Supported PLC Types are: <ul style="list-style-type: none"> • ControlLogix • SLC • PLC-5 • MicroLogix
<i>Write PDI to Tag/File Settings</i>	
PDI Tag/File Name <i>Default: blank</i>	The tag or file name to place the PDI data block. <ul style="list-style-type: none"> • ControlLogix family: <ul style="list-style-type: none"> - Tags must be same type as PDI Data Format (SINT, INT or DINT). - Tags must be an array. - Tags must be at least as long as the PDI Data Block Length. • SLC/PLC-5/MicroLogix: <ul style="list-style-type: none"> - Files must be of INTEGER (16-bit) type. - Files must be named with standard file name conventions (i.e: N10:0, N21:30, etc) - The file must be at least as long as the PDI Data Block Length.
Append PDO to PDI Data <i>Default: False</i>	If selected, the IO-Link Master appends any PDO data to the end of the PDI data. <ul style="list-style-type: none"> • False = Do not append PDO data • True (enable check box) = Append PDO data
Maximum PLC Update Rate <i>Default: 40ms</i>	The maximum rate at which the IO-Link Master updates the PDI tag or file. This parameter is used to ensure that the PLC receives all state changes. Setting the update rate to 10 ms effectively disables this feature. The valid range is 10 to 65535 ms.
Heartbeat Update Enable <i>Default: False</i>	If selected, the IO-Link Master updates the PDI data block at the Heartbeat Update Rate . <ul style="list-style-type: none"> • False = Heartbeat update disabled • True (enable check box) = Heartbeat update enabled
Heartbeat Update Rate <i>Default: 1000ms</i>	If Heartbeat Update Enable is selected, the rate at which the IO-Link Master updates the PDI data block in the Write-to-Tag/File mode. The valid range is 50 to 65535 ms.

EtherNet/IP Settings Page (Continued)	
<i>Read PDO from Tag / File Settings</i>	
PDO Tag/File Name <i>Default: blank</i>	The tag or file name that the IO-Link Master reads the PDO data block from. <ul style="list-style-type: none"> • ControlLogix family: <ul style="list-style-type: none"> - Tags must be same type as PDO Data Format (SINT, INT or DINT). - Tags must be an array. - Tags must be at least as long as the PDO Data Block Length. • SLC/PLC-5/MicroLogix: <ul style="list-style-type: none"> - Files must be of INTEGER (16-bit) type. - Files must be named with standard file name conventions (i.e: N10:0, N21:30, etc) The file must be at least as long as the PDO Data Block Length .
PLC Poll Rate <i>Default: 1000ms</i>	The frequency which the IO-Link Master reads the PDO data block in the Read-from-Tag/File mode. Valid range: 50-65535 ms
TTL (Time To Live) Network Value (1-255) (Default: 1)	The TTL value indicates how many network “hops” can be made for Multicast packets. It is used to prevent Multicast packets from being forwarded beyond its own subnet(s). Each network router decreases the hop count when forwarding the Multicast packet. Once the hop count reaches zero, the Multicast packet is no longer forwarded.
Multicast IP Address Allocation Control (Default: Automatic)	This setting indicates how the starting Multicast address is determined. <ul style="list-style-type: none"> • Automatic – The IO-Link Master determines the starting Multicast IP address based on an EtherNet/IP specification algorithm. • User-Defined – The user sets the starting Multicast address.
User-Defined Number of Multicast IP Addresses (1-32) (Default: 32)	When the Multicast IP Address Allocation Control is set to User-Defined, the maximum number of Multicast addresses that the IO-Link Master may use.
User-Defined Multicast Start IP Address (239.192.1.0-239.255.255.255) (Default: 239.192.1.0)	When the multicast IP Address Allocation Control is set to User-Defined, the Multicast starting IP address for the IO-Link Master. Make sure you avoid redundant Multicast IP addresses on a network.
Session Encapsulation Timeout (0=disable; 1-3600 sec) (0 - 3600) (Default = 120)	Defines the inactivity period before an established session between a controller, such as a PLC, and the IOLM will time out. If such a timeout occurs, the current session is closed and a new session must be established before communications can resume between the controller and the IOLM.

6.4. Modbus/TCP Settings Configuration Page

You can use the **Configuration | Modbus/TCP Settings** page to configure Modbus/TCP with the IO-Link Master. Additional Modbus information is available in the following chapters:

- [Chapter 13. Functionality Descriptions](#) on Page 125
- [Chapter 18. Modbus/TCP Interface](#) on Page 211

This subsection includes these topics:

- [Editing Modbus/TCP Settings](#) on Page 55
- [Modbus/TCP Settings Parameters](#) on Page 56


The screenshot displays the 'Modbus/TCP Settings' configuration page. At the top, there is a navigation bar with 'CONTROL' logo and tabs for Home, Diagnostics, Configuration, Advanced, Attached Devices, and Help. The 'Configuration' tab is active. Below the navigation bar, there are links for IO-LINK, ETHERNET/IP, MODBUS/TCP, OPC UA, NETWORK, MISC, LOAD/SAVE, and CLEAR SETTINGS. The main content area is titled 'Modbus/TCP Settings' and contains a table for 'MODBUS/TCP PORT CONFIG' with four columns: PORT 1, PORT 2, PORT 3, and PORT 4. Each column has an 'EDIT' button. Below the table are sections for 'ISDU Data Settings', 'Process Data Settings', and 'Transfer Mode Settings'. At the bottom, there is a 'MODBUS/TCP CONFIGURATION' section with a 'Modbus Enable' dropdown menu currently set to 'disable' and an 'EDIT' button.

MODBUS/TCP PORT CONFIG	PORT 1	PORT 2	PORT 3	PORT 4
	<input type="button" value="EDIT"/>	<input type="button" value="EDIT"/>	<input type="button" value="EDIT"/>	<input type="button" value="EDIT"/>
ISDU Data Settings:				
ISDU Response Timeout (1 - 10000)	20 sec	20 sec	20 sec	20 sec
Process Data Settings:				
PDI Data Block Size (To PLC)	36 bytes	36 bytes	36 bytes	36 bytes
PDI Byte-Swap Method	no byte-swap	no byte-swap	no byte-swap	no byte-swap
PDO Data Block Size (From PLC)	32-bytes	32-bytes	32-bytes	32-bytes
PDO Byte-Swap Method	no byte-swap	no byte-swap	no byte-swap	no byte-swap
Append PDO to PDI Data	false	false	false	false
Clear Event Code In PDO Block	false	false	false	false
Clear Event Code After Hold Time	true	true	true	true
Active Event Hold Time (1 - 65535)	1000	1000	1000	1000
Event Hold Time Units	ms	ms	ms	ms
Clear Event Hold Time (1 - 65535)	500	500	500	500
Event Clear Time Units	ms	ms	ms	ms
Transfer Mode Settings:				
Slave Mode Device ID (1 - 247)	1	1	1	1
PDI Receive Mode(s) (To PLC)	Slave	Slave	Slave	Slave
MODBUS/TCP CONFIGURATION				<input type="button" value="EDIT"/>
Modbus Enable	disable			

Note: Modbus is disabled by default. To use Modbus, click the **EDIT** button and select **Enable**.

6.4.1. Editing Modbus/TCP Settings

1. If necessary, open the IO-Link Master web interface with your web browser using the IP address.
2. Click **Configuration | Modbus/TCP**.
3. Click the **EDIT** button for the port that you want to configure.



Note: You can click each **EDIT** button and open all ports to quickly configure port parameters.

4. Make appropriate selections for the IO-Link device that you will connect to that port. You can use the help system if you require definitions or values for the options or [Modbus/TCP Settings Parameters](#) on Page 56.
5. Scroll to the top of the page and click the **SAVE** button.
Make sure that the port now displays the **EDIT** button.

If it displays the **SAVE** and **CANCEL** buttons, that means that one of the parameters contains an incorrect value. If necessary, scroll down the page, make the needed corrections, and click **SAVE**.

6.4.2. Modbus/TCP Settings Parameters

The following table provides detailed information about the Modbus/TCP Settings page.

Modbus/TCP Settings Page	
ISDU Response Timeout <i>Default = 20 seconds</i>	The time that the IO-Link Master's Modbus/TCP interface waits for a response to an ISDU request. The timeout needs to set long enough to allow all commands within the ISDU request to be processed. Valid range: 1-10,000 seconds
<i>Process Data Settings</i>	
PDI Data Block Size <i>Default: 36-bytes</i>	The configurable PDI data block length. Optional lengths are: <ul style="list-style-type: none"> • 4-bytes (header only) • 8-bytes (4 bytes data) • 16-bytes (12 bytes data) • 24-bytes (20 bytes data) • 36-bytes (32 bytes data)
PDI Byte-Swap Method <i>Default: No byte-swap</i>	If enabled, the IO-Link Master swaps the data bytes in word (2 byte) format or dword (4 byte) format. Options include: <ul style="list-style-type: none"> • No byte-swap – data passed through as received • Word (16-bit) byte-swap – data is byte-swapped in word format • Dword (32-bit) byte-swap – data is byte-swapped in dword format • Reverse registers – data passed through after being reversed <p><i>Note: Because both IO-Link and Modbus/TCP use big-endian byte ordering, byte swapping typically is not required for word and dword data.</i></p> <p><i>Byte swapping is most commonly required when receiving byte (8-bit) data and it is desired to place the first data byte in the least significant byte position of the holding register. For these cases, word (16 bit) byte-swap is typically used.</i></p>
Include Digital I/O in PDI Data Block <i>Default: False</i>	If enabled, the IO-Link Master includes the current digital I/O pins D1 to D4 status in the PDI data block header. <ul style="list-style-type: none"> • False – Do not include the digital I/O pins status • True (enable check box) – Include the digital I/O pins status in PDI data block header <p><i>Note: Does not affect the Auxiliary Input.</i></p>

Modbus/TCP Settings Page (Continued)	
<p>PDO Data Block Size (From PLC) <i>Default: 32-bytes</i></p>	<p>The configurable PDO data block length. Optional lengths are: Event code not included:</p> <ul style="list-style-type: none"> • 4-bytes = 2 data words • 8-bytes = 4 data words • 16-bytes = 8 data words • 24-bytes = 12 data words • 32-bytes = 16 data words • 34-bytes = 16 data words, 1 pad word <p>Event code included:</p> <ul style="list-style-type: none"> • 4-bytes = event code word, 1 data word • 8-bytes = event code word, 3 data words • 16-bytes = event code word, 7 data words • 24-bytes = event code word, 11 data words • 32-bytes = event code word, 15 data words • 34-bytes = event code word, 16 data words
<p>PDO Byte-Swap Method <i>Default: No byte-swap</i></p>	<p>If enabled, the IO-Link Master swaps the data bytes in word (2 byte) format or dword (4 byte) format. Options include:</p> <ul style="list-style-type: none"> • No byte-swap – data passed through as received • Word (16-bit) byte-swap – data is byte-swapped in word format • Dword (32-bit) byte-swap – data is byte-swapped in dword format • Reverse registers – data passed through after being reversed <p>Note: <i>Because both IO-Link and Modbus/TCP use big-endian byte ordering, byte swapping typically is not required for word and dword data.</i></p> <p><i>Byte swapping is most commonly required when sending byte (8-bit) data to the IO-Link device and it is desired to send the least significant byte of the holding register first. For these cases, word (16 bit) byte-swap is typically used.</i></p>
<p>Append PDO to PDI Data <i>Default: False</i></p>	<p>If selected, the IO-Link Master appends any PDO data to the end of the PDI data.</p> <ul style="list-style-type: none"> • False = Do not append PDO data • True (enable check box) = Append PDO data
<p>Clear Event Code in PDO Block <i>Default: False</i></p>	<p>If enabled, the IO-Link Master expects the first word of the PDO block to be used for event code handling.</p> <p>Values are:</p> <ul style="list-style-type: none"> • True (enable check box) = expect event code • False = no event code, expect only PDO data
<p>Clear Event Code After Hold Time <i>Default: True</i></p>	<p>If enabled, the IO-Link Master clears any event code reported in the PDI data block after the Event Active Hold Time.</p> <p>Values are:</p> <ul style="list-style-type: none"> • True (enable check box) = clear event code after hold time • False = do not clear event code after hold time

Modbus/TCP Settings Page (Continued)	
<p>Active Event Hold Time <i>Default: 1000 ms</i></p>	<p>If Clear Event Code After Hold Time is enabled, the time period an event code is reported in the PDI block before it is cleared.</p> <p>Valid range: 1-65535</p> <p>Valid Units are:</p> <ul style="list-style-type: none"> • ms (milliseconds) • sec (seconds) • min (minutes) • hours • days
<p>Event Hold Time Units</p>	<p>Valid Units:</p> <ul style="list-style-type: none"> • ms (milliseconds) • sec (seconds) • min (minutes) • hours • days
<p>Clear Event Hold Time <i>Default: 500 ms</i></p>	<p>Once an event code has been cleared, the time an event code stays cleared in the PDI block before another event code can be reported.</p> <p>Valid range: 1-65535</p> <p>Valid Units:</p> <ul style="list-style-type: none"> • ms (milliseconds) • sec (seconds) • min (minutes) • hours • days
<p>Event Clear Time Units</p>	<p>Valid Units:</p> <ul style="list-style-type: none"> • ms (milliseconds) • sec (seconds) • min (minutes) • hours • days
<p>Include Digital Output(s) in PDO Data Block <i>Default: False</i></p>	<p>If enabled, the IO-Link Master expects the digital output settings to be included in the PDO data block.</p> <ul style="list-style-type: none"> • False – The digital pin setting(s) are not included in the PDO data block • True (enable check box) – The digital pin setting(s) are included in the PDO data block

Modbus/TCP Settings Page (Continued)	
<i>Transfer Mode Settings</i>	
Slave Mode Device ID <i>Default: 1</i>	The Modbus Device ID used to access this IO-Link port. Range: 1-247
PDI Receive Mode(s) <i>Default: Slave</i>	Determines which PDI Receive (To PLC) Modes are enabled. The selectable modes is Slave. Note: <i>Not selecting slave mode disables Modbus/TCP access to the PDI data block.</i>
PDO Transmit Mode <i>Default: Slave</i>	Selectable Modes are: <ul style="list-style-type: none"> • Disabled • Slave

6.5. OPC UA Settings Configuration Page

Use the **Configure | OPC UA Settings** page to configure OPC UA with the IOLM.

Note: *Not all models support OPC UA.*

This subsection includes these topics:


- [Edit OPC UA Settings](#) on Page 60
- [OPC UA Settings Parameters](#) on Page 60

Note: *OPC UA is disabled by default.*

6.5.1. Edit OPC UA Settings

You can use this procedure to edit OPC UA settings.

1. If necessary, open the IO-Link Master web interface with your web browser using the IP address.
2. Click **Configuration | OPC UA**.
3. Click the **EDIT** button.



4. Make the appropriate selections for your environment. You can use the help system if you require definitions or values for the options or [6.5.2. OPC UA Settings Parameters](#) on Page 60.
5. Click the **SAVE** button.

6.5.2. OPC UA Settings Parameters

The following table provides information about the **OPC UA Setting** page.

Option	OPC UA Configuration Descriptions
OPC UA Server Enable (Default = disable)	This option controls whether or not the OPC UA server runs on the IO-Link Master.
Work-around for faulty OPC UA clients that require unique browsenames (Default = disable)	Enables an alternative set of browsenames where each node's browsename is unique. Normally only browsepaths are required to be unique.
Allow OPC UA clients to write PDO data (Default = disable)	Determines whether OPC UA clients are allowed to write PDO data to the IO-Link slaves.
Allow OPC UA clients to write ISDU data (Default = disable)	Determines whether OPC UA clients are allowed to write ISDU data to the IO-Link slaves.

Chapter 7. Dedicated Digital I/O Port Configuration (IOLM-DR-8-EIP)

This section discusses the dedicated digital IO port (D1 through D4) configuration, including these topics:

- [Digital I/O Settings Page](#)
- [Editing Digital I/O Settings](#) on Page 62
- [Digital I/O Setting Parameters](#) on Page 63

Note: Dedicated DIO ports are only available on the IOLM-DR-8-EIP.

7.1. Digital I/O Settings Page

Use the **Configuration | Digital I/O** page to configure the dedicated DIO port characteristics for the IOLM DR-8-EIP. **D1** and **D2** are located next to IO-Link Port 1 and **D3** and **D4** are located next to IO-Link Port 4.

The screenshot displays the 'Digital I/O Settings' page. At the top, there is a navigation bar with 'CONTROL' logo and menu items: Home, Diagnostics, Configuration, Advanced, Attached Devices, Help, and a user profile 'IO-Link Master DR-8-EIP (DUR)' with a Logout button. Below the navigation bar is a sub-menu with 'DIGITAL I/O' selected, along with other options like IO-LINK, ETHERNET/IP, MODBUS/TCP, OPC UA, NETWORK, MISC, LOAD/SAVE, and CLEAR SETTINGS.

The main content area is titled 'Digital I/O Settings' and contains a table for 'DIGITAL I/O CONFIGURATION'. The table has an 'EDIT' button in the top right corner. It is organized into four sections, one for each digital port:

DIGITAL I/O CONFIGURATION	
D1 Digital Input Configuration	
Mode	Off
Invert Input	false
Input Settling Time (0 - 10000)	0 ms
Input Hold Time (0 - 10000)	0 ms
D2 Digital I/O Configuration	
Mode	Off
Invert I/O	false
Default Digital Output	Off
Input Settling Time (0 - 10000)	0 ms
Input Hold Time (0 - 10000)	0 ms
D3 Digital Input Configuration	
Mode	Off
Invert Input	false
Input Settling Time (0 - 10000)	0 ms
Input Hold Time (0 - 10000)	0 ms
D4 Digital I/O Configuration	
Mode	Off
Invert I/O	false
Default Digital Output	Off
Input Settling Time (0 - 10000)	0 ms
Input Hold Time (0 - 10000)	0 ms

7.2. Editing Digital I/O Settings

You can use this procedure to configure digital I/O characteristics for the digital I/O ports.

1. If necessary, open the IOLM 8-EIP web interface with your web browser using the IP address.
2. Click **Configuration | Digital I/O**.
3. Click the **EDIT** button.
4. Make appropriate selections for the digital I/O device or devices that you will connect to the ports. You can use the help system if you require definitions or values for the options or [Digital I/O Setting Parameters](#) on Page 63.

Digital I/O Settings Click SAVE after making changes

DIGITAL I/O CONFIGURATION CANCEL SAVE

D1 Digital Input Configuration	
Mode	Digital-Input ▼
Invert Input	<input checked="" type="checkbox"/>
Input Settling Time (0 - 10000)	0 ms
Input Hold Time (0 - 10000)	0 ms

D2 Digital I/O Configuration	
Mode	Digital-Input ▼
Invert I/O	<input type="checkbox"/>
Default Digital Output	Off ▼
Input Settling Time (0 - 10000)	0 ms
Input Hold Time (0 - 10000)	0 ms

D3 Digital Input Configuration	
Mode	Off ▼
Invert Input	<input type="checkbox"/>
Input Settling Time (0 - 10000)	0 ms
Input Hold Time (0 - 10000)	0 ms

D4 Digital I/O Configuration	
Mode	Digital-Output ▼
Invert I/O	<input type="checkbox"/>
Default Digital Output	On ▼
Input Settling Time (0 - 10000)	0 ms
Input Hold Time (0 - 10000)	0 ms

Welcome Admin © Copyright Control Corp.

5. Click the **SAVE** button.

7.3. Digital I/O Setting Parameters

The Configuration | Digital I/O Settings page supports the following options.

Digital I/O Settings Page (IOLM-DR-8-EIP)	
D1 Digital Input Configuration	
Mode <i>Default = Off</i>	Selects the Mode : <ul style="list-style-type: none"> • Off – No monitoring of the digital input pin. • Digital-Input – monitors the digital input status
Invert Input <i>Default= False</i>	If Mode is set to Digital-Input , the input status is inverted.
Input Settling Time (0 - 10000ms) <i>Default= 0ms</i>	If non-zero and Mode is set to Digital-Input , the required time that the input status must remain constant before an input status change is reported.
Input Hold Time (0 - 10000ms) (Default: 0ms)	This is how long the IOLM keeps the input at its present value. For example, if the IOLM detects the input to go to high, and the hold time is X milliseconds, then the IOLM reports the input as high for X milliseconds, even though the input itself may have gone away already. If X is zero, then you get the behavior currently in the field.
D2 Digital I/O Configuration	
Mode <i>Default= Off</i>	Selects the Mode : <ul style="list-style-type: none"> • Off – No monitoring or setting of the digital I/O pin. • Digital-Input – monitors the digital input status • Digital-Output – sets the digital output to either the default setting or value received from a controller.
Invert I/O <i>Default= False</i>	If selected: <ul style="list-style-type: none"> • If Mode is set to Digital-Input, the input status is inverted. • If Mode is set to Digital-Output, the output setting is inverted.
Default Digital Output <i>Default= Off</i>	If Mode is set to Digital Output , defines the default digital output setting: <ul style="list-style-type: none"> • At startup before a controller can set the digital output. • When communication to all controller(s) has been lost. Possible settings: <ul style="list-style-type: none"> • Off - low voltage • On – high voltage
Input Settling Time (0 - 10000ms) <i>Default= 0ms</i>	If non-zero and Mode is set to Digital-Input , the required time that the input status must remain constant before an input status change is reported.
Input Hold Time (0 - 10000ms) (Default: 0ms)	This is how long the IOLM keeps the input at its present value. For example, if the IOLM detects the input to go to high, and the hold time is X milliseconds, then the IOLM reports the input as high for X milliseconds, even though the input itself may have gone away already. If X is zero, then you get the behavior currently in the field.

Digital I/O Settings Page (IOLM-DR-8-EIP)	
D3 Digital Input Configuration	
Mode <i>Default= Off</i>	Selects the Mode : <ul style="list-style-type: none"> • Off – No monitoring of the digital input pin. • Digital-Input – Monitors the digital input status
Invert Input <i>Default= False</i>	If Mode is set to Digital-Input , the input status is inverted.
Input Settling Time (0 - 10000) <i>Default= 0ms</i>	If non-zero and Mode is set to Digital-Input , the required time that the input status must remain constant before an input status change is reported.
Input Hold Time (0 - 10000ms) (Default: 0ms)	This is how long the IOLM keeps the input at its present value. For example, if the IOLM detects the input to go to high, and the hold time is X milliseconds, then the IOLM reports the input as high for X milliseconds, even though the input itself may have gone away already. If X is zero, then you get the behavior currently in the field.
D4 Digital I/O Configuration	
Mode <i>Default= Off</i>	Selects the Mode : <ul style="list-style-type: none"> • Off – No monitoring or setting of the digital I/O pin. • Digital-Input – Monitors the digital input status • Digital-Output – sets the digital output to either the default setting or value received from a controller.
Invert I/O <i>Default= False</i>	If selected: <ul style="list-style-type: none"> • If Mode is set to Digital-Input, the input status is inverted. • If Mode is set to Digital-Output, the output setting is inverted.
Default Digital Output <i>Default= Off</i>	If Mode is set to Digital Output , defines the default digital output setting: <ul style="list-style-type: none"> • At startup before a controller can set the digital output. • When communication to all controller(s) has been lost. Possible settings: <ul style="list-style-type: none"> • Off - low voltage • On – high voltage
Input Settling Time (0 - 10000) <i>Default= 0ms</i>	If non-zero and Mode is set to Digital-Input , the required time that the input status must remain constant before an input status change is reported.
Input Hold Time (0 - 10000ms) (Default: 0ms)	This is how long the IOLM keeps the input at its present value. For example, if the IOLM detects the input to go to high, and the hold time is X milliseconds, then the IOLM reports the input as high for X milliseconds, even though the input itself may have gone away already. If X is zero, then you get the behavior currently in the field.

Chapter 8. Loading and Managing IODD Files


There are several **Attached Devices** pages that support IO-Link Device Description (IODD) file management.

- [IO-Link Device Description Files Page](#) - load IODD files from the IO-Link device manufacturer onto the IOLM.
- [IO-Link Device Configuration Summary Page](#) on Page 72 - verify the correct files were loaded for each IO-Link device or use the page to .
- The **Port** pages are discussed in [Chapter 9. Configuring IO-Link Devices](#) on Page 73.

8.1. IO-Link Device Description Files Page

Use the **IO-Link Device Description Files** page to update (upload) and delete IO-Link Device Description (IODD) files associated with this IOLM. In addition, you can review the IODD xml file by clicking the **IODD FILENAME** in the table after loading the IODD file.

Note: You will need to download the appropriate IODD files from your IO-Link device manufacturer.-



The IOLM provides 15790K of space to store IODD files. The IOLM includes the following default IODD files, which cannot be deleted.

- **IODD-StandardDefinitions1.0.1.xml**
- **IODD-StandardUnitDefinitions1.0.1.xml**
- **IODD-StandardDefinitions1.1.xml**
- **IODD-StandardUnitDefinitions1.1.xml**

Note: You can use the **Configuration | Save/Load** feature to backup your IODD files. You can save the configuration file from an IOLM that has IODD files installed and then load that configuration file to another IOLM to quickly load the IODD files.

8.1.1. Preparing IODD Files to Upload

After downloading the IODD files for the IO-Link device from the IO-Link sensor or actuator manufacturer, you may need to unzip the file and locate the appropriate **xml** file for the device.

- Some IODD zip files contain the **xml** files and supporting image files for a single product. This type of zip file can be immediately loaded onto the IOLM.
- Some IODD zip files contain the files for multiple products. If you upload this type of IODD zip file, the IOLM loads the first **xml** file and the associated image files, which may or may not correspond to the IO-Link device connected to the port. If you need to zip the appropriate files, the following information may be useful:
 - Unzip the package and locate the **xml** file needed for your IO-Link device.
 - Open the **xml** file and search for the **productID**, which identifies the IO-Link device.
 - Zip the **xml** file along with the supporting images. There are several ways to locate the supporting images:
 - Locate the appropriate images using the **xml** file.
 - Load only the **xml** file and the IOLM notifies you what files are missing. Use the **UPDATE** feature to upload the missing images.
 - Zip the **xml** with all of the images and the IOLM ignores (and not upload) any unused files and notifies which files did not upload.

Note: Image files are not required for IO-Link device configuration.


Use the appropriate discussion for your IODD files.

- [Uploading IODD Zip Files](#)
- [Uploading xml Files or Supporting Files](#) on Page 68


8.1.2. Uploading IODD Zip Files

You can use the following procedure to upload IODD zip files.

1. Click **Attached Devices** and **IODD FILES**.
2. Click the **UPLOAD FILE** button.
3. Click the **CHOOSE FILE** button and browse to the file location.
4. Highlight the **zip** file, click **Open** and then the **UPLOAD** button.




5. If necessary, click **Ok**.



Note: Only images referenced in the xml file load to the IOLM and the remaining files are ignored.

6. If desired, you can view the xml file by clicking the IODD FILENAME in the table.



7. Click the hyperlink at the top of the page if you want to view the xml file in your browser.



8. Optionally, verify that the correct xml file was loaded using the Summary page ([Page 72](#)).


8.1.3. Uploading xml Files or Supporting Files

You can use the following procedure to upload xml, or supporting image files.


1. Click **Attached Devices** and **IODD FILES**.
2. Click the **UPLOAD FILE** button.
3. Click the **CHOOSE FILE** button and browse to the file location.
4. Highlight the **xml** or image file and click **Open**.

Note: The xml file must be loaded before the IOLM will load the associated image files.

5. Click the **UPLOAD** button.




Note: The IOLM notifies you what files are missing. The missing files do not affect the operation of the IODD Port page but the product image and logo for the IO-Link device company do not display.



6. Optionally, use the following steps to load image files:
 - a. Select the row in the table that contains the xml file by clicking the check box.
 - b. Click the **UPLOAD FILE** button.

- c. Click the **Choose File** button and browse to the file location.




- d. Highlight the file and click **Open**.
- e. Click the **UPLOAD** button.
- f. Optionally, verify that the correct **xml** file was loaded using the **Summary** page ([Page 72](#)).

8.1.4. Viewing and Saving IODD Files

Use the following procedure to view the contents of an IODD file.


1. If necessary, click **Attached Devices** and **IODD Files**.
2. Click the **IODD FILENAME** in the table that you want to review. A pop up window displays the contents of the IODD file.
3. Optionally, click the file name hyperlink at the top of the window to view the formatted file or if you want to save a copy of the file to another location.




8.1.5. Deleting IODD Files

Use the following procedure to delete an IODD file set from the IOLM.

1. If necessary, click **Attached Devices** and **IODD Files**.
2. Check the corresponding row of the IODD file that you want to delete.
3. Click the **DELETE SELECTED** button.



4. Click **CONTINUE** to the *Delete files?* message.



8.2. IO-Link Device Configuration Summary Page

The **IO-Link Device Configuration Summary** page provides basic device configuration (device profile) information for ports with valid IO-Link devices attached. The **Configuration Summary** page retrieves information that resides on the IO-Link device from the manufacturer.

A file name displayed in the **IODD Name** field for a port indicates that a valid IODD file is associated with that device. If the field is empty, that indicates that a valid IODD file has not been loaded.

You can review complete IODD file information on a port by port basis by clicking the **MORE** button next to the port in question or by clicking the **PORT** menu selection in the navigational bar.

Use the following steps to access the **IO-Link Device Configuration Summary** page.

1. Click **Attached Devices**.
2. Click **SUMMARY**.

***Note:** The Configuration Summary page takes several minutes to completely load as each device is queried.*

3. Click the **MORE** button or the corresponding **Port** (in the navigational bar) to configure the IO-Link device parameters for a specific device. See [Chapter 9. Configuring IO-Link Devices](#) on Page 73 for more information.

The screenshot shows the 'IO-Link Device Configuration Summary' page. At the top, there is a navigation bar with 'CONTROL' logo and tabs for 'Home', 'Diagnostics', 'Configuration', 'Advanced', 'Attached Devices', and 'Help'. Below the navigation bar, there are links for 'IODD FILES', 'SUMMARY', 'PORT 1', 'PORT 2', 'PORT 3', and 'PORT 4'. The main content area is titled 'IO-Link Device Configuration Summary' and contains a table with the following data:

DEVICE SETTINGS	PORT1	MORE	PORT2	MORE	PORT3	MORE	PORT4	MORE
Vendor Name	wenglor sensoric GmbH		Leuze electronic GmbH + Co. KG		SICK AG		ifm electronic GmbH	
VENDOR	87		338		26		310	
DEVICE	1247490		2096		8388739		87	
Description					Photoelectric proximity sensor		Temperature sensor, -40°C to 150°C	
IO-Link Version	1.1		1.1		1.0		1.0	
Hardware Version	Version V01.00.00		B000		1.00		AC	
Firmware Version	Version V01.02.00		1.1		1.07		124	
Baud Rate	38400		38400		38400		38400	
SIO Mode	Yes		Yes		Yes		Yes	
Min Cycle Time	2.3 ms		2.3 ms		2.3 ms		2.3 ms	
IODD Name	wenglor-OV1P303P0102-201408-20-IODD1.1.xml		Leuze_electronic-HT10_2096-20150929-IODD1.1.xml		SICK-WTB12C-3_V1_2-20140513-IODD1.0.1.xml		ifm-000057-20121210-IODD1.0.1.xml	

At the bottom of the page, there is a footer that says 'Welcome Admin' on the left and '© Copyright Control Corp.' on the right.

Chapter 9. Configuring IO-Link Devices

This chapter discusses using the **Attached Devices | Port** pages to change IO-Link device parameters.

Note: *Optionally, you can use traditional methods such as: PLC interfaces or HMI/SCADAs, depending on your protocol to configure the IO-Link devices.*

9.1. Port Pages Overview

You can use the **Attached Devices | Port** page for a port to review and easily edit the IO-Link device configuration or view Process Data.

Parameter Name	Index	Subindex	Value	Description	R/W	Unit	Min	Max	Comments	Gradient
+ Identification										
- Parameter										
Switching Output Property	82		1	0:Switching Off 1:Switching On 2:Unchanged	RW		0	2	value range:0:1:2	
Q1 Light/Dark	85		1	0:Light Switching 1:Dark Switching	RW		0	1	value range:0:1	
Q1 Evaluation Depth	89		4		RW					
Q1 Hysteresis Class	90		1	0:Raw 1:Medium 2:Fine	RW		0	2	value range:0:1:2	
Q1 Reserve Class	91		1	Same as previous description	RW		0	2	value range:0:1:2	
Q2 Light/Dark	94		1	0:Light Switching 1:Dark Switching	RW		0	1	value range:0:1	
Q2 Evaluation Depth	98		4		RW					
Q2 Hysteresis Class	99		1	0:Raw 1:Medium 2:Fine	RW		0	2	value range:0:1:2	
Q2 Reserve Class	100		2	Same as previous description	RW		0	2	value range:0:1:2	

Observation
Diagnosis

Expand or collapse parameter groups to customize your view

IO-Link Device ISDU Interface - Port 4

Port Status: Operational, PDI Valid

Port is displaying valid PDI operation

The **Port** page provides two IO-Link device configuration methods:

- **IO-Link Device Port** table (GUI), which depends on the appropriate IODD file loaded from the IO-Link device manufacturer onto the IOLM. To use the **IO-Link Device Port** table for configuring IO-Link devices, refer to the following subsections:
 - [Editing Parameters - IO-Link Device - Port Table](#) on Page 76
 - [Resetting IO-Link Device Parameters to Factory Defaults](#) on Page 77
- **IO-Link Device ISDU Interface - Port**, which can be used with or without IODD files loaded. Refer to the following information to use the **IO-Link Device ISDU Interface - Port** method:
 - The *IO-Link Device Operator Manual* from the device manufacturer is needed to use the **IO-Link Device ISDU Interface** since ISDU block index and ISDU sub-index numbers are required.
 - [Editing Parameters - IO-Link Device ISDU Interface - Port](#) on Page 79

The IO-Link Device Port table provides detailed information about the indexes and sub-indexes. Not all indexes have sub-indexes. In the following image, Index 114 has two sub-indexes, Sub-index 1, which is one bit and Sub-index 2 has 15 bits. Note that the sub-indexes have an asterisk, which indicates that if using the IO-Link ISDU Interface that you must enter a value

Parameter Name	Index	Subindex	Value	Description	R/W	Unit	Min	Max	Comments	Gradient	Offset	Data Type	SimpleDataType	BitLength	FixedLength	DisplayFormat
- Setting of the sensor display																
Unit	107		0	0:cm 1:inch	RW		0	1	value range:0;1			UIntegerT		8		
Display On / OFF	114	1*	0	0:On 1:OFF	RW		0	1	value range:0;1			RecordT	BooleanT	1		
Displayed measurement	114	2*	1	0:cm 1:in	RW		1	2	value range:1;2			RecordT	UIntegerT	15		
Lac	124		1	0:Lac 1:NoLac	RW		0	1	value range:0;1			UIntegerT		8		
S-Lac	125		1	0:S-Lac 1:NoS-Lac	RW		0	1	value range:0;1			UIntegerT		8		
- Setup																
OPS	87		0.0	0.0-100.0	RW	cm	0.0	100.0	value range:0.0-100.0	0.1	0	IntegerT		16		Dec.1
LEN	113		45.0	10.0-160.0	RW	mm	10.0	160.0	value range:10.0-160.0	0.1	0	IntegerT		16		Dec.1
MBst	119		0	0:HIGH 1:LOW	RW		0	1	value range:0;1			UIntegerT		8		
Prsh	117		1	0:CDAX 1:rd	RW		0	1	value range:0;1			UIntegerT		8		

Access the Process Data page by selecting Process Data from the drop box next to the port number.

Parameter Name	Index	Subindex	Value	Description	R/W	Unit	Min	Max	Comments	Gradient
+ Identification										
- Parameter										
Switching Output Property	82		1	0:Switching Off 1:Switching On 2:Unchanged	RW		0	2	value range:0;1;2	
Q1 Light/Dark	85		1	0:Light Switching 1:Dark Switching	RW		0	1	value range:0;1	
Q1 Evaluation Depth	89		4		RW					
Q1 Hysteresis Class	90		1	0:Raw 1:Medium 2:Fine	RW		0	2	value range:0;1;2	
Q1 Reserve Class	91		1	Same as previous description	RW		0	2	value range:0;1;2	
Q2 Light/Dark	94		1	0:Light Switching 1:Dark Switching	RW		0	1	value range:0;1	
Q2 Evaluation Depth	98		4		RW					
Q2 Hysteresis Class	99		1	0:Raw 1:Medium 2:Fine	RW		0	2	value range:0;1;2	
Q2 Reserve Class	100		2	Same as previous description	RW		0	2	value range:0;1;2	
+ Observation										
+ Diagnosis										

This shows a typical **Process Data** page.

IO-Link Device - Port 4 [Process Data] [REFRESH]

Parameter Name	Value	Description	DataType	SimpleDatatype	BitLength	BitOffset
- Process Data						
- Status Information						
Q1 Output State	0	0:Q1 Off 1:Q1 On	RecordT	BooleanT	1	0
Q2 Output State	0	0:Q2 Off 1:Q2 On	RecordT	BooleanT	1	1
Q3 Output State	0	0:Q3 Off 1:Q3 On	RecordT	BooleanT	1	2
Measure State	1	0:No Measure (Startup, Teach or Deactivated) 1:Measure is Running	RecordT	BooleanT	1	3
Received Signal	1	0:No Signal; no measurement value available 1:Signal and measurement value available	RecordT	BooleanT	1	4
Warning: reduced accuracy	0	0:No Warning 1:Warning	RecordT	BooleanT	1	5

IO-Link Device ISDU Interface - Port 4 Port Status: Operational, PDI Valid

Welcome Admin © Copyright Control Corp.

If the correct IODD file has not been loaded or the IO-Link device does not support PDO, then you will receive this message.

IO-Link Device - Port 3 [Process Data]

Parameter Name	Value	Description	DataType	SimpleDatatype	BitLength	BitOffset
- Process Data						
- Process data in						

No Process Data

Unable to load the Process Data! Make sure the attached IO-Link device is supported and the corresponding IODD file is loaded.

OK

IO-Link Device ISDU Interface - Port 3 Port Status: Operational, PDI Valid

Welcome Admin © Copyright Control Corp.

9.2. Editing Parameters - IO-Link Device - Port Table

Use the following procedure to edit IO-Link device parameters using the **IO-Link Device Port** table.

Note: You may want to verify that the **Automatic Download Enable for Data Storage** option on the **Configuration | IO-Link Settings** page is **NOT** set to **On** as this can cause unreliable results on the corresponding port.

1. If you have not done so, load the IODD file from the IO-Link device manufacturer ([Chapter 8. Loading and Managing IODD Files](#) on Page 65).
2. Access the appropriate **Port** page by clicking **Attached Devices** and then the **Port** number that you want to configure.
3. Click the **EDIT** button after all of the device information is populated in the table.
4. Scroll down the table and make appropriate parameter changes for your environment.

Note: An IODD file may not contain all IO-Link device settings depending on the IO-Link device manufacturer. If you need to change a parameter that is not displayed in the **IO-Link Device - Port** table, you can refer to the **IO-Link Device Operators Manual** and use the **IO-Link Device ISDU Interface** to change the settings.

You may need to scroll to the right in the table to view applicable parameter values if the parameter is not selectable in a drop list.

The screenshot shows the 'IO-Link Device - Port 4' configuration page. The top navigation bar includes 'CONTROL', 'Home', 'Diagnostics', 'Configuration', 'Advanced', 'Attached Devices', and 'Help'. Below the navigation, there are tabs for 'IODD FILES', 'SUMMARY', 'PORT 1', 'PORT 2', 'PORT 3', and 'PORT 4'. The main content area displays a table of device parameters:

Parameter	ID	Value	Description	Access	Min	Max	Value Range
Vendor Text	17	Leuze electronic - the sensor p eople		RO			
Product Name	18	HT10L1-25M.3/L69-M12		RO			
Product ID	19	90129541		RO			
Product Text	20	scanner with background supp ression		RO			
Serial Number	21	01540018205		RO			
Hardware Version	22	B000		RO			
Firmware Version	23	1.1		RO			
Application Specific Tag	24	Loaner#1		RW			
Parameter							
Switching Output Property	82	1	0:Switching Off 1:Switching On 2:Unchanged	RW	0	2	value range:0;1;2
Q1 Light/Dark	85	0	0:Light Switching 1:Dark Switching	RW	0	1	value range:0;1
Q1 Evaluation Depth	89	4		RW			
Q1 Hysteresis Class	90	2	0:Raw 1:Medium 2:Fine	RW	0	2	value range:0;1;2
Q1 Reserve Class	91	2	Same as previous description	RW	0	2	value range:0;1;2
Q2 Light/Dark	94	1	0:Light Switching 1:Dark Switching	RW	0	1	value range:0;1
Q2 Evaluation Depth	98	4		RW			
Q2 Hysteresis Class	99	1	0:Raw 1:Medium 2:Fine	RW	0	2	value range:0;1;2
Q2 Reserve Class	100	2	Same as previous description	RW	0	2	value range:0;1;2
Observation							

At the bottom of the page, there is a status bar that reads 'IO-Link Device ISDU Interface - Port 4' and 'Port Status: Operational, PDI Valid'. The footer includes 'Welcome Admin' and '© Copyright Control Corp.'.

5. Click the **SAVE** button after editing the parameters.

9.3. Resetting IO-Link Device Parameters to Factory Defaults

In the event you want to reset the IO-Link device to factory default, typically the IODD file provides the ability from the IO-Link device manufacturer. Use the following example to reset an IO-Link device.

1. Click the **COMMAND** button and locate the **Restore Factory** button.
2. Click the **Restore Factory** or **Load Factory Settings** button.


Note: The name of the button is determined by the IO-Link device manufacturer.

The screenshot shows the 'IO-Link Device - Port 2' configuration page. A table lists various parameters with their current values and ranges. The 'Standard Command' row for parameter 130 has a 'Restore Factory' button highlighted with a red box. Other buttons in the same row include 'IO-Link 1.1 sy...', 'IO-Link 1.1 sy...', 'IO-Link 1.1 sy...', and 'IO-Link 1.1 sy...'. The 'Commands' row for parameter 253 has a '[ES] Reset to...' button.

OF5	87		0.0	0.0-100.0	RW	cm	0.0	100.0	value range:0.0-100.0	0.1
LEnG	115		45.0	10.0-160.0	RW	cm	10.0	160.0	value range:10.0-160.0	0.1
MEdt	119		0	0:HIGH 1:LOW	RW		0	1	value range:0:1	
Prob	117		1	0:COAX 1:rod	RW		0	1	value range:0:1	
Standard Command	2			130:Restore Factory Settings	WO		130	130	value range:130	
Standard Command	2			240:IO-Link 1.1 system test c ommand 240, Event SDFE app ears	WO		240	240	value range:240	
Standard Command	2			241:IO-Link 1.1 system test c ommand 241, Event SDFE dis appears	WO		241	241	value range:241	
Standard Command	2			242:IO-Link 1.1 system test c ommand 242, Event SDFE app ears	WO		242	242	value range:242	
Standard Command	2			243:IO-Link 1.1 system test c ommand 243, Event SDFE disa ppears	WO		243	243	value range:243	
Commands	241			253:[ES] Reset to...	WO		253	253	value range:253	
Data Storage Lock	12	2*	0	0 1	RW		0	1	value range:0:1	
Local User Interface Lock	12	4*	0	Same as previous description	RW		0	1	value range:0:1	

Port Status: Operational,POI Invalid

3. Click OK when the *Refresh* message appears.



9.4. Editing Parameters - IO-Link Device ISDU Interface - Port

The **IO-Link Device ISDU Interface** follows these guidelines:

- If necessary, convert hexadecimal ISDU index numbers to decimal, you must enter the decimal value for the ISDU Block Index and ISDU Sub-index numbers.
- You must enter the hexadecimal value for the IO-Link device parameters.


If the appropriate IODD file has been loaded, you can use the **IO-Link Device - Port** table to determine the index numbers and acceptable values for each parameter.

Note: An IODD file may not contain every IO-Link device setting depending on the IO-Link device manufacturer. If you need to change a parameter that is not displayed in the **IO-Link Device - Port** table, you can refer to the *IO-Link Device Operators Manual*.


If an IODD file has not been loaded for an IO-Link device, you can use the *IO-Link Device Operator's Manual* to determine the ISDU indexes.

Please note:


- You must enter the decimal value for the ISDU Block Index and ISDU Sub-index.
- The **GET** button retrieves the parameter value in hex from the IO-Link device. You may want to retrieve values to determine the data length.




- The **SET** button sends the value to the IO-Link device.




- After successfully changing a parameter, the IO-Link Master responds with a command executed notification.



- This message means that the IO-Link device defines the entry as an invalid setting.




- This message indicates that the IO-Link device cannot read the specified ISDU Block Index and Sub-index.



Use the following procedure to edit parameters using the IO-Link Device ISDU Interface - Port.

Note: You may want to verify that the *Automatic Download Enable for Data Storage* option on the *Configuration | IO-Link Settings* page is *NOT* set to *On* as this can cause unreliable results on the corresponding port.

1. Click the + next to the IO-Link Device ISDU Interface to open the interface.



2. Enter the ISDU Block Index number (decimal) that you want to edit.
3. If applicable, enter the ISDU Sub-index (decimal).
4. Edit the parameter (hex) and click the SET button.



5. Verify that a *command executed* message returns.

6. If the IODD file is loaded, optionally click **REFRESH** to verify your changes.

The screenshot displays the 'IO-Link Device - Port 1' configuration interface. At the top, there is a navigation bar with 'CONTROL' logo and tabs for 'Home', 'Diagnostics', 'Configuration', 'Advanced', 'Attached Devices', and 'Help'. The user is logged in as 'IO-Link Master DR-8-EIP'. Below the navigation bar, there are tabs for 'IODD FILES', 'SUMMARY', and 'PORT 1' through 'PORT 8'. The main content area is titled 'IO-Link Device - Port 1' and includes a 'REFRESH' and 'EDIT' button. A table lists device parameters:

Parameter Name	AV		min. measuring grain	RO				
Product Name	18		LMT121	RO				
Product Text	20		Electronic level sens or	RO				
Serial Number	21		u0062130814	RO				
Hardware Version	22		AF	RO				
Firmware Version	23		102	RO				
Application Specific Tag	24			RW				

Below the table, there are sections for '+ Parameter', '+ Output Configuration', and '- Digital Output 1'. The Digital Output 1 section contains a table:

SP1	67		40	RW	%	4	98	value range:4-98
rP1	68		29	RW	%	2	96	value range:2-96
dr1	79		0	RW	S	0	100	value range:0-100

At the bottom, there is a section for 'IO-Link Device ISDU Interface - Port 1' with an 'ISDU Block Index' field set to 87, an 'ISDU Sub-index' field, and 'GET' and 'SET' buttons. A command execution log shows 'command executed'.

Chapter 10. Utilizing IOLM Features

This chapter discusses using the following features:

- *Setting User Accounts and Passwords*
- [10.2. Data Storage](#) on Page 86, which provides automatic and manual data storage to upload or download IO-Link v1.1 device parameters
- [10.3. Device Validation](#) on Page 90, which supports identical or compatible device validation to dedicate a port or ports to specific IO-Link devices
- [10.4. Data Validation](#) on Page 92, which supports strict or loose data validation to verify data integrity
- [10.5. IOLM Configuration Files](#) on Page 93 that supports a method to back up configuration files or load the same configuration to multiple IOLM units
- [10.6. Configuring Miscellaneous Settings](#) on Page 97, which provides the following options:
 - [10.6.1. Using the Menu Bar Hover Shows Submenu Option](#) on Page 97
 - [10.6.2. Enable PDO Write From Attached Devices Port Page](#) on Page 98
 - [10.6.3. IO-Link Test Event Generator](#) on Page 99
- [10.7. Clearing Settings](#) on Page 103, which allows you to reset the IOLM to factory default values

10.1. Setting User Accounts and Passwords

The IOLM is shipped from the factory without passwords. See the following table if you want to see how permissions are granted.

Page	Admin	Operator	User
Log-in	Yes	Yes	Yes
Home	Yes	Yes	Yes
Diagnostics - All	Yes	Yes	Yes
Configuration - IO-Link Settings	Yes	Yes	View-only
Configuration - Digital I/O Settings (Applicable models)	Yes	Yes	View-only
Configuration - EtherNet/IP Settings	Yes	Yes	View-only
Configuration - Modbus/TCP	Yes	Yes	View-only
Configuration - OPC UA	Yes	Yes	View-only
Configuration - Network	Yes	View-only	No
Configuration - Misc	Yes	Yes	Yes
Configuration - Load/Save	Yes	Yes	View-only
Configuration - Clear Settings	Yes	No	No
Advanced - Software	Yes	No	No
Advanced - Accounts	Yes	No	No
Advanced - Log Files	Yes	Yes	Yes
Advanced - Licenses	Yes	Yes	Yes
Attached Devices - IO-Link Device Description Files	Yes	Yes	View-only

Page	Admin	Operator	User
Attached Devices - IO-Link Device Configuration Summary	Yes	Yes	View-only
Attached Devices - IO-Link Device - Port	Yes	Yes	View-only


You can use this procedure to set up passwords for the IOLM.

1. Open your browser and enter the IOLM IP address.
2. Click **Advanced** | **ACCOUNTS**.


The screenshot shows the 'Accounts' configuration page in a web browser. The navigation bar at the top includes 'CONTROL', 'Home', 'Diagnostics', 'Configuration', 'Advanced', 'Attached Devices', and 'Help'. Below the navigation bar, there are tabs for 'SOFTWARE', 'ACCOUNTS', 'LOG FILES', and 'LICENSES'. The main content area is titled 'Accounts' and contains three sections, one for each user type: ADMIN, OPERATOR, and USER. Each section has a header with the user name and '(NO PASSWORD)', followed by a checkbox. Below each checkbox are three text input fields: 'Old Password', 'New Password', and 'Confirm Password'. The ADMIN section's checkbox is checked. At the bottom right of the form, there is an 'Apply' button.

3. Click the **ADMIN** check box.
4. If applicable, enter the old password in the **Old Password** text box.
5. Enter the new password in the **New Password** text box.
6. Re-enter the password in the **Confirm Password** text box.
7. Optionally, click the **Operator** check box, enter a new password, and re-enter the password in the **Confirm Password** text box.
8. Optionally, click the **User** check box, enter the new password, and re-enter the password in the **Confirm Password** text box.
9. Click **Apply**.

10. Close the new window that displays a *Password saved* banner.



- 11. Click the **Log out** button on the top navigation bar.
- 12. Re-open the web interface by selecting the appropriate user type in the drop list and entering the password.



10.2. Data Storage

Data storage is typically supported by IO-Link v1.1 devices. *Data storage* means that you can upload parameters from an IO-Link device to the IOLM and/or download parameters from the IOLM to the IO-Link device. This feature can be used to:

- Quickly and easily replace a defective IO-Link device
- Configure multiple IO-Link devices with the same parameters as fast as it takes to connect and disconnect the IO-Link device

To determine whether an IO-Link (v1.1) device supports data storage, you can check one of the following:

- **IO-Link Diagnostics** page - check the **Data Storage Capable** field to see if it displays **Yes**.
- **IO-Link Configuration** page - check to see if **UPLOAD** and **DOWNLOAD** buttons display under the **Data Storage Manual Ops** group. If only a **Clear** button displays, the device on the port does not support data storage.

10.2.1. Uploading Data Storage to the IOLM

The IO-Link device manufacturer determines which parameters are saved for data storage. Remember, the IO-Link device should be configured before enabling data storage unless you are using data storage to back up the default device configuration.

There are two methods to upload Data Storage using the **Configuration | IO-Link** page:

- **Automatic Enable Upload** - If a port is set to **On** for this option, the IOLM saves the data storage parameters (if the data storage is empty) from the IO-Link device to the IOLM.

When this option is enabled and another IO-Link device (different Vendor ID and Device ID), the **IO-Link Diagnostics** page displays a *DS: Wrong Sensor* in the **IOLink State** field and the IO-Link port LED flashes red, indicating a hardware fault.

Automatic upload occurs when the **Automatic Upload Enable** option is set to **On** and one of these conditions exists:

- There is no upload data stored on the gateway and the IO-Link device is connected to the port.
- The IO-Link device has the **DS upload** bit on; generally because you have changed the configuration through Teach buttons or the web interface.

Note: *Not all device parameters are sent to data storage. The IO-Link device manufacturer determines what parameters are sent to data storage.*

- **Data Storage Manual Ops: UPLOAD** - Selecting the **UPLOAD** button saves the data storage from the IO-Link device to the IOLM. The contents of the data storage does not change unless it is uploaded again or cleared. Another IO-Link device with a different Vendor ID and Device ID can be attached to the port without causing a hardware fault.

10.2.2. Downloading Data Storage to the IO-Link Device

There are two methods to download Data Storage using the **Configuration | IO-Link Device** page:

- **Automatic Download Enable** - An automatic download occurs when the **Automatic Download Enable** option is set to **On** and one of these conditions exists:

- The original IO-Link device is disconnected and an IO-Link device whose configuration data differs from the stored configuration data.
- The IO-Link device requests an upload and the **Automatic Upload Enable** option is set to **Off**.

Note: *Do not enable both Automatic Upload and Download at the same time, the results are not reliable among IO-Link device manufacturers.*

- **Data Storage Manual Ops: DOWNLOAD** - Selecting the **DOWNLOAD** button downloads the data storage from the that port to the IO-Link device.

If an IO-Link device with a different Vendor ID and Device ID is attached to the port and a manual download is attempted, the IOLM issues a hardware fault.

10.2.3. Automatic Device Configuration


Use the following steps to use an IOLM port to configure multiple IO-Link devices with the same configuration parameters.

1. If necessary, configure the IO-Link device as required for the environment.
2. Click **Configuration** | **IO-Link**.
3. Click the **EDIT** button for the port for which you want to store the data on the IOLM.
4. Click the **UPLOAD** button.
5. Click the **CONTINUE** button to the *Continue to upload the data storage on IO-Link Master port [number]* message.

The screenshot shows the 'IO-Link Settings' web interface. At the top, there is a navigation bar with 'CONTROL' logo and tabs for 'Home', 'Diagnostics', 'Configuration', 'Advanced', 'Attached Devices', and 'Help'. Below this is a secondary navigation bar with 'IO-LINK', 'ETHERNET/IP', 'MODBUS/TCP', 'OPC UA', 'NETWORK', 'MISC', 'LOAD/SAVE', and 'CLEAR SETTINGS'. The main content area is titled 'IO-Link Settings' and contains a table for 'IO-LINK PORT CONFIG' with columns for PORT 1, PORT 2, PORT 3, and PORT 4. Each port has an 'EDIT' button. The table includes fields for Port Name, Port Mode, Invert SIO, Invert Auxiliary Input, Default Digital Output, Minimum Cycle Time, Auxiliary Input Setting Time, Auxiliary Input Hold Time, SIO Input Setting Time, SIO Input Hold Time, Data Storage Config (Storage Contents, Automatic Upload/Download Enable), Data Storage Manual Ops (CLEAR, UPLOAD, DOWNLOAD), and Validation Config (Device Validation Mode, Vendor Id, Device Id). A dialog box titled 'Continue?' is overlaid on the table, asking 'Continue to upload the data storage on IO-Link Master port 3?'. The dialog has 'CONTINUE' and 'CANCEL' buttons. A red box highlights the 'CONTINUE' button with the number '2.' next to it. Another red box highlights the 'UPLOAD' button in the table with the number '1.' next to it.

6. Click the **Ok** button to the *Data storage upload successful on Port [number]* message.

7. Set the **Automatic Download Enable** option to **On**.



8. Click **SAVE**.

9. Click **Diagnostics | IO-Link**.

10. Replace the IO-Link device on that port with the IO-Link device for which you want configured automatically.

11. Verify that the IO-Link device displays operational **Port Status** and the appropriate IO-Link State.

12. Repeat Steps [10](#) and [11](#) for as many device as you want to configure.

10.2.4. Automatic Device Configuration Backup

The following procedure shows how to utilize data storage to automatically backup an IO-Link device configuration.

Remember, if you adjust parameters using **Teach** buttons those values may or not may be updated in the data storage, which depends on the IO-Link device manufacturer. If you are unsure, you can always use the manual **UPLOAD** feature to capture the latest settings.

1. Click **Configuration | IO-Link**.
2. Click the **EDIT** button for the port for which you want to store the data on the IOLM.
3. Select **On** in the drop list for **Automatic Data Storage Upload Enable**.

The screenshot shows the 'IO-Link Settings' page with a table for 'IO-LINK PORT CONFIG'. The table has columns for PORT 1, PORT 2, PORT 3, and PORT 4. The 'Automatic Upload Enable' row shows 'On' selected for PORT 2. The 'Data Storage Config' section shows 'Storage Contents' as 'empty' for PORT 2. The 'SAVE' button for PORT 2 is highlighted with a red box and a red '3.'. The 'On' dropdown for PORT 2 is highlighted with a red box and a red '2.'. The 'empty' storage content for PORT 2 is highlighted with a red box and a red '1.'.

IO-LINK PORT CONFIG	PORT 1	PORT 2	PORT 3	PORT 4
Port Name	IOLink Port 1	IOLink Port 2	IOLink Port 3	IOLink Port 4
Port Mode	IOLink	IOLink	IOLink	IOLink
Invert SIO	false	false	false	false
Invert Auxiliary Input	false	false	false	false
Default Digital Output	Off	Off	Off	Off
Minimum Cycle Time (4 - 538)	4 ms	4 ms	4 ms	4 ms
Auxiliary Input Settling Time (0 - 10000)	0 ms	0 ms	0 ms	0 ms
Auxiliary Input Hold Time (0 - 10000)	0 ms	0 ms	0 ms	0 ms
SIO Input Settling Time (0 - 10000)	0 ms	0 ms	0 ms	0 ms
SIO Input Hold Time (0 - 10000)	0 ms	0 ms	0 ms	0 ms
Data Storage Config				
Storage Contents	empty	empty	empty	empty
Automatic Upload Enable	Off	On	Off	Off
Automatic Download Enable	Off	Off	Off	Off
Data Storage Manual Ops				
	CLEAR	CLEAR	CLEAR	CLEAR
	UPLOAD	UPLOAD		
	DOWNLOAD	DOWNLOAD		
Validation Config				
Device Validation Mode	None	None	None	None
Vendor Id (0 - 65535)	0	0	0	0

4. Click **SAVE**.

When the **Configuration | IO-Link** page is refreshed, the **Storage Contents** field displays the **Vendor ID** and **Device ID**. In addition, the **IO-Link Diagnostics** page displays **Upload-Only** in the **Automatic Data Storage Configuration** field.

10.3. Device Validation

Device validation is supported by many IO-Link devices. **Device Validation Mode** provides these options:

- **None** - this disables **Device Validation Mode**.
- **Compatible** - permits a compatible IO-Link device (same Vendor ID and Device ID) to function on the corresponding port.
- **Identical** - only permits an IO-Link device (same Vendor ID, Device ID, and serial number) to function on the corresponding port.

Use this procedure to configure device validation.

1. Click **Configuration | IO-Link Settings**.
2. Click the **EDIT** button.
3. Select **Compatible** or **Identical** for the **Device Validation** mode.


Note: *Identical Device Validation requires a device serial number to operate.*

4. Click the **GET ATTACHED** button or manually complete the Vendor ID, Device, ID, and serial number.
If the device does not have a serial number, you should not select **Identical** because the IOLM requires a serial number to identify a specific device.

The screenshot shows the 'IO-Link Settings' page with a table for 'IO-LINK PORT CONFIG'. The table has columns for PORT 1, PORT 2, PORT 3, and PORT 4. The 'Validation Config' section is expanded for PORT 1, showing 'Device Validation Mode' set to 'Compatible' (highlighted with a red box and '1.'). Below it, 'Vendor Id' is '310', 'Device Id' is '10', and 'Serial Num' is 'd0033151013'. At the bottom of the PORT 1 column, the 'GET ATTACHED' button is highlighted with a red box and '2.'. Above the table, the 'EDIT' button for PORT 1 is highlighted with a red box and '3.'. The interface also shows 'Data Storage Config' and 'Data Storage Manual Ops' sections.

5. Click the SAVE button. If the wrong or incompatible device is connected to the port, the IO-Link port LED flashes red and no IO-Link activity occurs on the port until the issue is resolved.

In addition, the **IO-Link Diagnostics** page displays the following information.



10.4. Data Validation

You can use this procedure to configure data validation.

1. Click **Configuration | IO-Link Settings**.
2. Click the **EDIT** button on the port you want to configure for data validation.
3. Select **Loose** or **Strict** to enable data validation.
 - **Loose** - the slave device's PDI/PDO lengths must be less than or equal to the user-configured values.
 - **Strict** - the slave device's PDI/PDO lengths must be the same as the user-configured values.
4. Click the **GET ATTACHED** button or manually enter the PDI and PDO length.

The screenshot shows the 'IO-Link Settings' page for a device. The interface is divided into several sections: 'IO-LINK PORT CONFIG', 'Data Storage Config', 'Data Storage Manual Ops', and 'Validation Config'. The 'Validation Config' section is the focus, showing settings for Port 3. The 'Data Validation Mode' is set to 'Strict' (indicated by a red box and '1.'). The 'GET ATTACHED' button for Port 3 is highlighted with a red box and a mouse cursor (indicated by '2.'). The 'SAVE' button for Port 3 is also highlighted with a red box (indicated by '3.').

IO-LINK PORT CONFIG	PORT 1	PORT 2	PORT 3	PORT 4	PORT 5	PORT 6	PORT 7	PORT 8
Port Name	Pressure#55	Flow Meter#50	Flow Meter#50	Proximity#76	Proximity#80	DI Proximity#28	Proximity#5	IOLink Port 8
Port Mode	IOLink	IOLink	IOLink	IOLink	IOLink	DigitalIn	IOLink	IOLink
Invert IO	false	false	<input type="checkbox"/>	false	false	false	false	false
Default Digital Output	Off	Off	Off	Off	Off	Off	Off	Off
Minimum Cycle Time (4 - 538)	4 ms	4 ms	4 ms	4 ms	4 ms	4 ms	4 ms	4 ms
Data Storage Config								
Storage Contents	empty	empty	empty	empty	empty	empty	empty	empty
Automatic Upload Enable	Off	Off	Off	Off	Off	Off	Off	Off
Automatic Download Enable	Off	Off	Off	Off	Off	Off	Off	Off
Data Storage Manual Ops								
	<input type="button" value="CLEAR"/>	<input type="button" value="CLEAR"/>	<input type="button" value="CLEAR"/>	<input type="button" value="CLEAR"/>	<input type="button" value="CLEAR"/>	<input type="button" value="CLEAR"/>	<input type="button" value="CLEAR"/>	<input type="button" value="CLEAR"/>
		<input type="button" value="UPLOAD"/>	<input type="button" value="UPLOAD"/>		<input type="button" value="UPLOAD"/>			
		<input type="button" value="DOWNLOAD"/>	<input type="button" value="DOWNLOAD"/>		<input type="button" value="DOWNLOAD"/>			
Validation Config								
Device Validation Mode	None	Identical	None	None	None	None	None	None
Vendor Id (0 - 65535)	0	310	310	0	0	0	0	0
Device Id (0 - 16777215)	0	392	392	0	0	0	0	0
Serial Num		e0051171013	e0048171013					
Data Validation Mode	None	None	Strict	None	None	None	None	None
PDI Length (0 - 32)	0 byte	8 byte	8 byte	0 byte	0 byte	0 byte	0 byte	0 byte
PDO Length (0 - 32)	0 byte	0 byte	0 byte	0 byte	0 byte	0 byte	0 byte	0 byte
	<input type="button" value="GET ATTACHED"/>	<input type="button" value="GET ATTACHED"/>	<input type="button" value="GET ATTACHED"/>	<input type="button" value="GET ATTACHED"/>	<input type="button" value="GET ATTACHED"/>	<input type="button" value="GET ATTACHED"/>	<input type="button" value="GET ATTACHED"/>	<input type="button" value="GET ATTACHED"/>

5. Click the **SAVE** button.

If data validation fails, the IO-Link port LED flashes red and the **IO-Link Diagnostics** page displays an error.

10.5. IOLM Configuration Files

You can use the web interface or PortVision DX to save or load IOLM configuration files.

Note: You can optionally install and use [PortVision DX](#) to save or load IOLM configuration files.


Use one of the following procedures to save or load configuration files.

- [Saving Configuration Files \(Web Interface\)](#) on Page 93
- [Saving Configuration Files \(PortVision DX\)](#) on Page 95
- [Loading Configuration Files \(Web Interface\)](#) on Page 94
- [Loading Configuration Files \(PortVision DX\)](#) on Page 95

10.5.1. Saving Configuration Files (Web Interface)

Use this procedure to save configuration files for the IOLM. The configuration files includes all port settings, network settings, and encrypted passwords.

1. Click **Configuration | Load/Save**.
2. Click the **SAVE** button.




3. Click the **Save as** option and browse to the location that you want to store the configuration file.

10.5.2. Loading Configuration Files (Web Interface)

Use this procedure to load a configuration file onto the IOLM.

1. Click **Configuration | Load/Save**.
2. Click the **Browse** button and locate the configuration file (.dcz extension).
3. Click the **LOAD** button.




4. Click the **OK** button to close the *Configuration Uploaded* message that notifies you of what configuration parameters loaded.

10.5.3. Saving Configuration Files (PortVision DX)

Use this procedure to save configuration files for the IOLM. The configuration files includes all port settings, network settings, and encrypted passwords.

1. If necessary, open PortVision DX and click the **Scan** button to locate the IO-Link Master units on your network.
2. Right-click the IOLM in the *Device List* pane (lower pane).
3. Click **Configuration** and **Save**.
4. Browse to a suitable location, enter a file name, and click **Save**.
5. If necessary, enter **Admin** as the *User name* and the administrator password.




6. Click **Ok** to the *A Device Configuration file was created for the selected device* message.

10.5.4. Loading Configuration Files (PortVision DX)

Use this procedure to load configuration files for the IOLM.

1. If necessary, open PortVision DX and click the **Scan** button to locate the IO-Link Master units on your network.
2. Right-click the IOLM in the *Device List* pane (lower pane).
3. Click **Configuration** and **Load**.
4. Click **Yes** to the *This process may take up to 25 seconds per device* message.
5. Browse to the configuration file location, select the file, and click **Open**.

6. If necessary, enter **Admin** as the *User name* and the administrator password.



7. Click **Ok** to the *Load Configuration* message.


10.6. Configuring Miscellaneous Settings

The **Miscellaneous Settings** page includes the following options:

- **Menu Bar Hover Shows Submenu**

This option displays sub-menus for a category when you hover over the category name.

For example, if you hover over **Advanced**, the **SOFTWARE**, **ACCOUNTS**, **LOG FILES**, and **LICENSES** sub-menus display. You can click any submenu and avoid opening the default menu for a category.



- **Enable PDO Write From Attached Devices Port Page**

When enabled, it allows you to write PDO data to IO-Link slaves from the **Attached Devices | Port** page in the web user interface. See [10.6.2. Enable PDO Write From Attached Devices Port Page](#) on Page 98 for more information.

Note: *The PDO write will not allow writes if the IOLM has a PLC connection. **This should never be enabled in a production environment.***

- **LED Flash**

You can force the IO-Link port LEDs on the IOLM into a flashing tracker pattern that allows you to easily identify a particular unit.

- Click the **ON** button to enable the LED tracker feature on the IOLM. The LEDs remain flashing until you disable the LED tracker feature
- Click the **OFF** button to disable the LED tracker.


10.6.1. Using the Menu Bar Hover Shows Submenu Option

Use this procedure to enable the **Menu Bar Hover Shows Submenu** option. If you enable this feature it displays the submenus for a category when you hover over the category name.

For example, if you hover over **Advanced**, the **SOFTWARE**, **ACCOUNTS**, **LOG FILES**, and **LICENSES** submenus display. You can click any submenu and avoid opening the default menu for a category.

1. Click **Configuration | MISC**.
2. Click the **EDIT** button.
3. Click **Enable** next to the **Menu Bar Hover Shows Submenu** option.

4. Click SAVE.



10.6.2. Enable PDO Write From Attached Devices Port Page


The purpose of this feature is for a **non-production** type of demonstration of the IOLM. You can enable this feature to get familiar with IO-Link or if you are commissioning a system and want to be able to test / get familiar with devices. It allows you to interact with a PDO device that does not have a PLC connection.

Note: *The PDO write will not allow writes if the IOLM has a PLC connection. **This should never be enabled in a production environment.***

Use this procedure to enable PDO write from the **Attached Devices | Port** page.

1. If necessary, log into the IOLM using the Administrator account.
2. Click **Configuration | MISC**.
3. Click the **EDIT** button.
4. Click **Enable** next to the **Enable PDO Write From Attached Devices Port Page** option.
5. Click the **SAVE** button.


6. If this will not cause an unstable environment, click the **CONTINUE** button.



10.6.3. IO-Link Test Event Generator


You can use the **IO-Link Test Event Generator** to send messages to an IOLM port. The generated events are displayed in the **Diagnostics | IO-Link Settings** page under the **Last Events** field and the syslog. This can test a port to verify that it is functioning correctly through

1. Click **Configuration | Misc.**
2. Expand the **IO-Link Test Event Generator**.



3. Select the port and type of event that you want to test.
Use the following table to determine what type of event you want to generate.

IO-Link Test Event Generator Descriptions	
Port	The port number to which you want to send an event.
Mode	This is the first item in the event generated. <ul style="list-style-type: none"> • Single: generates Single in the event. • Coming: generates Active in the event • Going: generates Cleared in the event



IO-Link Test Event Generator Descriptions (Continued)	
Type	<p>This is the second item in the event generated.</p> <ul style="list-style-type: none"> • Message: generates Message in the event. • Warning: generates Warning in the event. • Error: generates Error in the event.
Instance	<p>This is the level in which the event is generated. This is not displayed in the generated event.</p> <ul style="list-style-type: none"> • unknown • physical • datalink • applayer • application
Source	<p>This is the source in which the event is generated. This is the third item in the generated event.</p> <ul style="list-style-type: none"> • local: simulation generated from the IOLM, which displays as Local in the event. • remote: simulation of an IO-Link device event, which displays as Device in the generated event.
PDI	<p>This indicates whether to send valid or invalid PDI, which is not displayed in the generated event.</p> <ul style="list-style-type: none"> • valid • invalid
Code	<p>This is the fourth and fifth items in the generated event.</p> <ul style="list-style-type: none"> • 0x0000: generates a s_pdu_check event • 0x0001: generates a s_pdu_flow event • 0x0002: generates a m_pdu_check event • 0x0003: generates a s_pdu_illegal event • 0x0004: generates a m_pdu_illegal event • 0x0005: generates a s_pdu_buffer event • 0x0006: generates a s_pdu_inkr event • 0x0007: generates an s_pd_len event • 0x0008: generates an s_no_pdin event • 0x0009: generates an s_no_pdout event • 0x000a: generates an s_channel event • 0x000b: generates an m_event event • 0x000c: generates an a_message event • 0x000d: generates an a_warning event • 0x000e: generates an a_device event • 0x000f: generates an a_parameter event • 0x0010: generates a devicelost event • 0x0011, 13 - 17: generates an unknown event • 0x0012: generates a s_desina event

4. Click **Diagnostics** and scroll down to **Last Events**.

The screenshot shows the 'IO-Link Diagnostics' page in a web browser. The page has a navigation bar with 'CONTROL' logo and menu items: Home, Diagnostics (selected), Configuration, Advanced, Attached Devices, Help. The user is logged in as 'IO-Link Master 4-EIP' and can click 'Logout'. Below the navigation bar are protocol options: IO-LINK, ETHERNET/IP, MODBUS/TCP, OPC UA. The main content area is titled 'IO-Link Diagnostics' and includes three buttons: 'UPDATE', 'STOP LIVE UPDATES', and 'RESET STATISTICS'. A table displays various statistics and event logs. The 'Last Events' section is highlighted in yellow, showing a list of events, with the fifth event being '5)Single,Warning,Device,0777h unknown'. Below the table, the 'ISDU Statistics' section is highlighted in red, with the text 'This is the event that was generated'.

Category	Value
Time Since Initialization	0:49:02
Process Data Errors	1
Process Data Retries	1
Total Events	5
First Events	1)Single,Message,Local,0024h m_preoperate 2)Cleared,Error,Local,0010h s_devicelost 3)Single,Error,Local,0002h m_pdu_check 4)Single,Warning,Local,001bh s_retry
Last Events	2)Cleared,Error,Local,0010h s_devicelost 3)Single,Error,Local,0002h m_pdu_check 4)Single,Warning,Local,001bh s_retry 5)Single,Warning,Device,0777h unknown
ISDU Statistics	This is the event that was generated
ISDU Read Cmd Attempts	32
ISDU Read Cmd Errors	3
ISDU Write Cmd Attempts	0
ISDU Write Cmd Errors	0

Welcome Admin © Copyright Control Corp.


10.7. Clearing Settings

You can return the IOLM to factory default values and can choose whether you want to restore these default values:

- Uploaded IODD files
- IO-Link data storage
- Hostname, network settings (DHCP/Static, static IP address, static network mask, and static IP gateway)

Use the following procedure to restore factory default values on the IOLM.

1. Click **Configuration | Clear Settings**.



2. Click the **OK** button to the *Done Configuration Cleared* message.

Chapter 11. Using the Diagnostics Pages

This chapter provides information about the following **Diagnostics** pages.

- [IO-Link Port Diagnostics](#) on Page 106
- [Digital I/O Diagnostics \(IOLM DR-8-EIP\)](#) on Page 109
- [EtherNet/IP Diagnostics](#) on Page 110
- [Modbus/TCP Diagnostics](#) on Page 114
- [OPC UA Diagnostics Page](#) on Page 117

Note: *Not all models support OPC UA.*

11.1. IO-Link Port Diagnostics

Use the IO-Link Diagnostics page to determine the status of the IO-Link configuration.

IO-Link Diagnostics ? UPDATE START LIVE UPDATES RESET STATISTICS

IO-LINK PORT STATUS	PORT 1	PORT 2	PORT 3	PORT 4
Port Name	IOLink Port 1	IOLink Port 2	IOLink Port 3	IOLink Port 4
Port Mode	IOLink	IOLink	IOLink	IOLink
Port Status	Operational	Operational, PDI Valid	Operational, PDI Valid	Operational, PDI Valid
IOLink State	Operate	Operate	Operate	Operate
Device Vendor Name	ifm electronic gmbh	wenglor sensoric GmbH	Leuze electronic GmbH + Co. KG	
Device Product Name	LR8000	OY1P303P0102	HT10L1-25M.3/L69-M12	
Device Serial Number	d0033151013	590003365	01540018205	
Device Hardware Version	AF	Version V01.00.00	B000	
Device Firmware Version	354	Version V01.02.00	1.1	
Device IO-Link Version	1.1	1.1	1.1	1.1
Actual Cycle Time	4.0ms	4.0ms	4.0ms	4.0ms
Device Minimum Cycle Time	2.3ms	2.3ms	2.3ms	2.3ms
Configured Minimum Cycle Time	4ms	4ms	4ms	4ms
Data Storage Capable	Yes	Yes	Yes	No
Automatic Data Storage Configuration	Disabled	Disabled	Disabled	Disabled
Auxiliary Input (AI) Bit Status	Off	On	Off	Off

Welcome Admin © Copyright Control Corp.

Note: This does not illustrate the complete IO-Link Diagnostic page.


The following table provides information about the **IO-Link Diagnostics** page.

IO-Link Diagnostics	
Port Name	This is an optional friendly port name, which can be configured in the Configuration IO-Link page.
Port Mode	Displays the active device mode: <ul style="list-style-type: none"> • Reset = The port is configured to disable all functionality. • IO-Link = The port is configured to IO-Link mode. • Digital In = The port is configured to operate as a digital input. • Digital Out = The port is configured to operate as a digital output.
Port Status	Displays the port status: <ul style="list-style-type: none"> • Inactive = The port is in active state. Typically, this indicates that the device is either not attached or not detected. • Initializing = The port is in the process of initializing. • Operational = The port is operational and, if in IO-Link mode, communications to the IO-Link device has been established. • PDI Valid = The PDI data is now valid. • Fault = The port has detected a fault and is unable to re-establish communications.
IO-Link State	<ul style="list-style-type: none"> • Operate - Port is functioning correctly in IO-Link mode but has not received valid PDI data. This may also display during a data storage upload or download. • Init - The port is attempting initialization. • Reset - One of the following conditions exists: <ul style="list-style-type: none"> - The Port Mode configuration is set to Reset. - The Port Mode configuration is set to DigitalIn or DigitalOut. • DS - Wrong Sensor - Hardware failure (IO-Link LED also flashes red) because there is Data Storage on this port, which does not reflect the attached device. • DV - Wrong Sensor - Hardware failure (IO-Link LED also flashes red) because Device Validation is configured for this port and the wrong device is attached. • DS - Wrong Size - Hardware failure (IO-Link LED also flashes red) because the size of the configuration on the device does not match the size of the configuration stored on the port. • Comm Lost - Temporary state after a device is disconnected and before the port is re-initialized. • Pre-operate - Temporary status displayed when the device: <ul style="list-style-type: none"> - Is starting up after connection or power-up. - Uploading or downloading automatic data storage.
Device Vendor Name	Displays the Device Vendor Name as stored in ISDU Index 16.
Device Product Name	Displays the device product name as stored in ISDU Index 18.
Device Serial Number	Displays the device serial number as stored in ISDU Index 21.
Device Hardware Version	Displays the device hardware version as stored in ISDU Index 22.
Device Firmware Version	Displays the device firmware version as stored in ISDU Index 23.
Device IO-Link Version	The supported device IO-Link version as stored in ISDU Index 0.

IO-Link Diagnostics (Continued)	
Actual Cycle Time	This is the actual, or current, cycle time of the IO-Link connection to the device.
Device Minimum Cycle Time	This is the minimum, or fastest, cycle time supported by the connected IO-Link device.
Configured Minimum Cycle Time	Configured in the Configuration IO-Link page, this is the minimum cycle time the IO-Link Master will allow the port to operate at. The Actual Cycle Time , which is negotiated between the IO-Link Master and the device, will be at least as long as the greater of the Configured Minimum Cycle Time and the Device Minimum Cycle Time .
Data Storage Capable	Displays whether the IO-Link device on a port supports the data storage feature. Not all IO-Link devices support the data storage feature.
Automatic Data Storage Configuration	Displays whether a port is configured to automatically upload data from the IO-Link device or download data from the IOLM to the IO-Link device. Disabled displays if automatic upload or download are not enabled.
Auxiliary Input (AI) Bit Status	The current status of the auxiliary bit as received on DI (Pin 2 on the IOLM 4-EIP and 8-EIP) of the IO-Link port.
Device PDI Data Length	The supported Device PDI Data Length, in bytes, as stored in ISDU Index 0.
PDI Data Valid	Current status of PDI data as received from the IO-Link device.
Last Rx PDI Data (MS Byte First)	The last Rx PDI data as received from the IO-Link device.
Device PDO Data Length	The supported Device PDO Data Length, in bytes, as stored in ISDU Index 0.
PDO Data Valid	Status of PDO data being received from controller(s).
Last Tx PDO Data (MS Byte First)	The last Tx PDO data.
Time Since Initialization	The time since the last port initialization.
Process Data Errors	The number of process data errors the port received.
Process Data Retries	The number of process data retries the port performed.
Total Events	The total number of events that were received on this port.
First Events	Up to the first, or oldest, three events that were received on this port.
Last Events	Up to the last, or most recent, three events that were received on this port.
ISDU Statistics	
ISDU Read Cmd Attempts	The number of read ISDU command attempts.
ISDU Read Cmd Errors	The number of read ISDU command errors.
ISDU Write Cmd Attempts	The number of write ISDU command attempts.
ISDU Write Cmd Errors	The number of write ISDU command errors.

11.2. Digital I/O Diagnostics (IOLM DR-8-EIP)

The **Digital I/O Diagnostics** page may be useful when trying to troubleshoot port issues related to configuration.



The following table provides information about the **Digital I/O Diagnostics** page.

Digital I/O Diagnostics	
Mode	Displays the current configured operating mode of the digital I/O pin. <ul style="list-style-type: none"> • Off • Digital-Input • Digital-Output (Pins D2 and D4 only)
Invert I/O	Displays the current configured Invert I/O setting: <ul style="list-style-type: none"> • True(Invert I/O) • False (Do not invert I/O)
Input Settling Time (ms)	Displays the current configured input settling time.
Status	Displays the current status of the digital I/O pin. <ul style="list-style-type: none"> • On (high voltage) • Off (low voltage)
Status Changes	Displays the number of times that the status of the digital I/O pin has changed.

11.3. EtherNet/IP Diagnostics

The EtherNet/IP Diagnostics page may be useful when trying to troubleshoot EtherNet/IP communications and port issues related to EtherNet/IP configuration.

The screenshot shows the 'EtherNet/IP Diagnostics' page in a web interface. The page title is 'EtherNet/IP Diagnostics' and it includes buttons for 'UPDATE', 'STOP LIVE UPDATES', and 'RESET STATISTICS'. A table titled 'ETHERNET/IP GENERAL STATUS' displays various metrics, all of which are currently at 0, except for 'First Error String' which is 'No Error Detected'. A red text overlay is present over the right side of the table.

ETHERNET/IP GENERAL STATUS	
Active Session Count	0
Active Connections	0
Total Connections Established	0
Connection Timeouts	0
Connections Closed	0
Class 3 Messages/Responses Received	0
Broadcast Messages Received	0
Class 3 Messages/Responses Transmitted	0
Class1 Output Updates (From PLC)	0
Class 1 Output Data Changes (From PLC)	0
Class1 Input Updates (To PLC)	0
Client Object Requests	0
Good Responses from PLC	0
Bad Responses from PLC	0
No Responses From PLC	0
Invalid Network Paths	0
Pending Request Limit Reached	0
Unexpected Events	0
Unsupported CIP Class Errors	0
Unsupported CIP Instance Errors	0
Unsupported CIP Service Errors	0
Unsupported CIP Attribute Errors	0
Unsupported File Errors	0
System Resource Errors	0
First Error String	No Error Detected
Last Error String	

The following table provides information about the **EtherNet/IP Diagnostics** page.

EtherNet/IP Diagnostics	
Active Session Count	The number of active Ethernet/IP sessions. A session can: <ul style="list-style-type: none"> • Support both Class 1 I/O and Class 3 Messages • Can be initiated by either the PLC or the IO-Link Master • Can be terminated by either the PLC or the IO-Link Master
Active Connections	The current number of active connections (both Class 1 and 3).
Total Connections Established	The total number of connections that have been established.
Connection Timeouts	The number of connections that have closed due to timing out.
Connections Closed	The number connections that have closed due to a standard processes.
Class 3 Messages/ Responses Received	The number of Class 3 messages and responses received from the PLC or PLCs.
Broadcast Messages Received	The number of broadcast messages received from PLC or PLCs.
Class 3 Messages/ Responses Transmitted	The number of Class 3 messages and responses sent to the PLC or PLCs.
Class 1 Output Updates (From PLC)	The number of Class 1 output data updates received from the PLC or PLCs.
Class 1 Output Data Changes (From PLC)	The number of changes in Class 1 output data received from the PLC.
Class 1 Input Data Updates (To PLC)	The number of Class 1 input data updates sent to the PLC or PLCs.
Client Object Requests	The number of Class 3 requests to the IO-Link Master vendor specific objects.
Good Responses from PLC	The number of good responses from messages sent to PLC or PLCs.
Bad Responses from PLC	Displays the number of bad responses from messages sent to the PLC or PLCs. Bad responses are typically returned for such errors as: <ul style="list-style-type: none"> • Incorrect tag or file names • Incorrect tag or file data types • Incorrect tag or file data sizes • PLC is overloaded and cannot handle the amount of Ethernet traffic • PLC malfunction
No Responses from PLC	Displays the number of no responses from messages sent to the PLC or PLCs. No responses are typically returned for such errors as: <ul style="list-style-type: none"> • Incorrect IP address • Incorrect PLC configuration • PLC malfunction • PLC is overloaded and cannot handle the amount of Ethernet traffic
Invalid Network Paths	Displays the number of network path errors on messages sent to the PLC or PLCs. These are typically caused by incorrect IP address settings.
Pending Request Limit Reached	Displays the number of pending request limit errors. These errors occur when the PLC is sending a continuous stream of messages to the IO-Link Master faster than the IO-Link Master can process them.
Unexpected Events	Displays the number of unexpected event errors. Unexpected event errors occur when the IO-Link Master receives an unexpected message from the PLC such as an unexpected response or unknown message.

EtherNet/IP Diagnostics (Continued)	
Unsupported CIP Class Errors	Displays the number of unsupported CIP class errors. These errors occur when a message that attempts to access an invalid class is received by the IO-Link Master.
Unsupported CIP Instance Errors	Displays the number of unsupported CIP instance errors. These errors occur when a message that attempts to access an invalid instance is received by the IO-Link Master.
Unsupported CIP Service Errors	Displays the number of unsupported CIP service errors. These errors occur when a message that attempts to access an invalid service is sent to the IO-Link Master.
Unsupported CIP Attribute Errors	Displays the number of unsupported CIP request attribute errors. These errors occur when a message that attempts to access an invalid attribute is sent to the IO-Link Master.
Unsupported File Errors	Displays the number of messages from SLC/PLC-5/MicroLogix PLCs that attempt to access an unsupported file address.
System Resource Errors	Displays the number of system resource errors. These errors indicate a system error on the IO-Link Master such as operating system errors or full message queues. These errors typically occur when the PLC or PLCs are sending messages to the IO-Link Master faster than the IO-Link Master can process them.
First Error String	Text description of the first error that occurred.
Last Error String	Text description of the last error that occurred.
<i>EtherNet/IP Port Specific Diagnostics</i>	
Configuration Errors	Displays the number of improper configuration errors. These errors occur when the IO-Link Master receives a message that cannot be performed due to an invalid configuration.
Invalid Data Errors	Displays the number of invalid message data errors. These errors occur when the IO-Link Master receives a message that cannot be performed due to invalid data.
Active PDO Controller(s)	Lists the controller interface(s) type, (Class 1 or Class 3), and IP address that are controlling the PDO data.
PDO Writes to Offline or Read-Only Ports	Displays the number of PDO write messages that were dropped due to any of the following: <ul style="list-style-type: none"> • The port is configured in IO-Link mode: <ul style="list-style-type: none"> - There is no device connected to the port. - The IO-Link device is off-line. - The IO-Link device does not support PDO data. • The PDO Transmit Mode (To PLC) is disabled. • The port is configured in Digital Input mode.
Undeliverable PDI Updates (To PLC)	Displays the number of PDI update messages that could not be delivered to the PLC in the Write-to-Tag/File method. Undeliverable updates may result when: <p>The IO-Link Master cannot complete an Ethernet connection to the PLC.</p> <p>The PDI data is changing faster than the Maximum PLC Update Rate.</p>
ISDU Request Msgs From PLC(s)	Displays the number of ISDU request messages received from the PLC(s) or other controllers. These request messages may contain one or multiple ISDU commands.
ISDU Invalid Requests	Displays the number of ISDU requests received over EtherNet/IP with one or more invalid commands.

EtherNet/IP Diagnostics (Continued)	
ISDU Requests When Port Offline	<p>Displays the number of ISDU requests received over EtherNet/IP when the IO-Link port was offline. This can occur when:</p> <ul style="list-style-type: none"> • The IO-Link port is initializing, such as after start-up. • There is no IO-Link device attached to the port. • The IO-Link device is not responding. • Communication to the IO-Link device has been lost.
Valid ISDU Responses From Port	Displays the number of valid ISDU response messages returned from the IO-Link port interface and available to the PLC(s). The response messages contain results to the ISDU command(s) received in the request message.
ISDU Response Timeouts	Displays the number of ISDU requests that did not receive a response within the configured ISDU Response Timeout .
Unexpected ISDU Responses	<p>Displays the number of unexpected ISDU responses.</p> <p>Unexpected responses may occur when an ISDU response is received after the ISDU request has timed out. This typically requires setting the ISDU Response Timeout to a longer value.</p>
ISDU Read Commands	Displays the number of ISDU read commands received over EtherNet/IP.
Maximum ISDU Request Msg Response Time	Displays the maximum time period required to process all commands within an ISDU request message. The response is not available until all ISDU command(s) contained in the request have been processed.
Average ISDU Request Msg Response Time	Displays the average time period required to process the ISDU request message(s). The response is not available until all ISDU command(s) contained in the request have been processed.
Minimum ISDU Request Msg Response Time	Displays the minimum time period required to process all commands within an ISDU request message. The response is not available until all ISDU command(s) contained in the request have been processed.
ISDU Write Commands	Displays the number of ISDU write commands received over EtherNet/IP.
ISDU NOP Commands	Displays the number of ISDU NOP (no operation) commands received over EtherNet/IP.

11.4. Modbus/TCP Diagnostics

The **Modbus/TCP Diagnostics** page may be useful when trying to troubleshoot Modbus/TCP communications or port issues related to Modbus/TCP configuration.

Modbus/TCP Diagnostics

UPDATE STOP LIVE UPDATES RESET STATISTICS

MODBUS/TCP GENERAL STATUS	
Modbus/TCP Server Enable	disable
Active Connections	
Messages Received From Masters	
Responses Sent To Masters	
Broadcasts Received	
Invalid Message Length Errors	
Invalid Message Data Errors	
Invalid Message Address Errors	
Unknown Device ID Errors	
Invalid Protocol Type Errors	
Unsupported Function Code Errors	
Configuration Errors	
No Available Connection Errors	
System Resource Errors	
First Error String	
Last Error String	

The complete Diagnostics page is not displayed in this image

MODBUS/TCP PORT STATUS	PORT 1	PORT 2	PORT 3	PORT 4
Active PDO Controller(s)				
PDO Writes to Offline or Read-Only Ports				
ISDU Request Msgs from PLC(s)				
ISDU Invalid Requests				
ISDU Requests When Port Offline				
Valid ISDU Responses from Port				
ISDU Response Timeouts				
Unexpected ISDU Responses				

Welcome Admin © Copyright Comtrol Corp.

The following table provides information about the **Modbus/TCP Diagnostics** page.

Modbus/TCP Diagnostics	
Active Connections	Displays the current number of active Modbus/TCP connections.
Messages Received from Masters	Displays the number of Modbus messages received from Modbus/TCP Masters.
Responses Sent to Masters	Displays the number of Modbus responses sent to Modbus/TCP Masters.
Broadcasts Received	Displays the number of broadcast Modbus/TCP messages received.
Invalid Message Length Errors	Displays the number of Modbus messages received with incorrect length fields.
Invalid Message Data Errors	Displays the number of invalid message data errors. These errors occur when the IO-Link Master receives a message that cannot be performed due to invalid data.
Invalid Message Address Errors	Displays the number of invalid message address errors. These errors occur when the IO-Link Master receives a message that cannot be performed due to an invalid address.
Unknown Device ID Errors	Displays the number of unknown device ID errors. These errors occur when the IO-Link Master receives a message that is addressed to a device ID other than the configured Slave Mode Device ID .
Invalid Protocol Type Errors	Displays the number of invalid message protocol type errors. These errors occur when the IO-Link Master receives a Modbus/TCP message that specifies a non-Modbus protocol.
Unsupported Function Code Errors	Displays the number of invalid Modbus function code errors. These errors occur when the IO-Link Master receives a message that cannot be performed due to an unsupported Modbus function code.
Configuration Errors	Displays the number of improper configuration errors. These errors occur when the IO-Link Master receives a message that cannot be performed due to an invalid configuration.
No Available Connection Errors	Displays the number of Modbus/TCP connection attempts that were rejected due to no available connections. This occurs when the number of Modbus/TCP connections has reached the limit.
System Resource Errors	Displays the number of system resource errors. These errors indicate a system error on the IO-Link such as operating system errors or full message queues. These errors typically occur when the PLC(s) are sending messages to the IO-Link Master faster than the IO-Link Master can process them.
First Error String	Text description of the first error that occurred.
Last Error String	Text description of the last error that occurred.
<i>Modbus/TCP Port Specific Diagnostics</i>	
Active PDO Controller(s)	Lists the controller interface(s) type, (Class 1 or Class 3), and IP address that are controlling the PDO data.
PDO Writes to Offline or Read-Only Ports	Displays the number of PDO write messages that were dropped due to any of the following: <ul style="list-style-type: none"> • The port is configured in IO-Link mode: <ul style="list-style-type: none"> - There is no device connected to the port. - The IO-Link device is off-line. - The IO-Link device does not support PDO data. • The PDO Transmit Mode (To PLC) is disabled. • The port is configured in Digital Input mode.

Modbus/TCP Diagnostics (Continued)	
ISDU Request Msgs From PLC(s)	Displays the number of ISDU request messages received from the PLC(s) or other controllers. These request messages may contain one or multiple ISDU commands.
ISDU Invalid Requests	Displays the number of ISDU requests received over Modbus/TCP with one or more invalid commands.
ISDU Requests When Port Offline	Displays the number of ISDU requests received over Modbus/TCP when the IO-Link port was offline. This can occur when: <ul style="list-style-type: none"> • The IO-Link port is initializing, such as after start-up. • There is no IO-Link device attached to the port. • The IO-Link device is not responding. • Communication to the IO-Link device has been lost.
Valid ISDU Responses From Port	Displays the number of valid ISDU response messages returned from the IO-Link port interface and available to the PLC(s). The response messages contain results to the ISDU command(s) received in the request message.
ISDU Response Timeouts	Displays the number of ISDU requests that did not receive a response within the configured ISDU Response Timeout .
Unexpected ISDU Responses	Displays the number of unexpected ISDU responses. Unexpected responses may occur when an ISDU response is received after the ISDU request has timed out. This typically requires setting the ISDU Response Timeout to a longer value.
Maximum ISDU Request Msg Response Time	Displays the maximum time period required to process all commands within an ISDU request message. The response is not available until all ISDU command(s) contained in the request have been processed.
Average ISDU Request Msg Response Time	Displays the average time period required to process the ISDU request message(s). The response is not available until all ISDU command(s) contained in the request have been processed.
Minimum ISDU Request Msg Response Time	Displays the minimum time period required to process all commands within an ISDU request message. The response is not available until all ISDU command(s) contained in the request have been processed.
ISDU Read Commands	Displays the number of ISDU read commands received over Modbus/TCP.
ISDU Write Commands	Displays the number of ISDU write commands received over Modbus/TCP.
ISDU NOP Commands	Displays the number of ISDU NOP (no operation) commands received over Modbus/TCP.

11.5. OPC UA Diagnostics Page

The **OPC UA Diagnostics** page displays status for OPC UA:

- Whether the OPC UA feature is enabled or disabled
- Number of TCP connections

The screenshot shows the 'OPC UA Diagnostics' page. The navigation bar includes 'CONTROL', 'Home', 'Diagnostics', 'Configuration', 'Advanced', 'Attached Devices', 'Help', 'IO-Link Master 4-EIP', and 'Logout'. Below the navigation bar, there are tabs for 'IO-LINK', 'ETHERNET/IP', 'MODBUS/TCP', and 'OPC UA'. The main content area is titled 'OPC UA Diagnostics' and contains a table with the following data:

OPC UA GENERAL STATUS	
OPC UA Server Enable	disable
Number of TCP connections	0

Buttons for 'UPDATE', 'STOP LIVE UPDATES', and 'RESET STATISTICS' are located to the right of the table. The footer of the page displays 'Welcome Admin' and '© Copyright Control Corp.'.


Note: *Not all models support OPC UA.*

Chapter 12. EtherNet/IP Interface

12.1. Introduction

This section is intended to describe the EtherNet/IP interface provided by the IOLM.

These interfaces provide the ability to retrieve port and device status information, input and output process data and access to IO-Link device ISDU (SPDU) data blocks.



Note: Indexed Service Data Unit (ISDU) is sometimes referred to as Service Protocol Data Unit (SPDU). See [13.3. ISDU Handling](#) on Page 134 for more information.

12.1.1. Functionality Summary

The EtherNet/IP interface consists of:

- Input Process Data blocks that include:
 - Port communication status
 - PDI valid status
 - Auxiliary Input status of IO-Link connector (DI on the IOLM DR-8-EIP and Pin 2 on the IOLM 4-EIP and 8-EIP)
 - The active event code (zero if no active event)
 - The input process data received from the port. This may be
 - IO-Link mode: IO-Link device input process data

- I/O Input mode: Input bit status
- I/O Output mode: Output bit status (configurable option)
- Output Process Data blocks that include:
 - The active event code to clear ((configurable option)
 - The output process data to be sent to the port. This may be
 - IO-Link mode: IO-Link device output process data
 - I/O Output mode: Output bit status
- ISDU (ISDU) interface:
 - Provides single and nested batch read/write capabilities
 - Requires use of MSG instructions
 - Provides both blocking and non-blocking message capabilities
 - Blocking message responses are not returned until all the ISDU command(s) have completed.
 - Non-blocking messages return immediately. The PLC must then request the ISDU command(s) response status until a valid response is returned.
- Web based configuration and diagnostic pages:
 - IO-Link interface configuration and diagnostics
 - EtherNet/IP interface configuration and diagnostics
- EtherNet/IP interface support for ControlLogix, SLC, MicroLogix, and PLC-5 PLC families.
- Modbus/TCP slave interface.
- Example PLC programs to aid the PLC programmer.

12.1.2. Data Type Definitions

The following data type definitions apply.

Data Type Definitions	
BOOL	Boolean; TRUE if = 1; False if = 0
USINT	Unsigned Short Integer (8 bit)
CHAR	Character (8 bit)
SINT	Short Integer (8 bit)
UINT	Unsigned Integer (16 bit)
INT	Signed Integer (16 bit)
UDINT	Unsigned Double Integer (32 bit)
DINT	Signed Double Integer (32 bit)
STRING	Character String (1 byte per character)
BYTE	Bit String (8 bit)
WORD	Bit String (16 bits)
DWORD	Bit String (32 bits)

12.1.3. Terms and Definitions

This section uses the following terms and definitions.

Term	Definition
Class 1	Otherwise called implicit messaging, is a method of communication between EtherNet/IP controllers and devices that: <ul style="list-style-type: none"> • Uses Ethernet UDP messages. • Is cyclic in nature. Input and/or output data is exchanged between the controllers and devices at regular time intervals.
Class 3	Otherwise called explicit messaging, is a method of communication between EtherNet/IP controllers and devices that: <ul style="list-style-type: none"> • Uses Ethernet TCP/IP messages. • By itself is not cyclic in nature. The controller and devices must send individual messages to each other.
EtherNet/IP	An Ethernet based industrial communication protocol utilized to communicate between controllers, often times PLCS, and devices.
Ethernet TCP/IP	Standard Ethernet communications protocol utilizing socket communication interfaces that guarantees delivery to the intended device.
Ethernet UDP/IP	Standard Ethernet communications protocol utilizing socket communication interfaces that does not guarantee delivery . The data may or may get to the intended device.
IOLM	IO-Link gateway that provides communication between IO-Link devices and Ethernet protocols such as EtherNet/IP and Modbus/TCP.
Multicast	Multicast addressing involves Ethernet devices sending messages to each other using a multicast address. Multicast addressing: <ul style="list-style-type: none"> • Uses a specified IP address range designated for multicast communication. • Allows either one or multiple devices to receive the same messages.
Point-to-Point	Point-to-Point, otherwise called unicast , addressing involves Ethernet devices sending messages directly to each other using their own IP addresses. Messages are sent to only one device.
PDI data (Process Data Input)	Process data received from an IO-Link device or I/O interface that can be provided to external controllers such as PLCs, HMIs, SCADA, and OPC UA Servers.
PDO data (Process Data Output)	Process data received from external controllers such as PLCs, HMIs, SCADA, and OPC Servers and sent to an IO-Link device or I/O interface. Note: <i>IO-Link devices may or may not support PDO data.</i>
ISDU	Indexed Service Data Unit. Otherwise called ISDU, refers to the Service Data units on IO-Link devices that are used for information, status and configuration settings.
Class 1	Otherwise called implicit messaging, is a method of communication between EtherNet/IP controllers and devices that: <ul style="list-style-type: none"> • Uses Ethernet UDP messages. • Is cyclic in nature. Input and/or output data is exchanged between the controllers and devices at regular time intervals.

12.2. Data Transfer Methods

The IOLM provides a selection of process data transfer methods and a number of options to customize the process data handling.

- [Receive Process Data Methods](#) on Page 122
- [Transmit Process Data Methods](#) on Page 123


12.2.1. Receive Process Data Methods

The IOLM supports the following receive process data methods:

- [Polling-PLC Requests Data](#) on Page 122
- [Write-to-Tag/File-IOLM Writes Data Directly Into PLC Memory](#) on Page 122
- [Class 1 Connection \(Input Only\)-PLC and IOLM Utilize an I/O Connection](#) on Page 123


12.2.1.1. Polling-PLC Requests Data

Also called *Slave-Mode* for some industrial protocols, the polling method requires the controller to request data from the IOLM via messages. The IOLM does not respond until it receives a request for data.




12.2.1.2. Write-to-Tag/File-IOLM Writes Data Directly Into PLC Memory

Also called *Master-Mode* for some industrial protocols, the Write-to-Tag/File method requires the IOLM to send messages that write data directly into a tag or file on the PLC. The IOLM sends changed data to the PLC immediately and, optionally, can be configured to also send “heartbeat” update messages at a regular time interval.



12.2.1.3. Class 1 Connection (Input Only)-PLC and IOLM Utilize an I/O Connection

Also called *I/O Mode* for some industrial protocols, the Class 1 connection method requires the IOLM and PLC to connect to each via an I/O connection. For EtherNet/IP, a connection over UDP must first be created. Once the connection is established, the IOLM continually sends input data to the PLC at a PLC configurable rate.




12.2.2. Transmit Process Data Methods

The IOLM supports the following transmit process data methods:

- [PLC-Writes](#) on Page 123
- [Read-from-Tag / File-IOLM Reads Data from PLC Memory](#) on Page 124
- [Class 1 Connection \(Input and Output\)-PLC and IOLM Utilize an I/O Connection](#) on Page 124


12.2.2.1. PLC-Writes

Also called *Slave-Mode* for some industrial protocols, the PLC-Writes method requires the PLC to send data to the IOLM via write messages.




12.2.2.2. Read-from-Tag/File-IOLM Reads Data from PLC Memory

Also called *Master-Mode* for some industrial protocols, the Read-from-Tag/File method requires the IOLM to read data from a tag or file on the PLC. In this method, the IOLM requests data from the PLC at configurable time intervals.



12.2.2.3. Class 1 Connection (Input and Output)-PLC and IOLM Utilize an I/O Connection

Also called *I/O Mode* for some industrial protocols, the Class 1 connection method requires the IOLM and PLC to connect to each via an I/O connection. For EtherNet/IP, a connection over UDP must first be created. Once the connection is established, the PLC and IOLM continually exchange data at a configurable rate.



Chapter 13. Functionality Descriptions

This chapter discusses the following for EtherNet/IP and Modbus/TCP:

- *Process Data Block Descriptions*
- [Event Handling](#) on Page 130
- [ISDU Handling](#) on Page 134

13.1. Process Data Block Descriptions



This subsection discusses the following:

- *Input Process Data Block Description*
- [Output Process Data Block Description](#) on Page 127

13.1.1. Input Process Data Block Description

The Input Process Data Block format is dependent on the configured PDI Data Format. The following tables describe the Input Process Data Block in the possible formats.

Parameter Name	Data Type	Description
Port Status	BYTE	<p>The status of the IO-Link device.</p> <p>Bit 0 (0x01): 0 = IO-Link port communication initialization process is inactive 1 = IO-Link port communication initialization process is active</p> <p>Bit 1 (0x02): 0 = IO-Link port communication is not operational 1 = IO-Link port communication is operational</p> <p>Bit 2 (0x04): 0 = IO-Link input process data is not valid. 1 = IO-Link input process data is valid.</p> <p>Bit 3 (0x08): 0= No fault detected 1= Fault detected</p> <ul style="list-style-type: none">• A minor communication fault is indicated by the Operational status bit being set to 1. A minor communication fault results from:<ul style="list-style-type: none">- A temporary loss of communication to the IO-Link device.- A recoverable IOLM software or hardware fault.• A major communication fault is indicated by the Operational bit being set to 0.<ul style="list-style-type: none">- An unrecoverable loss of communication to the IO-Link device.- An unrecoverable IOLM software or hardware fault. <p>Bits 4-7: Reserved (0)</p>

Parameter Name	Data Type	Description
Auxiliary I/O  	BYTE	Auxiliary I/O: <i>Note: The auxiliary bit on the IO-Link port is Pin 2 on the IOLM 4-EIP and 8-EIP and DI on the IOLM DR-8-EIP.</i> Bit 0 (0x01): The status of the auxiliary bit. 0 = off 1 = on Bits 1-3: Reserved (0) If Include Digital I/O in PDI Data Block is disabled: Bits 4-7: Reserved (0) If Include Digital I/O in PDI Data Block is enabled: Bits 4-7: Bit 4 (0x10) – L+ input status Bit 5 (0x20) – DI I/O status Bit 6 (0x40) – L- input status Bit 7 (0x80) – C/Q I/O status
Event Code	INT	16-bit event code received from the IO-Link device.
PDI Data <i>Default Length = 32 bytes</i>	Array of up to 32 BYTES	The PDI data as received from the IO-Link device. May contain from 0 to 32 bytes of PDI data. The definition of the PDI data is device dependent. <i>Note: Length is configurable using the web page interface.</i>

13.1.1.1. Input Process Data Block-8 Bit Data Format

The following table provides detailed information about the Input Process Data Block-8 Bit data format.

Byte	Bit 7	Bit 0
0	Port Status	
1	Auxiliary I/O	
2	Event Code LSB	
3	Event Code MSB	
4	PDI Data Byte 0	
5	PDI Data Byte 1	
..	..	
..	..	
N+3	PDI Data Byte (N-1)	

13.1.1.2. Input Process Data Block-16 Bit Data Format

The following table provides detailed information about the Input Process Data Block-16 data format.

Word	Bit 15	Bit 8	Bit 7	Bit 0
0	Port Status		Auxiliary I/O	
1	Event Code			
2	PDI Data Word 0			
3	PDI Data Word 1			
..	..			
..	..			
N+1	PDI Data Word (N-1)			

13.1.1.3. Input Process Data Block-32 Bit Data Format

The following table provides detailed information about the Input Process Data Block-32 Bit data format.

Long Word	Bit 31	Bit 24	Bit 23	Bit 16	Bit 15	Bit 0
0	Port Status		Auxiliary I/O		Event Code	
2	PDI Data Long Word 0					
3	PDI Data Long Word 1					
..	..					
N	PDI Data Long Word (N-1)					

13.1.2. Output Process Data Block Description

The contents of the Output Process Data Block are configurable.

Parameter Name	Data	Description
Clear Event Code in PDO Block (Configurable option) <i>Default:</i> Not included	INT	If included, allows clearing of 16-bit event code received in the PDI data block via the PDU data block.
Include Digital Output(s) in PDO Data Block <i>Default:</i> Not included	INT	If included, allows setting the Digital Output Pins D2 and D4.
PDO Data <i>Default Length = 32 bytes</i>	Array of up to 32 BYTEs	The PDO data written to the IO-Link device. May contain from 0 to 32 bytes of PDO data. The definition and length of the PDO data is device dependent. Note: Length is configurable via web page interface.

13.1.2.1. Output Process Data Block-8 Bit (SINT) Data Format

Without either the **Clear Event Code in PDO Block** or **Include Digital Output(s) in PDO Data Block** options selected:

Byte	Bit 7	Bit 0
0	PDO Data Byte 0	
1	PDO Data Byte 1	
..	..	
..	..	
N-1	PDO Data Byte (N-1)	

With the **Clear Event Code in PDO Block** option selected and without the **Include Digital Output(s) in PDO Data Block** option selected:

Byte	Bit 7	Bit 0
0	Event Code LSB	
1	Event Code MSB	
2	PDO Data Byte 0	
3	PDO Data Byte 1	
..	..	
..	..	
N+1	PDO Data Byte (N-1)	

With both the **Clear Event Code in PDO Block** and **Include Digital Output(s) in PDO Data Block** options selected:

Byte	Bit 7	Bit 0
0	Event code LSB	
1	Event code MSB	
2	Digital Output Settings: Bit 1 (0x02) - DI setting Bit 3 (0x08) - C/Q setting	
3	0 (Unused)	
4	PDO Data Byte 0	
5	PDO Data Byte 1	
..	..	
..	..	
N + 3	PDO Data Byte (N-1)	

13.1.2.2. Output Process Data Block-16 Bit (INT) Data Format

Without either the Clear Event Code in PDO Block or Include Digital Output(s) in PDO Data Block options selected:

Word	Bit 15	Bit 0
0	PDO Data Word 0	
1	PDO Data Word 1	
..	..	
..	..	
N-1	PDO Data Word (N-1)	

With the Clear Event Code in PDO Block option selected and without the Include Digital Output(s) in PDO Data Block option selected:

Word	Bit 15	Bit 0
0	Event Code	
1	PDO Data Word 0	
2	PDO Data Word 1	
..	..	
..	..	
N	PDO Data Word (N-1)	

With both the Clear Event Code in PDO Block and Include Digital Output(s) in PDO Data Block options selected:

Word	Bit 15	Bit 0
0	Event Code	
1	Digital Output Settings: Bit 1 (0x02) - DI setting Bit 3 (0x08) - C/Q setting	
2	PDO Data Word 0	
3	PDO Data Word 1	
..	..	
..	..	
N+1	PDO Data Word (N-1)	

13.1.2.3. Output Process Data Block-32 Bit (DINT) Data Format

Without either the Clear Event Code in PDO Block or Include Digital Output(s) in PDO Data Block options selected:

Long Word	Bit 31	Bit 0
0	PDO Data Long Word 0	
1	PDO Data Long Word 1	
..	..	
..	..	
N-1	PDO Data Long Word (N-1)	

With the **Clear Event Code in PDO Block** option selected and without the **Include Digital Output(s) in PDO Data Block** option selected:

Long Word	Bit 31	Bit 16	Bit 15	Bit 0
0	0		Event Code	
1	PDO Data Long Word 0			
2	PDO Data Long Word 1			
..	..			
..	..			
N - 1	PDO Data Long Word (N-1)			

With both the **Clear Event Code in PDO Block** and **Include Digital Output(s) in PDO Data Block** options selected:

Long Word	Bit 31	Bit 16	Bit 15	Bit 0
0	Digital Output Settings: Bit 17 (0x2000) – DI setting Bit 19 (0x8000) – C/Q setting		Event Code	
1	PDO Data Long Word 0			
2	PDO Data Long Word 1			
..	..			
..	..			
N - 1	PDO Data Long Word (N-1)			

13.2. Event Handling


The IOLM event handling is designed to provide real-time updates of event codes received directly from the IO-Link device. The IO-Link event code:

- Is included in the second 16-bit word of the Input Process Data (PDI) block.
 - An active event is indicated by a non-zero value.
 - Inactive or no event is indicated by a zero value.
- Two methods are provided to clear an event:
 - Enable the *Clear Event After Hold Time* option.
 - The IOLM keeps, or holds, the active event code in the PDI block until the configured *Active Event Hold Time* has passed.
 - The IOLM then clears the event code in the PDI block and waits until the *Clear Event Hold Time* has passed before including another event code in the PDI block.
 - Enable the *Clear Event In PDO Block* option.
 - The IOLM monitors the PDO block received from the PLC.
 - The IOLM expects the first entry of the PDO block to indicate an event code to be cleared.
 - If there is an active event code in the PDI block and the PDO block both contain the same event code, the event code is cleared in the PDI block.
 - The IOLM then clears event code in the PDI block and waits until the *Clear Event Hold Time* has passed before including another event code in the PDI block.
- The two methods can be used separately or together to control clearing of events.

The next subsections illustrate the event clearing process for the various event configurations.


13.2.1. Clear Event After Hold Time Process

This illustrates clearing the event after the hold time process.




13.2.2. Clear Event in PDO Block Process

This illustrates clearing the event in the PDO block process.




13.2.3. Clear Event Code in PDO Block and Clear Event After Hold Time Process-PDO Block First

This illustrates clearing the event code in the PDO block and clearing the event after the hold time process with the PDO block first.



13.2.4. Clear Event Code in PDO Block and Clear Event After Hold Time Process-Hold Time Expires

This illustrates clearing the event code in the PDO block and clearing the event after the hold time process with the hold time expired.



13.3. ISDU Handling

The IOLM provides a very flexible ISDU interface that is used by all supported industrial protocols. The ISDU interface contains the following:

- An ISDU *request* may contain one or multiple individual ISDU read and/or write *commands*.
- Individual ISDU command based byte swapping capabilities.
- Variable sized command structures to allow access to wide range of ISDU block sizes.
- A single ISDU request may contain as many ISDU read and/or write commands as allowed by the industrial protocol payload. For example, if an industrial protocol provides up to 500 byte read/write payloads, then an ISDU request may contain multiple commands of various lengths that can total up to 500 bytes in length.
- For the ControlLogix family of EtherNet/IP PLCs, both blocking and non-blocking ISDU request methods are provided.
 - The IOLM implements blocking ISDU requests by not responding to an ISDU request message until all commands have been processed.
 - The IOLM implements non-blocking ISDU requests by:
 - Responding to an ISDU request message immediately after receiving and verifying the ISDU request.
 - Requiring the PLC to monitor the ISDU request status with read messages. The IOLM will not return a completed status until all of the ISDU commands have been processed.


13.3.1. ISDU Request/Response Structure

ISDU requests may contain a single command or multiple, nested commands. This subsection discusses the following:

- *Single ISDU Command Request*
- [Multiple ISDU Command Structure](#) on Page 136

13.3.1.1. Single ISDU Command Request

This illustrates a single ISDU command request.




Single Command ISDU Request/Response

13.3.1.2. Multiple ISDU Command Structure

ISDU requests with multiple commands may consist of commands of the same data size or commands with different data sizes. The following are two examples of multiple ISDU commands.


- ISDU commands of same data size ([Page 136](#))
- ISDU commands of different data sizes ([Page 137](#))

Multiple Command ISDU Request/Response of Same Data Area Length



Example - Multiple Command ISDU Request/Response of Same Data Area Length

Multiple Command ISDU Request/Response of Different Data Lengths



Example - Multiple Command ISDU Request/Response of Different Data Area Lengths

13.3.2. ISDU Request Message Format-From PLC to IOLM

Write and read ISDU commands have the same message data format. Each ISDU request message is comprised of one or more commands. The command(s) can consist of either a series of nested commands or a single read command.

Note: A list of nested ISDU commands is terminated with either a control field of 0, (single/last operation), or the end of the message data.

13.3.2.1. Standard ISDU Request Command Format

This table displays a standard ISDU request command format with ControlLogix PLCs.

Name	Data Type	Parameter Descriptions
Byte Swapping	USINT	<p>Bits 0-3:</p> <ul style="list-style-type: none"> 0= No byte swapping. 1= 16-bit (INT) byte swapping of ISDU data. 2= 32-bit (DINT) byte swapping of ISDU data. <p>Bits 4-7:</p> <p>Set to zero. Unused.</p>
RdWrControlType	USINT	<p>Provides the control and type of ISDU command.</p> <p>Bits 0-3, Type Field:</p> <ul style="list-style-type: none"> 0 = NOP (No operation) 1 = Read operation 2 = Write operation 3 = Read/Write “OR” 4 = Read/Write “AND” <p>Bits 4-7, Control Field:</p> <ul style="list-style-type: none"> 0 = Single/Last Operation (length can vary from to 1 to 232) 1 = Nested batch command – fixed 4 byte data area 2 = Nested batch command – fixed 8 byte data area 3 = Nested batch command – fixed 16 byte data area 4 = Nested batch command – fixed 32 byte data area 5 = Nested batch command – fixed 64 byte data area 6 = Nested batch command – fixed 128 byte data area 7 = Nested batch command – fixed 232 byte data area
Index	UINT	The parameter address of the data object in the IO-Link device.
Subindex	UINT	The data element address of a structured parameter of the data object in the IO-Link device.
Datalength	UINT	<p>Length of data to read or write.</p> <p>For nested batch commands, the data length can vary from 1 to the fixed data area size.</p>
Data	Array of USINTs, UINTs, or UDINTs.	<p>Size of array is determined by the Control field in RdWrControlType.</p> <p>Note: Data is valid only for write commands.</p>

13.3.2.2. Integer (16-Bit Word) ISDU Request Command Format

This table shows an integer (16 bit word) ISDU request command format with a SLC, MicroLogix, PLC-5, or Modbus/TCP.

Name	Data Type	Parameter Description
Byte Swapping / RdWrControlType	UINT	<p>Provides the control, type and byte swapping of ISDU command</p> <p>Bits 0-3, Type Field:</p> <ul style="list-style-type: none"> 0 = NOP (No operation) 1 = Read operation 2 = Write operation 3 = Read/Write “OR” 4 = Read/Write “AND” <p>Bits 4-7, Control Field:</p> <ul style="list-style-type: none"> 0 = Single/Last Operation (length can vary from to 1 to 232) 1 = Nested batch command – fixed 4 byte data area 2 = Nested batch command – fixed 8 byte data area 3 = Nested batch command – fixed 16 byte data area 4 = Nested batch command – fixed 32 byte data area 5 = Nested batch command – fixed 64 byte data area 6 = Nested batch command – fixed 128 byte data area 7 = Nested batch command – fixed 232 byte data area <p>Bits 8-11:</p> <ul style="list-style-type: none"> 0= No byte swapping. 1= 16-bit (INT) byte swapping of ISDU data. 2= 32-bit (DINT) byte swapping of ISDU data. <p>Bits 12-15:</p> <ul style="list-style-type: none"> Set to zero. Unused.
Index	UINT	The parameter address of the data object in the IO-Link device.
Subindex	UINT	The data element address of a structured parameter of the data object in the IO-Link device.
Datalength	UINT	<p>Length of data to read or write.</p> <p>For nested batch commands, the data length can vary from 1 to the fixed data area size.</p>
Data	Array of USINTs, UINTs, or UDINTs.	<p>Size of array is determined by the Control field in RdWrControlType.</p> <p>Note: Data is valid only for write commands.</p>

13.3.3. ISDU Response Message Format

The ISDU responses have the same data format as requests with the only exception being the returned command status. Each ISDU response message is comprised of one or more responses to the single and/or nested command(s) received in the request.

13.3.3.1. Standard ISDU Response Command Format

The following table show the standard ISDU response command format with ControlLogix PLCs.

Name	Data Type	Parameter Description
Status	USINT	<p>Indicates the byte alignment and status of the command response.</p> <p>Byte swapping, bits 0-3:</p> <ul style="list-style-type: none"> 0= No byte swapping. 1= 16-bit (INT) byte swapping of TX/RX ISDU data. 2= 32-bit (DINT) byte swapping of TX/RX ISDU data. <p>Status, bits 4-7:</p> <ul style="list-style-type: none"> 0 = NOP (No operation) 1 = In process (Only valid for non-blocking requests) 2 = Success 3 = Failure: IO-Link device rejected the request. 4 = Timed out: IO-Link device did not respond
RdWrControlType	USINT	<p>Provides the control and type of ISDU request</p> <p>Bits 0-3, Type Field:</p> <ul style="list-style-type: none"> 0 = NOP (No operation) 1 = Read operation 2 = Write operation 3 = Read/Write "OR" 4 = Read/Write "AND" <p>Bits 4-7, Control Field:</p> <ul style="list-style-type: none"> 0 = Single/Last Operation (length can vary from to 1 to 232) 1 = Nested batch command – fixed 4 byte data area 2 = Nested batch command – fixed 8 byte data area 3 = Nested batch command – fixed 16 byte data area 4 = Nested batch command – fixed 32 byte data area 5 = Nested batch command – fixed 64 byte data area 6 = Nested batch command – fixed 128 byte data area 7 = Nested batch command – fixed 232 byte data area
Index	UINT	The parameter address of the data object in the IO-Link device.
Subindex	UINT	The data element address of a structured parameter of the data object in the IO-Link device.
Datalength	UINT	<p>Length of data that was read or written.</p> <p>For nested batch commands, the data length can vary from 1 to fixed data area size.</p>
Data	Array of USINTs, UINTs, or UDINTs.	<p>Data required for read commands. Optionally can return the data of a write command.</p> <p>The size of the array is determined by the Control field in the RdWrControlType.</p> <p>Note: Data field not required for single NOP commands.</p>

13.3.3.2. Integer (16-Bit Word) ISDU Response Command Format

The following table shows an integer (16-bit word) ISDU response command format with SLC, MicroLogix, PLC-5, or Modbus/TCP.


Name	Data Type	Parameter Descriptions
Status, Byte-Swapping, RdWrControlType	UINT	<p>Indicates the control, type, byte swapping and status of the ISDU command.</p> <p>Bits 0-3, Type Field:</p> <ul style="list-style-type: none"> 0 = NOP (No operation) 1 = Read operation 2 = Write operation 3 = Read/Write "OR" 4 = Read/Write "AND" <p>Bits 4-7, Control Field:</p> <ul style="list-style-type: none"> 0 = Single/Last Operation (length can vary from to 1 to 232) 1 = Nested batch command – fixed 4 byte data area 2 = Nested batch command – fixed 8 byte data area 3 = Nested batch command – fixed 16 byte data area 4 = Nested batch command – fixed 32 byte data area 5 = Nested batch command – fixed 64 byte data area 6 = Nested batch command – fixed 128 byte data area 7 = Nested batch command – fixed 232 byte data area <p>Byte swapping, bits 8-11:</p> <ul style="list-style-type: none"> 0= No byte swapping. 1= 16-bit (INT) byte swapping of TX/RX ISDU data. 2= 32-bit (DINT) byte swapping of TX/RX ISDU data. <p>Status, bits 12-15:</p> <ul style="list-style-type: none"> 0 = NOP (No operation) 1 = In process (Only valid for non-blocking requests) 2 = Success 3 = Failure: IO-Link device rejected the request. 4 = Timed out: IO-Link device did not respond
Index	UINT	The parameter address of the data object in the IO-Link device
Subindex	UINT	The data element address of a structured parameter of the data object in the IO-Link device.
Datalength	UINT	<p>Length of data that was read or written.</p> <p>For nested batch commands, the data length can vary from 1 to fixed data area size.</p>
Data	Array of USINTs, UINTs, or UDINTs	<p>Data returned for read commands. Contains the data of a write command.</p> <p>The size of the array is determined by the Control field in RdWrControlType.</p> <p>Note: Data field not required for single NOP commands.</p>

13.3.4. ISDU Blocking and Non-Blocking Methods

The IOLM supports both blocking and non-blocking ISDU requests. The following diagrams demonstrate how each mode works.

13.3.4.1. Single Command Blocking


The following illustrates the single command blocking method.



Single Command ISDU Blocking Process

13.3.4.2. Multiple Command Blocking


This illustrates the multiple command blocking method.



Multiple Command ISDU Blocking Process

13.3.4.3. Single Command Non-Blocking


This illustrates the single command non-blocking method.



Single Command ISDU Non-Blocking Process

13.3.4.4. Multiple Command Non-Blocking

This illustrates the multiple command non-blocking method.



Multiple Command ISDU Non-Blocking Process

Chapter 14. EtherNet/IP CIP Object Definitions

The following are the vendor specific CIP Object definitions as supported in the IOLM:

- [IO-Link Port Information Object Definition \(71 hex\)](#)
- [PDI \(Process Data Input\) Transfer Object Definition \(72 hex\)](#) on Page 153
- [PDO \(Process Data Output\) Transfer Object Definition \(73 hex\)](#) on Page 154
- [ISDU Read/Write Object Definition \(74 hex\)](#) on Page 155

The following are standard CIP Object Definitions that are supported in the IOLM.

- [Identity Object \(01hex, 1 instance\)](#) on Page 157
- [Message Router Object \(02 hex\)](#) on Page 159
- [Connection Manager Object \(06 hex\)](#) on Page 160
- [Port Object \(F4 hex-1 instance\)](#) on Page 161
- [TCP Object \(F5 hex-1 instance\)](#) on Page 163
- [Ethernet Link Object \(F6 hex-1 instance\)](#) on Page 165
- [PCCC Object \(67 hex-1 instance\)](#) on Page 167

14.1. IO-Link Port Information Object Definition (71 hex)

The IO-Link Device Information object defines the attributes by which the PLC can request standard device information stored in the IO-Link device's ISDU blocks.

14.1.1. Class Attributes

The following table shows the class attributes for IO-Link port information object definition (71 hex).

Attribute ID	Name	Data Type	Data Value(s)	Access Rule
1	Revision	UINT	1	Get
2	Max Instance	UINT	4 (4-Port models)8 (8-Port models)	Get
3	Num Instances	UINT	4 (4-Port models)8 (8-Port models) <i>Note: Instance number determines the IO-Link port.</i>	Get

14.1.2. Instance Attributes

The following table shows the instance attributes for IO-Link port information object definition (71 hex).

Attribute ID	Name	Data Type	Data Value(s)	Access Rule
1	Vendor Name	Array of 64 SINTs	0-255	Get
2	Vendor Text	Array of 64 SINTs	0-255	Get
3	Product Name	Array of 64 SINTs	0-255	Get
4	Product Id	Array of 64 SINTs	0-255	Get
5	Product Text	Array of 64 SINTs	0-255	Get
6	Serial Number	Array of 16 SINTs	0-255	Get
7	Hardware Revision	Array of 64 SINTs	0-255	Get
8	Firmware Revision	Array of 64 SINTs	0-255	Get
9	Device PDI Length	INT	0-32	Get
10	Device PDO Length	INT	0-32	Get
11	PDI Block Length	INT	4-36	Get
12	PDO Block Length	INT	0-36	Get
13	Input Assembly PDI Offset	INT	0-108 (8-bit format) 0-54(16-bit format) 0-27 (32-bit format)	Get
14	Input Assembly PDO Offset	INT	16-246 (8-bit format) 8-123(16-bit format) 4-62 (32-bit format)	Get
15	Output Assembly PDO Offset	INT	0-102 (8-bit format) 0-51 (16-bit format) 0-26 (32-bit format)	Get
16	Control Flags	INT	Bit settings	Get

14.1.3. Common Services

The following table shows the common services for IO-Link port information object definition (71 hex).

Service Code	Implemented in Class	Implemented in Instance	Service Name
01 hex	Yes	Yes	Get_Attributes_All
0E hex	Yes	Yes	Get_Attribute_Single

14.1.4. Instance Attribute Definitions

These attributes provide access to the standard ISDU information blocks on the IO-Link devices. These ISDUs are read at IO-Link device initialization time and then provided once the IO-Link device is operational.

14.1.4.1. Attribute 1-Vendor Name

Data	Attribute 1 - Vendor Name Description
64 ASCII characters	Requested from ISDU block index 16, contains the Vendor Name description of the IO-Link device.

14.1.4.2. Attribute 2-Vendor Text

Data	Attribute 2 - Vendor Text Description
64 ASCII characters	Requested from ISDU block index 17, contains the Vendor Text description of the IO-Link device.

14.1.4.3. Attribute 3-Product Name

Data	Attribute 3 - Product Name Description
64 ASCII characters	Requested from ISDU block index 18, contains the Product Name description of the IO-Link device.

14.1.4.4. Attribute 4-Product ID

Data	Attribute 4 - Product ID Description
64 ASCII characters	Requested from ISDU block index 19, contains the Product ID description of the IO-Link device.

14.1.4.5. Attribute 5-Product Text

Data	Attribute 5 - Product Text Description
64 ASCII characters	Requested from ISDU block index 20, contains the Product Text description of the IO-Link device.

14.1.4.6. Attribute 6-Serial Number

Data	Attribute 6 - Serial Number Description
16 ASCII characters	Requested from ISDU block index 21, contains the Vendor Specific Serial Number of the IO-Link device.

14.1.4.7. Attribute 7-Hardware Revision

Data	Attribute 7 - Hardware Revision Description
64 ASCII characters	Requested from ISDU block index 22, contains the Hardware Revision of the IO-Link device.

14.1.4.8. Attribute 8-Firmware Revision

Data	Attribute 8 - Firmware Revision Description
64 ASCII characters	Requested from ISDU block index 23, contains the Firmware Revision of the IO-Link device.

14.1.4.9. Attribute 9-Device PDI Length

Data	Attribute 9 - Device PDI Length Description
INT (0-32)	Requested from ISDU block index 0, sub-index 5. Contains the number of PDI data bytes provided by the IO-Link device.

14.1.4.10. Attribute 10-Device PDO Length

Data	Attribute 10 - Device PDO Length Description
INT	Requested from ISDU block index 0, sub-index 6. Contains the number of PDO data bytes required by the IO-Link device.

14.1.4.11. Attribute 11-PDI Data Block Length

Data	Attribute 11 - PDI Data Block Length Description
INT	The configured PDI block length in units based on the configurable PDI data format (8-bit, 16-bit, 32-bit). This contains the PDI block header, (port status, auxiliary bit, event code) status and the PDI data.

14.1.4.12. Attribute 12-PDO Data Block Length

Data	Attribute 12 - PDO Data Block Length Description
INT	The configured PDO data block length in units based on the configurable PDO data format (8-bit, 16-bit, 32-bit). Depending on the configuration, this may include both the returned event code and the PDO data.

14.1.4.13. Attribute 13-Input Assembly PDI Offset

Data	Attribute 13 - Input Assembly PDI Offset Description
INT	Based from the start of the first Input Assembly instance, the PDI data block's offset for the corresponding port's PDI data block. This index is based on the configurable PDI data format (8-bit, 16-bit, 32-bit). To use this offset effectively, it is recommended to set IOLM PDI and PDO data as well as the Class 1 I/O connection all to the same data format.

14.1.4.14. Attribute 14-Input Assembly PDO Offset

Data	Attribute 14 - Input Assembly PDO Offset Description
INT	Based from the start of the first Input Assembly instance, the PDO data block's offset for the corresponding port's PDO data block. This index is based on the configurable PDO data format (8-bit, 16-bit, 32-bit). To use this offset effectively, it is recommended to set IOLM PDI and PDO data as well as the Class 1 I/O connection all to the same data format.

14.1.4.15. Attribute 15-Output Assembly PDO Offset

Data	Attribute 15 - Output Assembly PDO Offset Description
INT	Based from the start of the first Output Assembly instance, the PDO data block's offset for the corresponding port's PDO data block. This index is based on the configurable PDO data format (8-bit, 16-bit, 32-bit). To use this offset effectively, it is recommended to set IOLM PDI and PDO data as well as the Class 1 I/O connection all to the same data format.

14.1.4.16. Attribute 16-Control Flags

Data	Attribute 16 - Control Flags Description
INT (bit-mapped word)	<p>Bit 0 (01h): 1 = Indicates that the event code to clear is expected in the PDO block 0 = Indicates that the event code to clear is not expected in the PDO block.</p> <p>Bit 1 (02h): 1 = Indicates that the IO-Link device is SIO mode capable 0 = Indicates that the IO-Link device is not SIO mode capable</p> <p>Bits 2 (04h) 1 = Indicates that Class 1 Rx (receive PDI block) is enabled 0 = Indicates that Class 1 Rx (receive PDI block) is disabled</p> <p>Bit 3 (08h): 1 = Indicates that Class 1 Tx (transmit PDO) is enabled 0 = Indicates that Class 1 Tx (transmit PDO) is disabled</p> <p>Bit 4 (10h): 1 = Indicates that the digital output settings for DI and C/Q are expected in the PDO block 0 = Indicates that the digital output settings for DI and C/Q are not expected in the PDO block.</p> <p>Bit 5 -15: Reserved</p>

14.2. PDI (Process Data Input) Transfer Object Definition (72 hex)

The PDI Transfer object defines the attributes by which the PLC can request the PDI data block from the IOLM.

14.2.1. Class Attributes

The following table displays Class Attributes for the PDI Transfer Object Definition (72 hex).

Attribute ID	Name	Data Type	Data Value(s)	Access Rule
1	Revision	UINT	1	Get
2	Max Instance	UINT	1	Get
3	Num Instances	UINT	1	Get

14.2.2. Instance Attributes

The following table displays Instance Attributes for the PDI Transfer Object Definition (72 hex).

Attribute ID	Name	Data Type	Length	Data Values	Access Rule
1	Port 1 PDI data block	Array of BYTEs	4-36 bytes	0-255	Get
2	Port 2 PDI data block	Array of BYTEs	4-36 bytes	0-255	Get
3	Port 3 PDI data block	Array of BYTEs	4-36 bytes	0-255	Get
4	Port 4 PDI data block	Array of BYTEs	4-36 bytes	0-255	Get
8-Port Models Only:					
5	Port 5 PDI data block	Array of BYTEs	4-36 bytes	0-255	Get
6	Port 6 PDI data block	Array of BYTEs	4-36 bytes	0-255	Get
7	Port 7 PDI data block	Array of BYTEs	4-36 bytes	0-255	Get
8	Port 8 PDI data block	Array of BYTEs	4-36 bytes	0-255	Get

14.2.3. Common Services

The following table shows Common Services for the PDI Transfer Object Definition (72 hex).

Service Code	Implemented in Class	Implemented in Instance	Service Name
01 hex	Yes	Yes	Get_Attributes_All
0E hex	Yes	Yes	Get_Attribute_Single

14.2.4. Instance Attribute Definitions - Attribute 1 to 4-PDI Data Blocks

These attributes provide access to the PDI data blocks.

- Get Attribute Single requests return the PDI data block for a specific port.
- Get Attribute All requests return all PDI data blocks from the IOLM.

All PDI data is returned in the configured PDI format (8-bit, 16-bit or 32-bit). Refer to [14.2. PDI \(Process Data Input\) Transfer Object Definition \(72 hex\)](#) on Page 153 for a detailed explanation of the PDI data block.

14.3. PDO (Process Data Output) Transfer Object Definition (73 hex)

The PDO Transfer object defines the attributes by which the PLC can:

- Request the PDO data block from the IOLM.
- Write PDO data block to the IOLM.

14.3.1. Class Attributes

The following table displays the Class Attributes for the PDO Transfer Object Definition (73 hex).

Attribute ID	Name	Data Type	Data Value	Access Rule
1	Revision	UINT	1	Get
2	Max Instance	UINT	1	Get
3	Num Instances	UINT	1	Get

14.3.2. Instance Attributes

The following table displays the Instance Attributes for the PDO Transfer Object Definition (73 hex).

Attribute ID	Name	Data Type	Length	Data Value	Access Rule
1	Port 1 PDO data block	Array of BYTEs	0-36 bytes	0-255	Get/Set
2	Port 2 PDO data block	Array of BYTEs	0-36 bytes	0-255	Get/Set
3	Port 3 PDO data block	Array of BYTEs	0-36 bytes	0-255	Get/Set
4	Port 4 PDO data block	Array of BYTEs	0-36 bytes	0-255	Get/Set
8-Port Models Only:					
5	Port 5 PDO data block	Array of BYTEs	0-36 bytes	0-255	Get/Set
6	Port 6 PDO data block	Array of BYTEs	0-36 bytes	0-255	Get/Set
7	Port 7 PDO data block	Array of BYTEs	0-36 bytes	0-255	Get/Set
8	Port 8 PDO data block	Array of BYTEs	0-36 bytes	0-255	Get/Set

14.3.3. Common Services

The following table displays the Common Services for the PDO Transfer Object Definition (73 hex).

Service Code	Implemented in Class	Implemented in Instance	Service Name
01 hex	Yes	Yes	Get_Attributes_All
0E hex	Yes	Yes	Get_Attribute_Single
10 hex	No	Yes	Set_Attribute_Single
02 hex	No	Yes	Set_Attribute_All

14.3.4. Instance Attribute Definitions - Attribute 1 to 4-PDO Data Blocks

These attributes provide write access to the PDO data blocks.

- Get Attribute Single requests return the current PDO data block for a specific port.
- Get Attribute All requests return all current PDO data blocks from the IOLM.
- Set Attribute Single allows writing the PDO data to one IO-Link port on the IOLM.
- Set Attribute All messages allow writing of PDO data to all IO-Link ports on the IOLM.

All PDO data is received and returned in the configured PDO format (8-bit, 16-bit or 32-bit). Refer to [14.3. PDO \(Process Data Output\) Transfer Object Definition \(73 hex\)](#) on Page 154 for a detailed explanation of the PDO data block.

14.4. ISDU Read/Write Object Definition (74 hex)

The ISDU Read/Write object defines the attributes by which the PLC can:

- Send an ISDU request containing one or more read and/or write ISDU commands to an IO-Link device via the IOLM.
- Request the ISDU response(s) from the IOLM.
- Send both blocking and non-blocking ISDU requests.

Refer to the ISDU Handling chapter for a detailed description of the ISDU functionality.

14.4.1. Class Attributes

The following table shows the Class Attributes for the ISDU Read/Write Object Definition (74 hex).

Attribute ID	Name	Data Type	Data Value(s)	Access Rule
1	Revision	UINT	1	Get
2	Max Instance	UINT	4 (4-Port Models) 8 (8-Port Models)	Get
3	Num Instances	UINT	4 (4-Port Models) 8 (8-Port Models) <i>Note: Instance number determines IO-Link port on the IOLM.</i>	Get

14.4.2. Instance Attributes

The following table shows the Instance Attributes for the ISDU Read/Write Object Definition (74 hex).

Attribute ID	Name	Data Type	Data Value(s)	Access Rule
1	ISDU Response	ISDU response data block	0-255	Get
2	ISDU Read/Write Request	ISDU request data block	0-255	Set

14.4.3. Common Services

The following table shows the Common Services for the ISDU Read/Write Object Definition (74 hex).

Service Code	Implemented in Class	Implemented in Instance	Service Name
01 hex	Yes	No	Get_Attributes_All
0E hex	Yes	Yes	Get_Attribute_Single
10 hex	No	Yes	Set_Attribute_Single
02 hex	No	No	Set_Attribute_All

14.4.4. Object Specific Services

The following table shows the Object Specific Services for the ISDU Read/Write Object Definition (74 hex).

Service Code	Implemented in Class	Implemented in Instance	Service Name
4B hex	No	Yes	Blocking ISDU Request

The Blocking ISDU Request service allows one message instruction to both send an ISDU request and receive the response. Using this service causes the message to be active for several seconds.

14.4.5. Instance Attribute Definitions

The following attributes provide access to the ISDU blocks on the IO-Link devices.

14.4.5.1. Attribute 1-ISDU Read/Write Response (Non-Blocking only)

Get Attribute Single messages returns the ISDU response for a specific port through the IOLM. The response may need to be read multiple times until a response of Success, Failure, or Timed Out has been received.

14.4.5.2. Attribute 2-ISDU Read/Write Request (Non-blocking only)

Set Attribute Single messages can send read/write type ISDU requests to the IO-Link devices via the IOLM. The ISDU request message need be sent only once for each ISDU read/write request.

14.5. Identity Object (01hex, 1 instance)

The Identity Object provides identification of and general information about the IOLM.

14.5.1. Class Attributes

This table shows the Class Attributes for the Identity Object (01 hex, 1 Instance).

Attribute ID	Name	Data Type	Data Value(s)	Access Rule
1	Revision	UINT	1	Get
2	Max Class	UINT	1	Get
3	Max Instance	UINT	1	Get
6	Maximum Number Class Attribute	UINT	7	Get
7	Maximum Number Instance Attributes	UINT	7	Get

14.5.2. Instance Attributes

This table shows the Instance Attributes for the Identity Object (01 hex, 1 Instance).

Attribute ID	Name	Data Type	Data Value(s)	Access Rule
1	Vendor ID	UINT	909 (Control)	Get
2	Device Type	UINT	2B hex (Generic Device)	Get
3	Product Code	UINT	As defined by Control	Get
4	Revision (Product or Software release) <i>Structure of:</i> Major Revision Minor Revision	USINT USINT	1 to 127 1 to 255	Get
5	Status	WORD	See Below	Get
6	Serial Number	UDINT	1-FFFFFFFF hex	Get
7	Product Name <i>Structure of:</i> Name Length Name String	USINT STRING	Length of string See below	Get Get

14.5.3. Status Word

Refer to Page 52 of Volume 3.5 of the CIP Common Specification.

The following applies to the Identity Object status word for the IOLM.

Status Word Bit	Setting	Description
0	0	Ownership Flag. Does not apply to the IOLM.
1	0	Reserved.
2	0	IOLM is operating on the default configuration.
	1	The IOLM has a configuration other than the default configuration.
3	0	Reserved.
4-7	0101 (0x50)	Indicates that there is a major fault (either Bit 10 or Bit 11 is set).
	0100 (0x40)	Indicates the stored configuration is invalid.
	0011 (0x30)	Indicates the system is operational and there are no I/O (Class 1) connections.
	0110 (0x60)	Indicates the system is operational and there is at least one active I/O (Class 1) connection.
	0000	Indicates the system is not operational. It may be in any of the following states: <ul style="list-style-type: none"> • System startup. • Configuration in process. • Idle. • Critical (major) fault.
8	0	No recoverable minor fault. No error history entry reported within the last ten seconds.
	1	Recoverable minor fault. The IOLM has reported an error within the last ten seconds and a major fault has not been detected.
9	1	Unrecoverable minor fault. Does not apply to the IOLM.
10	0	No recoverable major fault.
	1	A major recoverable fault exists. This is a fault that the IOLM may be able to recover from by a system reset. If the system does not recover automatically, a system reset message or a power cycle of the IOLM may be required.
11	0	No major unrecoverable fault.
	1	A major unrecoverable fault has occurred in the IOLM. If the major fault is not corrected with a system reset or a power cycle, refer to the User Guide or call Control support.
12-15	0	Reserved.

14.5.4. Common Services

Service Code	Implemented in Class	Implemented in Instance	Service Name
01 hex	Yes	Yes	Get_Attribute_All
05 hex	No	Yes	Reset
0E hex	Yes	Yes	Get_Attribute_Single

14.6. Message Router Object (02 hex)

The Message Router Object provides a messaging connection point through which a Client may address a service to any object or instance residing in the physical device.

14.6.1. Class Attributes

This table displays the Class Attributes for the Message Router Object (02 hex).

Attribute ID	Name	Data Type	Data Value	Access Rule
1	Revision	UINT	1	Get
2	Max Class	UINT	1	Get
3	Max Instance	UINT	1	Get
4	Optional Attribute List	UINT	2	Get
5	Option Service List	UINT	1	Get
6	Maximum Number Class Attribute	UINT	7	Get
7	Maximum Number Instance Attribute	UINT	2	Get

14.6.2. Instance Attributes

This table displays the Instance Attributes for the Message Router Object (02 hex)

Attribute ID	Name	Data Type	Data Value(s)	Access Rule
1	Object List <i>Structure of:</i> Number	UINT	Number of supported standard class codes	Get
	Classes	Array of UINT	List of supported standard class codes	Get
2	Max Connections	UINT	128	Get

14.6.3. Common Services

This table displays the Common Services for the Message Router Object (02 hex)

Service Code	Implemented in Class	Implemented in Instance	Service Name
01 hex	Yes	No	Get_Attribute_All
0E hex	Yes	Yes	Get_Attribute_Single
0A hex	No	Yes	Multiple_Service_Req

14.7. Connection Manager Object (06 hex)

This object provides services for connection and connection-less communications.

This object has no supported attributes.

14.7.1. Class Attributes Object (06 hex)

The following table displays the Class Attributes for the Connection Manager Object (06 hex).

Attribute ID	Name	Data Type	Data Value(s)	Access Rule
1	Revision	UINT	1	Get
2	Max Class	UINT	1	Get
3	Max Instance	UINT	1	Get
4	Optional Attribute List	UINT	8	Get
6	Maximum number Class Attribute	UINT	7	Get
7	Maximum Number Instance Attributes	UINT	8	Get

14.7.2. Instance Attributes (02 hex)

This table displays the Instance Attributes for the Message Router Object (02 hex).

Attribute ID	Name	Data Type	Data Value(s)	Access Rule
1	Open Requests	UINT	0-0xffffffff	Set/Get
2	Open Format Rejects	UINT	0-0xffffffff	Set/Get
3	Open Resource Rejects	UINT	0-0xffffffff	Set/Get
4	Open Other Rejects	UINT	0-0xffffffff	Set/Get
5	Close Requests	UINT	0-0xffffffff	Set/Get
6	Close Format Requests	UINT	0-0xffffffff	Set/Get
7	Close Other Requests	UINT	0-0xffffffff	Set/Get
8	Connection Time Outs	UINT	0-0xffffffff	Set/Get

14.7.3. Common Services Object (06 hex)

This table displays the Common Services for the Connection Manager Object (06 hex).

Service Code	Implemented in Class	Implemented in Instance	Service Name
01 hex	Yes	Yes	Get_Attribute_All
02 hex	No	Yes	Set_Attribute_ALL
0E hex	Yes	Yes	Get_Attribute_Single
10 hex	No	Yes	Set_Attribute_Single
4E hex	N/A	N/A	Forward_Close
52 hex	N/A	N/A	Unconnected_Send
54 hex	N/A	N/A	Forward_Open
5A hex	N/A	N/A	Get_Connection_Owner
5B hex	N/A	N/A	Large_Forward_Open

14.8. Port Object (F4 hex-1 instance)

The Port Object enumerates the CIP ports present on the IOLM.

14.8.1. Class Attributes

This table illustrates the Class Attributes for the Port Object (F4 hex - 1 Instance)

Attribute ID	Name	Data Type	Data Value(s)	Access Rule
1	Revision	UINT	1	Get
2	Max Instance	UINT	1	Get
3	Num Instances	UINT	1	Get
6	Maximum Number Class Attributes	UINT	9	Get
7	Maximum Number Instance Attributes	UINT	7	Get
8	Entry Port	UINT	1	Get
9	All Ports	Array of UINT	[0]=0 [1]=0 [2] = 1 (Vendor Specific) [3] = 1 (Backplane) [4]=TCP_IP_PORT_TYPE (4) [5]=TCP_IP_PORT_NUMBER(2)	Get

14.8.2. Instance Attributes

This table illustrates the Instance Attributes for the Port Object (F4 hex - 1 Instance).

Attribute ID	Name	Data Type	Data Value(s)	Access Rule
1	Port Type	UINT	1	Get
2	Port Number	UINT	1	Get
3	Port Object <i>Structure of:</i> 16 bit word count in path Path	UINT Array of UINT	2 [0]=6420 hex [1]=0124 hex	Get Get
4	Port Name <i>Structure of:</i> String Length Port Name	USINT Array of USINT	10 "Backplane"	Get Get
7	Node Address	USINT[2]	0x10, 0x00	Get

This table illustrates the Instance Attributes for the Port Object (F4 hex - 2 Instance).

Attribute ID	Name	Data Type	Data Value(s)	Access Rule
1	Port Type	UINT	4 (TCP/IP)	Get
2	Port Number	UINT	2 (TCP/IP)	Get
3	Port Object <i>Structure of:</i> 16 bit word count in path Path	UINT Array of UINT	2 [0]=F520 hex [1]=0124 hex	Get Get
4	Port Name <i>Structure of:</i> String Length Port Name	USINT Array of USINT	17 "Ethernet/IP Port"	Get Get
7	Node Address	USINT[2]	0x10, 0x00	Get

14.8.3. Common Services

This table illustrates the Common Services for the Port Object (F4 hex - 1 Instance).

Service Code	Implemented in Class	Implemented in Instance	Service Name
01 hex	Yes	Yes	Get_Attribute_All
0E hex	Yes	Yes	Get_Attribute_Single

14.9. TCP Object (F5 hex-1 instance)

The TCP/IP Interface Object provides the mechanism to retrieve the TCP/IP attributes for the IOLM.

14.9.1. Class Attributes

This table shows the Class Attributes for the TCP Object (F5 hex - I Instance).

Attribute ID	Name	Data Type	Data Value	Access Rule
1	Revision	UINT	1	Get
2	Max Instance	UINT	1	Get
3	Num Instances	UINT	1	Get
4	Optional Attribute List	UINT	4	Get
6	Maximum Number Class Attribute	UINT	7	Get
7	Maximum Number Instance Attribute	UINT	9	Get

14.9.2. Instance Attributes

This table shows the Instance Attributes for the TCP Object (F5 hex - I Instance).

Attribute ID	Name	Data Type	Data Value(s)	Access Rule
1	Status	DWORD	0 = The Interface Configuration attribute has not been configured. 1 = The Interface Configuration attribute contains configuration obtained from DHCP or nonvolatile storage. 2 = The IP address member of the Interface Configuration attribute contains configuration obtained, in part, from the hardware rotary switch settings. <ul style="list-style-type: none"> • Upper 3 bytes from nonvolatile storage. • Least significant byte from rotary switches. 	Get
2	Configuration Capability	DWORD	34 hex (DHCP, Settable and Hardware) 04 hex = DHCP 10 hex = Settable 20 hex = Hardware configurable	Get

Attribute ID	Name	Data Type	Data Value(s)	Access Rule
3	Configuration Control	DWORD	Interface control Flags: 0 = The device shall use statically-assigned IP configuration values. 2 = The device shall obtain its interface configuration values via DHCP.	Set/Get
4	Physical Link Object <i>Structure of:</i> Path Size Path	UINT Array of USINT	2 [0]=20 hex [1]=F6 hex [2]=24 hex [3]=01 hex	Get
5	Interface Configuration <i>Structure of:</i> IP Address Network Mask Gateway Address Name Server Name Server 2 Domain Name Length Domain Name	UDINT UDINT UDINT UDINT UDINT UINT STRING	<IP address> <Network mask> <Gateway Address> <Name server> <Name server2> <Length of name> <Domain name>	Set/Get
6	Host Name <i>Structure of:</i> Host Name Length Host Name String	UINT STRING	0 to 15 <Default =IP NULL (0)>	Set/Get
8	TTL (Time-to-Live) value for IP multicast packets.	USINT	1 to 255 <Default = 1>	Set/Get
9	IP Multicast Address Configuration	<i>Struct of:</i> USINT - Alloc Control USINT - Reserved UINT - Num Mcast UDINT - Start Mcast Address	Alloc Control: 0 = Default Algorithm 1 = Configuration Num Mcast: 1 to 32 Start Mcast Address: 239.192.1.0 to 239.255.255.255	Set/Get

14.9.3. Common Services

This table shows the Common Services for the TCP Object (F5 hex - I Instance).

Service Code	Implemented in Class	Implemented in Instance	Service Name
01 hex	Yes	Yes	Get_Attribute_All
02 hex	No	Yes	Set_Attribute_All
0E hex	Yes	Yes	Get_Attribute_Single
10 hex	No	Yes	Set_Attribute_Single

14.10. Ethernet Link Object (F6 hex-1 instance)

The Ethernet Link Object maintains link-specific counters and status information for the Ethernet communications interface on the IOLM.

14.10.1. Class Attributes

This table displays the Class Attributes for the Ethernet Link Object (F6 hex - 1 Instance).

Attribute ID	Name	Data Type	Data Value(s)	Access Rule
1	Revision	UINT	3	Get
2	Max Instance	UINT	1	Get
3	Num Instances	UINT	1	Get
4	Optional Attribute List	UINT	4	Get
6	Maximum Number Class Attributes	UINT	7	Get
7	Maximum Number Instance Attributes	UINT	1	Get

14.10.2.Instance Attributes

This table displays the Instance Attributes for the Ethernet Link Object (F6 hex - 1 Instance).

Attribute ID	Name	Data Type	Data Value(s)	Access Rule
1	Interface speed (Current operational speed)	UDINT	10=10 Mbit 100=100 Mbit	Get
2	Interface Flags (Current operational status)	DWORD	Bit 0 =link status (0=inactive) (1=active) Bit 1=Half/Full Duplex (0=half duplex) (2=full duplex) Bits 2-4: 00 = negotiation in progress 01 = negotiation failed 02 = negotiation failed speed OK 03 = negotiation success	Get
3	Physical Address	Array of 6 USINT	MAC Address	Get
7	Interface Type	USINT	2 = Twisted Pair	Get
8	Interface State	USINT	1 = Interface is enabled and operational	Get
9	Admin State	USINT	1 = Interface enabled	Get
10	Interface Label	USINT16 Array of USINT	Length = 1 to 64 ASCII characters <Default = IP address in “xxx.xxx.xxx.xxx” format>	Get

14.10.3.Common Services

This table displays the Common Services for the Ethernet Link Object (F6 hex - 1 Instance)

Service Code	Implemented in Class	Implemented in Instance	Service Name
01 hex	Yes	Yes	Get_Attribute_All
0E hex	Yes	Yes	Get_Attribute_Single

14.11. PCCC Object (67 hex-1 instance)

The PCCC Object provides the ability to encapsulate and then transmit and receive PCCC messages between devices on an Ethernet/IP network. This object is used to communicate to MicroLogix, SLC 5/05 and PLC-5 PLCs over EtherNet/IP.

The PCCC Object does not support the following:

- Class Attributes
- Instance Attributes

14.11.1. Instances

The PCCC Object supports Instance 1.

14.11.2. Common Services

The following table displays the Common Services for the PCCC Object.

Service Code	Implemented in Class	Implemented in Instance	Service Name
4B hex	No	Yes	Execute_PCCC

14.11.3. Message Structure Execute_PCCC: Request Message

This table displays the message structure for the Execute_PCCC Request Message for the PCCC Object.

Name	Data Type	Description
Length	USINT	Length of requestor ID
Vendor	UINT	Vendor number of requestor
Serial Number	UDINT	ASA Serial number of requestor
CMD	USINT	Command byte
STS	USINT	0
TNSW	UINT	Transport word
FNC	USINT	Function Code.
PCCC_params	Array of USINT	CMD/FMC specific parameters

14.11.4. Message Structure Execute_PCCC: Response Message

This table displays the message structure for the Execute PCCC Response Message for the PCCC Object.

Name	Data Type	Description
Length	USINT	Length of requestor ID
Vendor	UINT	Vendor number of requestor
Serial Number	UDINT	ASA Serial number of requestor
CMD	USINT	Command byte
STS	USINT	Status Byte
TNSW	UINT	Transport word. Same value as request.
EXT_STS	USINT	Extended status. (If error)
PCCC_params	Array of USINT	CMD/FMC specific result data

14.11.5. Supported PCCC Command Types

The following table displays the Supported PCCC Command Types for the PCCC Object.

CMD	FNC	Description
0F hex	A2 hex	SLC 500 protected typed read with 3 address fields
0F hex	AA hex	SLC 500 protected typed write with 3 address fields

14.12. Assembly Object (For Class 1 Interface)

The EtherNet/IP specification requires that all Class 1 interfaces be provided through the Assembly Object interface. The Assembly Object interface is used to directly tie Vendor Specific objects to a standard interface, which the EtherNet/IP controller, or PLC, uses to communicate to the device.

For the IOLM, the Assembly Object corresponds to the PDI and PDO Transfer objects. Each instance of the Assembly Object corresponds to one or more of the PDI and/or PDO Transfer Object attributes.

The Assembly Object is linked to the Process IO vendor specific object, which provides access to the PDI and PDO data. The Assembly object defines the interface by which a Class 1 PLC or controller can:

- Request the PDI data block from the IOLM.
- Write the PDO data block to the IOLM.

14.12.1. Class Attributes

This table shows the Class Attributes for the Assembly Object for a Class 1 interface.

Attribute ID	Name	Data Type	Data Value(s)	Access Rule
1	Revision	UINT	1	Get
2	Max Instance	UINT	12 (4-Port Models) 24 (8-Port Models)	Get
3	Num Instances	UINT	12 (4-Port Models) 24 (8-Port Models)	Get

14.12.2. Instance Definitions (4-Port Models)

This table shows the Instance Definitions for the Assembly Object for a Class 1 interface for the 4-port models.

Assembly Instance Number	Description	Data Type	Data Values	Access Rule
101	PDI data blocks from Ports 1 to 4. PDO data blocks from ports 1-4	BYTE Array Valid read lengths: 1-288	0-255	Get
102	PDI data blocks from Ports 2 to 4. PDO data blocks from Ports 1-4	BYTE Array Valid read lengths: 1-252	0-255	Get
103	PDI data blocks from Ports 3 to 4. PDO data blocks from Ports 1-4	BYTE Array Valid read lengths: 1-216	0-255	Get
104	PDI data blocks from Port 4. PDO data blocks from Ports 1-4	BYTE Array Valid read lengths: 1-180	0-255	Get

Assembly Instance Number	Description	Data Type	Data Values	Access Rule
105	PDO data blocks from Ports 1-4	BYTE Array Valid read lengths: 0-144	0-255	Get
106	PDO data blocks from Ports 2-4	BYTE Array Valid read lengths: 0-108	0-255	Get
107	PDO data blocks from Ports 3-4	BYTE Array Valid read lengths: 0-72	0-255	Get
108	PDO data blocks from Port 4	BYTE Array Valid read lengths: 0-36	0-255	Get
109	PDO data blocks to Ports 1-4	BYTE Array Valid read lengths: 0-144	0-255	Set
110	PDO data blocks to Ports 2-4	BYTE Array Valid read lengths: 0-108	0-255	Set
111	PDO data blocks to Ports 3-4	BYTE Array Valid read lengths: 0-72	0-255	Set
112	PDO data blocks to Port 4	BYTE Array Valid read lengths: 0-36	0-255	Set

14.12.3.Instance Definitions (8-Port Models)

This table shows the Instance Definitions for the Assembly Object for a Class 1 interface for the 8-port models.

Assembly Instance Number	Description	Data Type	Data Values	Access Rule
101	PDI data blocks from Ports 1 to 8. PDO data blocks from ports 1-8	BYTE Array Valid read lengths: 1-576	0-255	Get
102	PDI data blocks from Ports 2 to 8. PDO data blocks from Ports 1-8	BYTE Array Valid read lengths: 1-540	0-255	Get

Assembly Instance Number	Description	Data Type	Data Values	Access Rule
103	PDI data blocks from Ports 3 to 8. PDO data blocks from Ports 1-8	BYTE Array Valid read lengths: 1-504	0-255	Get
104	PDI data blocks from Port 4-8. PDO data blocks from Ports 1-8	BYTE Array Valid read lengths: 1-468	0-255	Get
105	PDI data blocks from Ports 5-8 PDO data blocks from Ports 1-8	BYTE Array Valid read lengths: 0-432	0-255	Get
106	PDI data blocks from Ports 6 to 8. PDO data blocks from Ports 1-8	BYTE Array Valid read lengths: 0-396	0-255	Get
107	PDI data blocks from Ports 7 to 8. PDO data blocks from Ports 1-8	BYTE Array Valid read lengths: 0-360	0-255	Get
108	PDI data blocks from Port 8. PDO data blocks from Ports 1-8	BYTE Array Valid read lengths: 0-324	0-255	Get
109	PDO data blocks from Ports 1-8	BYTE Array Valid read lengths: 0-288	0-255	Get
110	PDO data blocks from Ports 2-8	BYTE Array Valid read lengths: 0-252	0-255	Get
111	PDO data blocks from Ports 3-8	BYTE Array Valid read lengths: 0-216	0-255	Get
112	PDO data blocks from Port 4-8	BYTE Array Valid read lengths: 0-180	0-255	Get
113	PDO data blocks from Ports 5-8	BYTE Array Valid read lengths: 0-144	0-255	Get
114	PDO data blocks from Ports 6-8	BYTE Array Valid read lengths: 0-108	0-255	Get
115	PDO data blocks from Ports 7-8	BYTE Array Valid read lengths: 0-72	0-255	Get

Assembly Instance Number	Description	Data Type	Data Values	Access Rule
116	PDO data blocks from Port 8	BYTE Array Valid read lengths: 0-36	0-255	Get
117	PDO data blocks to Ports 1-8	BYTE Array Valid read lengths: 0-288	0-255	Set
118	PDO data blocks to Ports 2-8	BYTE Array Valid read lengths: 0-252	0-255	Set
119	PDO data blocks to Ports 3-8	BYTE Array Valid read lengths: 0-216	0-255	Set
120	PDO data blocks to Ports 4-8	BYTE Array Valid read lengths: 0-180	0-255	Set
121	PDO data blocks to Ports 5-8	BYTE Array Valid read lengths: 0-144	0-255	Set
122	PDO data blocks to Ports 6-8	BYTE Array Valid read lengths: 0-108	0-255	Set
123	PDO data blocks to Ports 7-8	BYTE Array Valid read lengths: 0-72	0-255	Set
124	PDO data blocks to Port 8	BYTE Array Valid read lengths: 0-36	0-255	Set

14.12.4.Instance Attributes

This table shows the Instance Attributes for the Assembly Object for a Class 1 interface.

Attribute ID	Name	Data Type	Data Value(s)	Access Rule
3	Data	Array of BYTE	0-255	Get/Set
4	Data Length	UINT	Maximum number of bytes in attribute 3	Get

14.12.5.Common Services

This table shows the Common Services for the Assembly Object for a Class 1 interface.

Service Code	Implemented in Class	Implemented in Instance	Service Name
01 hex	Yes	No	Get_Attributes_All
0E hex	Yes	Yes	Get_Attribute_Single
10 hex	No	Yes	Set_Attribute_Single
02 hex	No	No	Set_Attribute_All

14.12.6.Instance Attribute Definitions: Attribute 3-Request/Write Data

Dependent on the instance number, this is either the PDI data block and/or the PDO data block.

14.12.7.Instance Attribute Definitions: Attribute 4-Data Length


This is the maximum data length for each Assembly instance.


14.12.8. Overview of Assembly Interface

The Assembly interface is designed to:

- Provide access to all Input and Output assemblies.
- Maximize flexibility for the PLC programmer.
- Minimize required PLC and IO-Link communication bandwidth.
- Be as easy to use as possible.

The following diagram illustrates the Assembly instances for a four port IOLM. There is one Assembly input and output instance assigned to each IO-Link port.





| Assembly Object (For Class 1 Interface) | Grouping of Assembly Instances | In order to minimize the number of required I/O connections, the input and output assembly instances are organized as follows. The Input Assembly instances are grouped into one continuous array with no gaps between the instances. The same is also true for Output Assembly

14.12.9. Grouping of Assembly Instances

14.12.9.1. In order to minimize the number of required I/O connections, the input and output assembly instances are organized as follows. The Input Assembly instances are grouped into one continuous array with no gaps between the instances. The same is also true for Output Assembly Instances. **4-Port Models**

Assembly Controller Access									
	Assembly Instance Number	Controller Port 1 Access		Controller Port 2 Access		Controller Port 3 Access		Controller Port 4 Access	
		Read (Input)	Write (Output)	Read (Input)	Write (Output)	Read (Input)	Write (Output)	Read (Input)	Write (Output)
Read (Input) Process Data Input	101 (Port 1)								
	102 (Port 2)								
	103 (Port 3)								
	104 (Port 4)								
Read (Input) Process Data Output	105 (Port 1)								
	106 (Port 2)								
	107 (Port 3)								
	108 (Port 4)								
Write (Output) Process Data Output	109 (Port 1)								
	110 (Port 2)								
	111 (Port 3)								
	112 (Port 4)								

Where:

- All accessible data can be read (input) and written (output) from one I/O connection.
- Controller Read (Input) access:
 - One or more input instances may be read with one I/O connection. (i.e. If addressing the instance 101, all input instances for both PDI and PDO data, 101 to 108 (for 4-port models), may be read in one connection.)
 - The length of the Read (Input) connection can range from 1 to the total length for all input instances.
 - Multiple controllers can read access to the Input Assembly instances at one time.
- Controller Write (Output) access:

- Only output instances may be written.
- One or more output instances may be written to with one connection.
- The length of the Write (Output) connection must be equal to the total length of the output instance(s).
- Only one controller may have write access to an output instance.

Note: In order to receive all PDI and PDO data in one Class 1 connection, it may be necessary to decrease the size of one or more PDI and/or PDO blocks via the embedded EtherNet/IP configuration web page.

14.12.9.2. 8-Port Models

Assembly Controller Access									
	Assembly Instance Number	Controller Port 1 Access		Controller Port 2 Access		Controller Port 3 Access		Controller Port 8 Access	
		Read (Input)	Write (Output)	Read (Input)	Write (Output)	Read (Input)	Write (Output)	Read (Input)	Write (Output)
Read (Input) Process Data Input	101 (Port 1)								
	102 (Port 2)								
	103 (Port 3)								
	104 (Port 4)								
	105 (Port 5)								
	106 (Port 6)								
	107 (Port 7)								
	108 (Port 8)								

Assembly Controller Access									
	Assembly Instance Number	Controller Port 1 Access		Controller Port 2 Access		Controller Port 3 Access		Controller Port 8 Access	
		Read (Input)	Write (Output)	Read (Input)	Write (Output)	Read (Input)	Write (Output)	Read (Input)	Write (Output)
Read (Input) Process Data Output	109 (Port 1)								
	110 (Port 2)								
	111 (Port 3)								
	112 (Port 4)								
	113 (Port 5)								
	114 (Port 6)								
	115 (Port 7)								
	116 (Port 8)								
Write (Output) Process Data Output	117 (Port 1)								
	118 (Port 2)								
	119 (Port 3)								
	120 (Port 4)								
	121 (Port 5)								
	122 (Port 6)								
	123 (Port 7)								
	124 (Port 8)								

Where:

- All accessible data can be read (input) and written (output) from one I/O connection.
- Controller Read (Input) access:
 - One or more input instances may be read with one I/O connection. (i.e. If addressing the instance 101, all input instances for both PDI and PDO data, 101 to 116 (for 8-port models), may be read in one connection.)

- The length of the Read (Input) connection can range from 1 to the total length for all input instances.
- Multiple controllers can read access to the Input Assembly instances at one time.
- Controller Write (Output) access:
 - Only output instances may be written.
 - One or more output instances may be written to with one connection.
 - The length of the Write (Output) connection must be equal to the total length of the output instance(s).
 - Only one controller may have write access to an output instance.

Note: *In order to receive all PDI and PDO data in one Class 1 connection, it may be necessary to decrease the size of one or more PDI and/or PDO blocks via the embedded EtherNet/IP configuration web page.*

Chapter 15. ControlLogix Family - Example PLC Programs

The example RSLogix 5000 PLC program is intended to provide basic working functionality:

- Through a Class 1 connection, provide a PDI data block with the IO-Link port status, auxiliary bit status and the PDI data.
- Through explicit messages, provide the ability to send both read and write ISDU requests to the IO-Link devices and receive the responses.
- Through explicit messages, provide the Device Information block.

Perform the following steps to run the example PLC program on your ControlLogix family PLC.

1. [Import the PLC program into RSLogix 5000](#) on Page 181
2. [Configure the Controller](#) on Page 181
3. [Add the EtherNet/IP Module Interface](#) on Page 183
4. [Configure the Ethernet Module](#) on Page 185
5. [Example PLC Program Operation](#) on Page 190
6. [User Defined Data Structures](#) on Page 193

15.1. Import the PLC program into RSLogix 5000


Both the standard .ACD file and library file have been provided. If your version of RSLogix 5000 will not open the .ACD file, then you will need to import the .L5K file.

15.2. Configure the Controller


The following are the controller settings used by Control to create the example PLC program.

Note: You may need to change the controller settings to match those of your PLC.


1. Open the RSLogix 5000 *Properties* page, click the *General* tab, enter the name, and click the **Change Controller** button.



2. Select the controller type and click **Ok**.



3. Set the **System Overhead Time Slice** to 50% and click **Ok**.




15.3. Add the EtherNet/IP Module Interface


If the controller has been changed or if the Ethernet module is different, you will need to add the EtherNet/IP module to the PLC program.

You can use this procedure to add the Ethernet module for your PLC in the corresponding slot.


1. Click **IO Configuration** and select **New Module**.




2. Select the **Ethernet Module Type** and click **OK**.



3. Right-click the **Ethernet Module** and select **Properties**.




4. Set the **Name**, **IP Address**, **Slot**, and **Revision** for your PLC and then click **OK**.




15.4. Configure the Ethernet Module

You can use these procedure as a guideline to configure the Ethernet module.

1. Right-click the **Ethernet interface module** and select **New Module**.




2. Select **ETHERNET-MODULE** Generic Ethernet Module and then click **OK**.




3. Enter the following parameters on the *Module Properties* pane.
 - a. Enter **IOLinkMstr** for the module **Name**.
 - b. If desired, enter a **Description** for the module.
 - c. Select **INPUT Data - INT (16-bit)** for the **Comm Format**.
 - d. Enter the IP Address of the IOLM module.
 - e. Enter the **Connection Parameters**:
 - Enter **101** for the **Input - Assembly Instance**.
 - Enter **72** for the **Input-Size** (input data length in 16-bit words).
 - Enter **254** for the **Output - Assembly Instance**.
 - If not already set to zero, enter **0** for the **Output-Size** (output data length).
 - Set the **Configuration - Assembly Instance** to **254**.
 - Set the **Configuration-Size** to **0**. (There are no configuration parameters).
 - f. Click **Next**.

Note: Your version of RSLogix 5000 may only allow one Class 1 connection to a specific EtherNet/IP device.



4. Enter the **Requested Packet Interval**.
 - a. Enter the interval value that best suits your system. For the example program, it is recommended to set the interval to **10 ms**.
 - b. Click **Ok**.



- Review the *Module Information* pane.




Note: This pane is not updated until the program is downloaded to the PLC and both PLC and IOLM are running.


- Under **Controller Tags**, observe the input tags created for the module. The example PLC program requires the **IOLinkMstr.I** (input data tag). The **IOLinkMstr.C** (configuration tag) is unused and can be ignored.

+ IOLinkMstr.C	{...}	{...}	AB:ETHERNET_...
+ IOLinkMstr.I	{...}	{...}	AB:ETHERNET_...

7. Under **MainProgram**, configure the **Communication Path** for all messages in all four **ProcessIoLinkPortN** subroutines.



8. Enter **IOLinkMstr** for the **Path** for all MSG instructions in all four subroutines.




9. Save the RSLogix5000 program.

10. Download to the PLC.

11. Start the PLC.


12. Click **MainRoutine** and review the RSLogix 5000 screen.




15.5. Example PLC Program Operation

The example PLC Program has been designed to operate with the default IOLM settings. It provides only Input Process data, but can be modified to also transmit PDO data to the IOLM. The PLC program performs the following tasks:

1. The **MainProgram** calls each of the four **ProcessIoLinkPortN** subroutines once every 100 ms. The frequency of these calls can be adjusted by changing the **CycleTimer** Preset value on rung 0.
2. Each **ProcessIoLinkPortN** subroutine is designed to handle all status and communication between the EtherNet/IP controller and one port on the IOLM.




a. Rung 0:



This rung monitors the interface to the IO-Link. It sets the flags that control a port initialization or shutdown.


b. Rung 1:



- Using the parameters received in the **PortInfo** tag, automatically indexes into the input data block.
- Copies the PDI data block into the **PrtN_RxPdiData** tag.
- Monitors the IO-Link port status.


- When the device status transitions to active (2): The **PrtN_Operational** tag is enabled (latched). This enables explicit message communication to the IOLM on Rungs 3-6.
- When the device status transitions to inactive (0) or initializing (1): The **PrtN_Shutdown** flag is enabled (latched) which causes a full shutdown of the port.

c. Rung 2:




This rung clears all flags necessary to cleanly shut down a port.

d. Rung 3:



When the **PrtN_SendBlkgISDUReq** tag is enabled, this rung sends an explicit message to the IOLM. This message starts a blocking ISDU process where the IOLM will not return a MSG response until all ISDU commands have been processed.


e. Rung 4-5:



- When the **PrtN_SendNonBlkgISDUReq** tag is enabled, this rung sends an explicit message to the IOLM.
 - This message starts a blocking ISDU process where the IOLM returns a MSG response immediately after verifying the ISDU request.
 - The IOLM then processes all ISDU commands within the request.
 - The IO-Link returns In-Process statuses until all ISDU commands have been processed.
- When the **PrtN_GetNonBlkgISDUResp** tag is enabled, this rung sends an explicit message to the IOLM to retrieve the ISDU response.
- Run 7 enables (latches) **GetNonBlkgISDUResp** as soon the MSG in Rung 4 has completed successfully.


- The ISDU response is retrieved until the response received indicates either a success (2) or error (3 or 4).

f. Rung 6:



- When the **PrtN_GetPortInfo** tag is enabled, this rung sends an explicit message to request the IO-Link port information block.
- The **PrtN_GetDevInfo** tag is enabled in Rung 0 whenever the IOLM connection status transitions from inactive to active.

g. Rung 7:




This rung monitors the various explicit messages for completion.

- Controls the non-blocking ISDU request process by enabling messages to retrieve the ISDU response until the request has completed.
- Sets the various flags when a get port information message has completed.

15.6. User Defined Data Structures


The example PLC program contains a number of User Defined Data Structures that may be used or modified as need be.



The following illustrations show a few of the User Defined Data Structure formats.


15.6.1. User Defined Structure Example 1

This displays the first example of a User Defined Data Structure.




15.6.2. User Defined Structure Example 2

This the second example of the User Defined Structure.




15.6.3. User Defined Structure Example 3

This is the third example of a User Defined Structure.



15.6.4. User Defined Structure Example 4

This is the fourth example of a User Defined Structure.



15.7. Example PLC Program Tag Definitions

The following tag definitions apply to the example IOLM PLC program.

Prt1_Operational	0		Decimal	BOOL
Prt1_PdiValid	0		Decimal	BOOL
Prt1_PortInfoValid	0		Decimal	BOOL
Prt1_SendBlkgSpduReq	0		Decimal	BOOL
Prt1_SendNonBlkgSpduReq	0		Decimal	BOOL
+ Prt1_GetInfoMsg	{...}	{...}		MESSAGE
+ Prt1_GetNonBlkgSpduRespMsg	{...}	{...}		MESSAGE
+ Prt1_MiscSpduReqs	{...}	{...}		ReqMiscSizedSpd...
+ Prt1_MiscSpduResps	{...}	{...}		RespMiscSizedSp...
+ Prt1_PortInfo	{...}	{...}		IoLinkPortInfoStruct
+ Prt1_RxPdiData	{...}	{...}		RxPdiDataStruct_...
+ Prt1_RxPdoData	{...}	{...}		PdoDataStructEv...
+ Prt1_SendBlkgSpduReqMsg	{...}	{...}		MESSAGE
+ Prt1_SendNonBlkgSpduReqMsg	{...}	{...}		MESSAGE
+ Prt1_SpduReqArray4Byte	{...}	{...}		Req4ByteSpduDa...
+ Prt1_SpduRespArray4Byte	{...}	{...}		Resp4ByteSpduD...
+ Prt1_SpduSingleReqData	{...}	{...}		ReqSingleSpduD...
+ Prt1_SpduSingleRespData	{...}	{...}		RespMaxSpduDat...
RepeatSpduRequests	0		Decimal	BOOL
Run	1		Decimal	BOOL

Tag Name	Value Range	Description
PrtN_Operational (init state = false)	BOOL	Controlled by the subroutine, the port operational status. The port must be operational before communication to the IO-Link port is allowed. <ul style="list-style-type: none"> 0 = false 1= true
PrtN_PdiValid (init state = false)	BOOL	Controlled by the subroutine, the PDI (Input Process data block) valid status. <ul style="list-style-type: none"> 0 = false 1= true
PrtN_PortInfoValid (init state = false)	BOOL	Controlled by the subroutine, the port information valid status. The port information must be retrieved before the device can become operational. <ul style="list-style-type: none"> 0 = false 1= true
PrtN_SendBlkgISDUReq (init state = false)	BOOL	<i>Controlled by the User or some other part of a PLC program</i> , directs the subroutine whether to send a blocking ISDU request to the IOLM. <ul style="list-style-type: none"> 0 = false (do not send message) 1= true (send message)
PrtN_SendNonBlkgISDUReq (init state = false)	BOOL	Controlled by the User or some other part of a PLC program, directs the subroutine whether to begin the non-blocking ISDU request process. If true, the subroutine sends a non-blocking ISDU request to the IOLM. <ul style="list-style-type: none"> 0 = false (do not send message) 1= true (send message)

Tag Name	Value Range	Description
PrtN_GetInfoMsg	MSG instruction parameters	Used by the subroutine, the message data used to get the port information from the IOLM. Note: <i>This tag should not be modified by any other part of the PLC program or through the RSLogix 5000 user interface.</i>
PrtN_GetNonBlkISDURespMsg	MSG instruction parameters	Used by the subroutine, the message data used to get the non-blocking ISDU response from the IOLM. Note: <i>This tag should not be modified by any other part of the PLC program or through the RSLogix 5000 user interface.</i>
PrtN_MiscISDUReqs	User defined data structure	Group of ISDU commands used as the default ISDU request format for the example PLC program. Can be modified by the user or other part of a PLC program. Refer to 15.7.3. PrtN MiscISDUReqs on Page 200 for more information.
PrtN_MiscISDUResps	User defined data structure	Group of ISDU command responses that is returned by the IOLM after and ISDU request completion. Must be in same overall format as PrtN_MiscISDUReqs . Refer to 15.7.4. PrtN MiscISDUResp on Page 201 for a complete description.
PrtN_PortInfo	User defined data structure	Contains common device information parameters automatically read by the IOLM during initialization of the IO-Link device interface.
PrtN_RxPdiData	User defined data structure	This tag contains the latest PDI data block as received from the Class 1 interface. It is updated with every ProcessIoLinkPortN subroutine call. Refer to 15.7.2. PrtN RxPdiData Definition on Page 199 for more information.
PrtN_SendBlkgISDUReqMsg	MSG instruction parameters	MSG instruction parameters used to send a blocking ISDU Request message. Note: <i>This tag should not be modified by any other part of the PLC program or through the RSLogix 5000 user interface.</i>
PrtN_SendNonBlkISDUReqMsg	MSG instruction parameters	MSG instruction parameters used to send a non-blocking ISDU Request message. Note: <i>This tag should not be modified by any other part of the PLC program or through the RSLogix 5000 user interface.</i>
PrtN_ISDUReqArray4Byte	ISDU command parameters	An alternative ISDU request format.
PrtN_ISDURespArray4Byte	ISDU response parameters	An alternative ISDU response format. Must be used with PrtN_ISDUReqArray4Byte .
PrtN_ISDUSingleReqData	ISDU command parameters	An alternative ISDU request format.

Tag Name	Value Range	Description
PrtN_ISDUSingleRespData	ISDU response parameters	An alternative ISDU response format. Must be used with PrtN_ISDUReqArray4Byte .
RepeatISDURequests	BOOL	If enabled, instructs all subroutines to repeat any ISDU requests upon completion. Intended for testing purposes. May be enabled by end user.
Run	BOOL	MainProgram only. Allows the ProcessIoLinkPortN subroutine calls if enabled (1). Prevents the ProcessIoLinkPortN subroutine calls if disabled (0).

15.7.1. PrtN_DeviceInformation Definition

The IOLM requests this information from the IO-Link device during the IO-Link device initialization process. It is then made accessible via explicit messages. The example PLC program automatically requests this information block when the device status transitions to active.

Parameter Name	Data	Description
VendorName	64 ASCII characters	Requested from ISDU data block index 16, contains the Vendor Name description of the IO-Link device.
VendorText	64 ASCII characters	Requested from ISDU data block index 17, contains the Vendor Text description of the IO-Link device.
ProductName	64 ASCII characters	Requested from ISDU data block index 18, contains the Product Name description of the IO-Link device.
ProductId	64 ASCII characters	Requested from ISDU data block index 19, contains the Product ID description of the IO-Link device.
ProductText	64 ASCII characters	Requested from ISDU data block index 20, contains the Product Text description of the IO-Link device.
SerialNum	16 ASCII characters	Requested from ISDU data block index 21, contains the Vendor Specific Serial Number of the IO-Link device.
HardwareRev	64 ASCII characters	Requested from ISDU data block index 22, contains the Hardware Revision of the IO-Link device.
FirmwareRev	64 ASCII characters	Requested from ISDU data block index 23, contains the Firmware Revision of the IO-Link device.
DevicePdiLength	INT	Length of valid PDI data from IO-Link device or port (if not in I/O Link mode).
DevicePdoLength	INT	Length of valid PDO data that can accepted by the IO-Link device or port (if not in I/O Link mode).
PdiBlockLength	INT	The configured PDI data block length. This includes the header bytes and any PDI data.
PdoBlockLength	INT	The configured PDO data block length. This includes the header bytes and any PDO data.
InputRxPdiOffset	INT	Provides the index into the Class 1 I/O input data received from the IOLM. The index corresponds to the configured PDI data format of the port on the IOLM. Used to automatically index into the input data and retrieve the PDI data block.

Parameter Name	Data	Description
InputRxPdoOffset	INT	Provides the index into the Class 1 I/O input data received from the IOLM. The index corresponds to the configured PDO data format of the port on the IOLM. Used to automatically index into the input data and retrieve the PDO data block.
OutputPdoOffset	INT	Provides the index into the Class 1 I/O output data sent to the IOLM. The index corresponds to the configured PDO data format of the port on the IOLM. Used to automatically index into the output data and transmit the PDO data block.
ControlFlags	Bit-mapped INT	<p>Bit 0 (01h):</p> <p>1 =Indicates that the event code to clear is expected in the PDO block</p> <p>0 =Indicates that the event code to clear is not expected in the PDO block. The PDO data block only contains PDO data.</p> <p>Bit 1 (02h):</p> <p>1 =Indicates that the IO-Link device is SIO mode capable</p> <p>0 =Indicates that the IO-Link device is not SIO mode capable</p>

15.7.2. PrtN_RxPdiData Definition

The PDI data block is received from the IOLM over a Class 1 I/O connection. The data is then copied into the PDI data block in each subroutine.

[-] Prt1_RxPdiData	{...}	{...}		RxPdiDataStruct_...
+ Prt1_RxPdiData.statusAuxBits	16#0000		Hex	INT
+ Prt1_RxPdiData.event	16#0000		Hex	INT
[-] Prt1_RxPdiData.pdiData	{...}	{...}	Hex	INT[16]
+ Prt1_RxPdiData.pdiData[0]	16#0000		Hex	INT
+ Prt1_RxPdiData.pdiData[1]	16#0000		Hex	INT
+ Prt1_RxPdiData.pdiData[2]	16#0000		Hex	INT
+ Prt1_RxPdiData.pdiData[3]	16#0000		Hex	INT
+ Prt1_RxPdiData.pdiData[4]	16#0000		Hex	INT
+ Prt1_RxPdiData.pdiData[5]	16#0000		Hex	INT
+ Prt1_RxPdiData.pdiData[6]	16#0000		Hex	INT
+ Prt1_RxPdiData.pdiData[7]	16#0000		Hex	INT
+ Prt1_RxPdiData.pdiData[8]	16#0000		Hex	INT
+ Prt1_RxPdiData.pdiData[9]	16#0000		Hex	INT
+ Prt1_RxPdiData.pdiData[10]	16#0000		Hex	INT
+ Prt1_RxPdiData.pdiData[11]	16#0000		Hex	INT
+ Prt1_RxPdiData.pdiData[12]	16#0000		Hex	INT
+ Prt1_RxPdiData.pdiData[13]	16#0000		Hex	INT
+ Prt1_RxPdiData.pdiData[14]	16#0000		Hex	INT
+ Prt1_RxPdiData.pdiData[15]	16#0000		Hex	INT

Refer to section on Input Process data format.

15.7.3. PrtN_MiscISDUReqs

This tag is used as the default ISDU request. It contains several ISDU commands that are configured to read standard ISDU blocks supported by most IO-Link devices. This User Defined Structure may be changed to include any set of ISDU commands. The only constraint is that the entire Request and response must be no larger than the maximum MSG instruction payload of 500 bytes.

[-] Prt1_MiscSpduReqs	{...}	{...}		ReqMiscSizedSpd...
[-] Prt1_MiscSpduReqs.SpduReq1	{...}	{...}		Req16ByteSpduD...
+ Prt1_MiscSpduReqs.SpduReq1.byteSwap	16#00		Hex	SINT
+ Prt1_MiscSpduReqs.SpduReq1.rdWrType	16#31		Hex	SINT
+ Prt1_MiscSpduReqs.SpduReq1.index	0		Decimal	INT
+ Prt1_MiscSpduReqs.SpduReq1.subindex	0		Decimal	INT
+ Prt1_MiscSpduReqs.SpduReq1.dataLen...	16		Decimal	INT
+ Prt1_MiscSpduReqs.SpduReq1.data	{...}	{...}	Hex	SINT[16]
[-] Prt1_MiscSpduReqs.SpduReq2	{...}	{...}		Req64ByteSpduD...
+ Prt1_MiscSpduReqs.SpduReq2.byteSwap	16#00		Hex	SINT
+ Prt1_MiscSpduReqs.SpduReq2.rdWrType	16#51		Hex	SINT
+ Prt1_MiscSpduReqs.SpduReq2.index	16		Decimal	INT
+ Prt1_MiscSpduReqs.SpduReq2.subindex	0		Decimal	INT
+ Prt1_MiscSpduReqs.SpduReq2.dataLen...	64		Decimal	INT
+ Prt1_MiscSpduReqs.SpduReq2.data	{...}	{...}	Hex	SINT[64]
[-] Prt1_MiscSpduReqs.SpduReq3	{...}	{...}		Req32ByteSpduD...
+ Prt1_MiscSpduReqs.SpduReq3.byteSwap	16#00		Hex	SINT
+ Prt1_MiscSpduReqs.SpduReq3.rdWrType	16#41		Hex	SINT
+ Prt1_MiscSpduReqs.SpduReq3.index	18		Decimal	INT
+ Prt1_MiscSpduReqs.SpduReq3.subindex	0		Decimal	INT
+ Prt1_MiscSpduReqs.SpduReq3.dataLen...	32		Decimal	INT
+ Prt1_MiscSpduReqs.SpduReq3.data	{...}	{...}	Hex	SINT[32]
[-] Prt1_MiscSpduReqs.SpduReq4	{...}	{...}		Req16ByteSpduD...
+ Prt1_MiscSpduReqs.SpduReq4.byteSwap	16#00		Hex	SINT
+ Prt1_MiscSpduReqs.SpduReq4.rdWrType	16#31		Hex	SINT
+ Prt1_MiscSpduReqs.SpduReq4.index	21		Decimal	INT
+ Prt1_MiscSpduReqs.SpduReq4.subindex	0		Decimal	INT
+ Prt1_MiscSpduReqs.SpduReq4.dataLen...	16		Decimal	INT
+ Prt1_MiscSpduReqs.SpduReq4.data	{...}	{...}	Hex	SINT[16]
[-] Prt1_MiscSpduReqs.SpduReq5	{...}	{...}		Req4ByteSpduDa...
+ Prt1_MiscSpduReqs.SpduReq5.byteSwap	16#00		Hex	SINT
+ Prt1_MiscSpduReqs.SpduReq5.rdWrType	16#11		Hex	SINT
+ Prt1_MiscSpduReqs.SpduReq5.index	22		Decimal	INT
+ Prt1_MiscSpduReqs.SpduReq5.subindex	0		Decimal	INT
+ Prt1_MiscSpduReqs.SpduReq5.dataLen...	4		Decimal	INT
+ Prt1_MiscSpduReqs.SpduReq5.data	{...}	{...}	Hex	SINT[4]
[-] Prt1_MiscSpduReqs.SpduReq6	{...}	{...}		Req8ByteSpduDa...
+ Prt1_MiscSpduReqs.SpduReq6.byteSwap	16#00		Hex	SINT
+ Prt1_MiscSpduReqs.SpduReq6.rdWrType	16#21		Hex	SINT
+ Prt1_MiscSpduReqs.SpduReq6.index	23		Decimal	INT
+ Prt1_MiscSpduReqs.SpduReq6.subindex	0		Decimal	INT
+ Prt1_MiscSpduReqs.SpduReq6.dataLen...	8		Decimal	INT
+ Prt1_MiscSpduReqs.SpduReq6.data	{...}	{...}	Hex	SINT[8]

15.7.4. PrtN_MiscISDUResp


This tag contains the response to the ISDU request. It must be of the same size and structure as the request structure.

- Prt1_MiscSpduResps	{...}	{...}		RespMiscSizedSp...
- Prt1_MiscSpduResps.SpduReq1	{...}	{...}		Resp16ByteSpdu...
+ Prt1_MiscSpduResps.SpduReq1.respSt...	16#00		Hex	SINT
+ Prt1_MiscSpduResps.SpduReq1.rdWrT...	16#00		Hex	SINT
+ Prt1_MiscSpduResps.SpduReq1.index	0		Decimal	INT
+ Prt1_MiscSpduResps.SpduReq1.subindex	0		Decimal	INT
+ Prt1_MiscSpduResps.SpduReq1.dataLe...	0		Decimal	INT
+ Prt1_MiscSpduResps.SpduReq1.data	{...}	{...}	Hex	SINT[16]
+ Prt1_MiscSpduResps.SpduReq2	{...}	{...}		Resp64ByteSpdu...
+ Prt1_MiscSpduResps.SpduReq3	{...}	{...}		Resp32ByteSpdu...
+ Prt1_MiscSpduResps.SpduReq4	{...}	{...}		Resp16ByteSpdu...
+ Prt1_MiscSpduResps.SpduReq5	{...}	{...}		Req4ByteSpduDa...
+ Prt1_MiscSpduResps.SpduReq6	{...}	{...}		Req8ByteSpduDa...

15.7.5. Using Other ISDU Request/Response Command Formats

Other ISDU request/response formats may be used instead of the default request command set. The following steps demonstrate how to change the ISDU request/response formats:

1. If one ISDU request/response is required, create a new request and response tag with any of the defined ISDU User Defined structures. The one requirement is that the request and response formats must be the same. For example, if a 16 byte nested format is use for the request, then a 16 byte nested response structure must be used.
2. If multiple ISDU requests of the same nested lengths are required, created request and response arrays of the same User Defined format.
3. If multiple ISDU requests of different nested lengths are required, create new User Defined Data Structures for the request and response containing user defined command structures. Then create tags using the new user Defined data structures. You may also want to modify the **ReqMiscSizedISDUCmds** and **RespMiscSizedISDUCmds** User Defined data structures.
4. Modify the appropriate **MSG** instruction settings:



- a. Change the **Source Element** to that of the new ISDU request tag.
- b. Change the **Source Length** to that of the new **Source Element**. That information is often displayed on the User Defined Structure definition pane.
- c. Change the **Destination** to that of the new response tag.

Chapter 16. SLC/PLC-5/MicroLogix Interface

The IOLM provides support for the SLC, PLC-5 and MicroLogix PLCs. The following features are supported:

- Rx PDI data, both Polling and Write-to-File modes.
- Tx PDO data, both PLC-Writes and Read-From-File modes.
- PCCC based messages transferred by means of the PCCC CIP object, including:
 - SLC Typed Read Message
 - SLC Typed Write Message
 - PLC-5 Typed Read Message (Logical ASCII address format)
 - PLC-5 Typed Write Message (Logical ASCII address format)
- Receive, transmit and statistics data.
- Standard PLC-5/SLC file naming conventions.
- Controlled message rate to the PLC when operating in the Write-to-File receive method. This is accomplished by setting the **Maximum PLC Update Rate**.

The primary differences between the PLC-5/SLC interface and the ControlLogix interfaces are:

- Since the PLC-5 and SLC PLCs operate on a file memory system, the PLC-5/SLC interface provides Write-to-File and Read-from-File communication methods in place of Write-to-Tag and Read-from-Tag communication methods. The Write-to-File methods operate in a very similar manner to the Write-to-Tag method available for the ControlLogix family of PLCs.
- Polling is performed through the PLC-5/SLC specific messages instead of accessing the Serial Port Data Transfer object.
- When configuring the IOLM to operate in Write-to-File or Read-from-File, enter the file name starting with an N (i.e. N10:0).

Note: *While ControlLogix PLCs support the SLC and PLC-5 messages, using those messages on ControlLogix PLCs is not recommended due to data size and performance considerations.*

16.1. Requirements

Your PLC-5/SLC/MicroLogix PLC must support:

- MultiHop
- ControlLogix devices
- EtherNet/IP

The following tables list PLCs that support EtherNet/IP and the required firmware version for each PLC.

Note: *Older versions of the PLC firmware may or may not provide EtherNet/IP functionality. You must verify that an older version of the PLC firmware provides EtherNet/IP functionality before you can use it with IOLM.*

If you need to update your PLC firmware, contact your Rockwell distributor.

16.2. PLC-5 and SLC 5/05 PLC Requirements

The following PLCs support Ethernet/IP.

16.2.1. SLC 5/05

Models	Catalog Numbers	Required Firmware Version for Ethernet/IP
SLC 5/05	1747-L551 1747-L552 1747-L553	Series A: FRN 5 or later Series C: FRN 3 or later

Reference: SLC 500 Instruction Set, Appendix A Firmware History, Rockwell Publication 1747-RM001D-EN-P.

16.2.2. PLC-5

Models	Catalog Numbers	Required Firmware Version for Ethernet/IP
Ethernet PLC-5	1785-L20E 1785-L40E 1785-L80E	<p><i>Base Ethernet/IP functionality:</i></p> <ul style="list-style-type: none"> Series C: Revision N and later Series D: Revision E and later Series E: Revision D and later <p><i>Full Ethernet/IP Compliance:</i></p> <ul style="list-style-type: none"> Series C: Revision R and later Series D: Revision H and later Series E: Revision G and later
Enhanced PLC-5 Attached to Ethernet Module	1785-L11B 1785-L20B 1785-L30B 1785-L40B 1785-L40L 1785-L60B 1785-L60L 1785-L80B	<p>Series B: Revision N.1 or later</p> <p>Series C: Revision N or later</p> <p>Series D: Revision E or later</p> <p>Series E: Revision D or later</p>
ControlNet PLC-5 Attached to Ethernet Module	1785-L20C15 1785-L40C15 1785-L60C15 1785-L80C15	<p>Series C: Revision N or later</p> <p>Series D: Revision E or later</p> <p>Series E: Revision D or later</p> <p>All revisions</p>
Ethernet Module	1785-Enet	<p>Series B:</p> <ul style="list-style-type: none"> Base Ethernet/IP functionality: All Revisions Full Ethernet/IP Compliance: Revision D and later

References:

- Enhanced & Ethernet PLC-5 Series and Enhancement History, Rockwell Publication G19099
- ControlNet Processor Phase, Series, and Enhancement History, Rockwell Publication G19102
- PLC-5 Programmable Controllers System Selection Guide, Rockwell Publication 1785-SG001A-EN-P

- Ethernet Interface Module Series B, Revision D Product Release Notes, Rockwell Publication 1785-RN191E-EN-P

Note: Older versions of firmware may or may not provide Ethernet/IP functionality.

16.3. PLC-5 and SLC Messages

The following PCCC messages are supported for the PLC-5 and SLC 5/05 PLCs.

Message Type	PCCC Message ID	Maximum Message Size	Maximum Serial Packet Size
SLC Typed Read	162	CLX: 242 SINTs (121 INTs) SLC: 206 SINTs (103 INTs) PLC-5: 240 SINTs (120 INTs)	CLX: 238 SINTs (119 INTs) SLC: 202 SINTs (101 INTs) PLC-5: 236 SINTs (118 INTs)
SLC Typed Write	170	CLX: 220 SINTs (110 INTs) SLC: 206 SINTs (103 INTs) PLC-5: 238 SINTs (119 INTs)	216 SINTs (108 INTs) SLC: 202 SINTs (101 INTs) PLC-5: 234 SINTs (117 INTs)
PLC-5 Typed Read	104	CLX: 234 SINTs (117 INTs) SLC: 252 SINTs (126 INTs) PLC-5: 238 SINTs (119 INTs)	230 SINTs (115 INTs) SLC: 248 SINTs (124 INTs) PLC-5: 234 SINTs (117 INTs)
PLC-5 Typed Write	103	CLX: 226 SINTs (113 INTs) SLC: 226 SINTs (113 INTs) PLC-5: 224 SINTs (112 INTs)	CLX: 222 SINTs (111 INTs) SLC: 222 SINTs (111 INTs) PLC-5: 220 SINTs (110 INTs)

The Receive Port Information is provided in one continuous file. The following file addresses are used to retrieve the various parameters.

	IO-Link Port 1	IO-Link Port 2	IO-Link Port 3	IO-Link Port 4	Access	Length
PDI Data Block	N10:0	N20:0	N30:0	N40:0	Read-Only	Configurable per port Note: See below for details.
Receive PDO Data Block	N11:0	N21:0	N31:0	N41:0	Read-Only	Configurable per port Note: See below for details.
Transmit PDO Data Block	N12:0	N22:0	N32:0	N42:0	Write-Only	Configurable per port Note: See below for details.
Receive ISDU Response	N13:0	N23:0	N33:0	N43:0	Read-Only	4 INTs to Max Msg Size
Transmit ISDU Request	N14:0	N24:0	N34:0	N44:0	Write-Only	4 INTs to Max Msg Size
<i>Port Information Block (Continuous Block)</i>						464 Bytes (232 INTs)
Vendor Name	N15:0	N25:0	N35:0	N45:0	Read	64 Chars (32 INTs)
Vendor Text	N15:32	N25:32	N35:32	N45:32	Read	64 Chars (32 INTs)
Product Name	N15:64	N25:64	N35:64	N45:64	Read	64 Chars (32 INTs)

	IO-Link Port 1	IO-Link Port 2	IO-Link Port 3	IO-Link Port 4	Access	Length
Product ID	N15:96	N25:96	N35:96	N45:96	Read	64 Chars (32 INTs)
Product Text	N15:128	N25:128	N35:128	N45:128	Read	64 Chars (32 INTs)
Serial Number	N15:160	N25:160	N35:160	N45:160	Read	16 Chars (8 INTs)
Hardware Revision	N15:168	N25:168	N35:168	N45:168	Read	64 Chars (32 INTs)
Firmware Revision	N15:200	N25:200	N35:200	N45:200	Read	64 Chars (32 INTs)

This table provides information for 8-port models.

	IO-Link Port 5	IO-Link Port 6	IO-Link Port 7	IO-Link Port 8	Access	Length
PDI Data Block	N50:0	N60:0	N70:0	N80:0	Read-Only	Configurable per port Note: See below for details.
Receive PDO Data Block	N51:0	N61:0	N71:0	N81:0	Read-Only	Configurable per port Note: See below for details.
Transmit PDO Data Block	N52:0	N62:0	N72:0	N82:0	Write-Only	Configurable per port Note: See below for details.
Receive ISDU Response	N53:0	N63:0	N73:0	N83:0	Read-Only	4 INTs to Max Msg Size
Transmit ISDU Request	N54:0	N64:0	N74:0	N84:0	Write-Only	4 INTs to Max Msg Size
<i>Port Information Block (Continuous Block)</i>						464 Bytes (232 INTs)
Vendor Name	N55:0	N65:0	N75:0	N85:0	Read	64 Chars (32 INTs)
Vendor Text	N55:32	N65:32	N75:32	N85:32	Read	64 Chars (32 INTs)
Product Name	N55:64	N65:64	N75:64	N85:64	Read	64 Chars (32 INTs)
Product ID	N55:96	N65:96	N75:96	N85:96	Read	64 Chars (32 INTs)
Product Text	N55:128	N65:128	N75:128	N85:128	Read	64 Chars (32 INTs)
Serial Number	N55:160	N65:160	N75:160	N85:160	Read	16 Chars (8 INTs)
Hardware Revision	N55:168	N65:168	N75:168	N85:168	Read	64 Chars (32 INTs)
Firmware Revision	N55:200	N65:200	N75:200	N85:200	Read	64 Chars (32 INTs)

16.4. Process Data (PDI and PDO) Access via PCCC Messages

The process data has been grouped together in order to minimize the number of PCCC messages required to interface to the IOLM. The PDI and PDO data for multiple ports can be received or transmitted by one message.

	File Number	Controller Port 1 Access		Controller Port 2 Access		Controller Port 3 Access		Controller Port 4 Access	
		Read (Input)	Write (Output)	Read (Input)	Write (Output)	Read (Input)	Write (Output)	Read (Input)	Write (Output)
Read (Input) Process Data Input (Ports 5-8 Only Supported on 8-Port Models)	N10:0 (Port 1)								
	N20:0 (Port 2)								
	N30:0 (Port 3)								
	N40:0 (Port 4)								
	N50:0 (Port 5)								
	N60:0 (Port 6)								
	N70:0 (Port 7)								
	N80:0 (Port 8)								
Read (Input) Process Data Output (Ports 5-8 Only Supported on 8-Port Models)	N11:0 (Port 1)								
	N21:0 (Port 2)								
	N31:0 (Port 3)								
	N41:0 (Port 4)								
	N51:0 (Port 5)								
	N61:0 (Port 6)								
	N71:0 (Port 7)								
	N81:0 (Port 8)								

	File Number	Controller Port 1 Access		Controller Port 2 Access		Controller Port 3 Access		Controller Port 4 Access	
		Read (Input)	Write (Output)	Read (Input)	Write (Output)	Read (Input)	Write (Output)	Read (Input)	Write (Output)
Write (Output) Process Data Output (Ports 5-8 Only Supported on 8-Port Models)	N12:0 (Port 1)								
	N22:0 (Port 2)								
	N32:0 (Port 3)								
	N42:0 (Port 4)								
	N52:0 (Port 5)								
	N62:0 (Port 6)								
	N72:0 (Port 7)								
	N82:0 (Port 8)								

PCCC Read/Write Access *where*:

- All PDI data can be read with one PCCC read message.
- All PDO data can be read with one PCCC read message.
- All PDO data can be written with one PCCC write message.
- Controller Read access:
 - The PDI data from one or more ports may be read with one message. (That is, if addressing Port 1, N10:0, ports one to four may be read in one message.)
 - The PDO data from one or more ports may be read with one message. (That is, if addressing Port 1, N11:0, ports one to four may be read in one message.)
 - Partial PDI and PDO data reads are allowed.
 - The length of the Read message can range from 1 to the total, configured PDI or PDO length for all ports starting at the addressed port.
- Controller Write (Output) access:
 - Only PDO data may be written.
 - The PDO data for one or more ports may be written with one message.
 - Partial PDO data writes are not allowed.
 - The length of the Write message must be equal to the total of the configured PDO lengths for all ports to be written. The one exception is that the data length of the last port to be written must be equal to or greater than the device PDO length for that port.

Chapter 17. EDS Files

This chapter discusses the following topics:

- *Downloading the Files*
- *Configuring RSLinx*
- [Adding EDS Files to Rockwell Software](#) on Page 210

17.1. Overview

You do not need to add the IOLM to Rockwell software for normal IOLM-to-PLC communications. However, you can easily add the IOLM and its associated Electronic Data Sheet (EDS) files to Rockwell software.

The files named **IOLM_*.ico** are icon files and files named **IOLM_dd_NNNN-x.xx.eds** are ODVA electronic data sheet files where:

- **dd** is the model name
- **NNNN** is the product ID number
- **x.xx** is the version number

17.2. Downloading the Files

You can download the EDS files provided for the IOLM from the [download site](#).

17.3. Configuring RSLinx

You can use these steps to add the IOLM to RSLinx.

1. Open RSLinx.
2. If there is not an EtherNet/IP driver configured, use these steps:
 - a. Under **Communications**, select **Configure Drivers**.
 - b. Under **Available Drivers**, select **EtherNet/IP Driver**.
 - c. Select **Add New**.
 - d. Use the default driver name or type your own driver name and click **OK** to continue.
3. Select the adapter of the network card used to communicate with the IOLM and click **Ok**.
4. Select **RSWho** to verify that **RSLinx** can communicate with the IOLM.

Note: A yellow question mark appears by the IOLM(s) in the RSWho window when the associated EDS file(s) are not installed.

17.4. Adding EDS Files to Rockwell Software

You can use this procedure to add the EDS files to Rockwell software.

1. Open the **EDS Hardware Installation Tool**. (Select **Start > All Programs > Rockwell Software > RSLinx Tools**.)
2. Click **Add**.
3. Click **Register a directory of EDS files**.
4. Browse to the **Control/EtherNetIP** directory and click **Next** to continue.
5. Verify that there is a green check beside each EDS file name and select **Next** to continue.
6. Click **Finish** to exit.

If RSLinx does not display the device after adding IOLM and the EDS files to RSLinx, perform the following procedure:

1. Select **File > Exit and Shutdown** to exit and shutdown RSLinx.
2. Remove the following files from your hard drive:
 - `\Program Files\Rockwell Software\RSCOMMON\Harmony.hrc`
 - `\Program Files\Rockwell Software\RSCOMMON\Harmony.rsh`
3. Restart RSLinx. The IOLM or IOLMs should now appear with the associated icon or icons.


Chapter 18. Modbus/TCP Interface

The IOLM provides a slave-mode Modbus/TCP interface that provides:

- Read access to the Process Data Input (PDI) and Process Data Output (PDO) data blocks for each IO-Link port
- Write access to the PDO data block for each IO-Link port
- Write access to send ISDU requests to each IO-Link port
- Read access to ISDU responses from each IO-Link port
- Read access to the Port Information Block for each IO-Link port

The Modbus interface is disabled by default. To enable Modbus/TCP:

1. Click **Configuration | Modbus/TCP**.
2. Click the **EDIT** button in the **Modbus/TCP Configuration** table.
3. Select **enable** in the **Modbus Enable** drop box.
4. Click the **SAVE** button.



Refer to [Chapter 13. Functionality Descriptions](#) on Page 125 for detailed information about process data block descriptions, event handling, and ISDU handling.

- [13.1.1.1. Input Process Data Block-8 Bit Data Format](#) on Page 126
- [13.1.1.2. Input Process Data Block-16 Bit Data Format](#) on Page 127
- [13.1.1.3. Input Process Data Block-32 Bit Data Format](#) on Page 127
- [13.1.2.1. Output Process Data Block-8 Bit \(SINT\) Data Format](#) on Page 128
- [13.1.2.2. Output Process Data Block-16 Bit \(INT\) Data Format](#) on Page 129
- [13.1.2.3. Output Process Data Block-32 Bit \(DINT\) Data Format](#) on Page 129
- [13.2. Event Handling](#) on Page 130
- [13.3. ISDU Handling](#) on Page 134

18.1. Modbus Function Codes

This table shows the supported Modbus function codes.

Message Type	Function Code	Maximum Message Size
Read Holding Registers	3	250 Bytes (125 Words)
Write Single Register	6	2 bytes (1 Word)
Write Multiple Registers	16 (10 hex)	246 Bytes (123 Words)
Read/Write Holding Registers	23 (17 hex)	Write: 242 bytes (121 Words) Read: 246 bytes (123 Words)

18.2. Modbus Address Definitions

The address definitions for the Modbus/TCP interface are shown in the following tables.

	IO-Link Port 1	IO-Link Port 2	IO-Link Port 3	IO-Link Port 4	Access	Length
Multiple Port PDI Data Block(s)	999 (Base 0) 1000 (Base 1)	1999 (Base 0) 2000 (Base 1)	2999 (Base 0) 3000 (Base 1)	3999 (Base 0) 4000 (Base 1)	Read-Only	Configurable per port (s)
Port Specific PDI Data Block	1000 (Base 0) 1001 (Base 1)	2000 (Base 0) 2001 (Base 1)	3000 (Base 0) 3001 (Base 1)	4000 (Base 0) 4001 (Base 1)	Read-Only	Configurable per port
Multiple Port PDO Data Block(s)	1049 (Base 0) 1050 (Base 1)	2049 (Base 0) 2050 (Base 1)	3049 (Base 0) 3050 (Base 1)	4049 (Base 0) 4050 (Base 1)	Read/Write	Configurable per port(s)
Port Specific PDO Data Block	1050 (Base 0) 1051 (Base 1)	2050 (Base 0) 2051 (Base 1)	3050 (Base 0) 3051 (Base 1)	4050 (Base 0) 4051 (Base 1)	Read/Write	Configurable per port
Receive ISDU Response	1100 (Base 0) 1101 (Base 1)	2100 (Base 0) 2101 (Base 1)	3100 (Base 0) 3101 (Base 1)	4100 (Base 0) 4101 (Base 1)	Read-Only	4 to 125 Words
Transmit ISDU Request	1300 (Base 0) 1301 (Base 1)	2300 (Base 0) 2301 (Base 1)	3300 (Base 0) 3301 (Base 1)	4300 (Base 0) 4301 (Base 1)	Write-Only	4 to 123 Words
<i>Port Information Block (Continuous Block)</i>						232 Words
Vendor Name	1500 (Base 0) 1501 (Base 1)	2500 (Base 0) 2501 (Base 1)	3500 (Base 0) 3501 (Base 1)	4500 (Base 0) 4501 (Base 1)	Read-Only	64 Chars 32 Words

	IO-Link Port 1	IO-Link Port 2	IO-Link Port 3	IO-Link Port 4	Access	Length
Vendor Text	1532 (Base 0)	2532 (Base 0)	3532 (Base 0)	4532 (Base 0)	Read-Only	64 Chars
	1533 (Base 1)	2533 (Base 1)	3533 (Base 1)	4533 (Base 1)		32 Words
Product Name	1564 (Base 0)	2564 (Base 0)	3564 (Base 0)	4564 (Base 0)	Read-Only	64 Chars
	1565 (Base 1)	2565 (Base 1)	3565 (Base 1)	4565 (Base 1)		32 Words
Product Id	1596 (Base 0)	2596 (Base 0)	3596 (Base 0)	4596 (Base 0)	Read-Only	64 Chars
	1597 (Base 1)	2597 (Base 1)	3597 (Base 1)	4597 (Base 1)		32 Words
Product Text	1628 (Base 0)	2628 (Base 0)	3628 (Base 0)	4628 (Base 0)	Read-Only	64 Chars
	1629 (Base 1)	2629 (Base 1)	3629 (Base 1)	4629 (Base 1)		32 Words
Serial Number	1660 (Base 0)	2660 (Base 0)	3660 (Base 0)	4660 (Base 0)	Read-Only	16 Chars
	1661 (Base 1)	2661 (Base 1)	3661 (Base 1)	4661 (Base 1)		8 Words
Hardware Revision	1668 (Base 0)	2668 (Base 0)	3668 (Base 0)	4668 (Base 0)	Read-Only	64 Chars
	1669 (Base 1)	2669 (Base 1)	3669 (Base 1)	4669 (Base 1)		32 Words
Firmware Revision	1700 (Base 0)	2700 (Base 0)	3700 (Base 0)	4700 (Base 0)	Read-Only	64 Chars
	1701 (Base 1)	2701 (Base 1)	3701 (Base 1)	4701 (Base 1)		32 Words
Device PDI Length	1732 (Base 0)	2732 (Base 0)	3732 (Base 0)	4732 (Base 0)	Read-Only	1 Word
	1733 (Base 1)	2733 (Base 1)	3733 (Base 1)	4733 (Base 1)		
Device PDO Length	1733 (Base 0)	2733 (Base 0)	3733 (Base 0)	4733 (Base 0)	Read-Only	1 Word
	1734 (Base 1)	2734 (Base 1)	3734 (Base 1)	4734 (Base 1)		

18.2.1.8-Port Models

	IO-Link Port 5	IO-Link Port 6	IO-Link Port 7	IO-Link Port 8	Access	Length
Multiple Port PDI Data Block(s)	4999 (Base 0)	5999 (Base 0)	6999 (Base 0)	7999 (Base 0)	Read-Only	Configurable per port (s)
	5000 (Base 1)	6000 (Base 1)	7000 (Base 1)	8000 (Base 1)		
Port Specific PDI Data Block	5000 (Base 0)	6000 (Base 0)	7000 (Base 0)	8000 (Base 0)	Read-Only	Configurable per port
	5001 (Base 1)	6001 (Base 1)	7001 (Base 1)	8001 (Base 1)		
Multiple Port PDO Data Block(s)	5049 (Base 0)	6049 (Base 0)	7049 (Base 0)	8049 (Base 0)	Read/Write	Configurable per port(s)
	5050 (Base 1)	6050 (Base 1)	7050 (Base 1)	8050 (Base 1)		

	IO-Link Port 5	IO-Link Port 6	IO-Link Port 7	IO-Link Port 8	Access	Length
Port Specific PDO Data Block	5050 (Base 0) 5051 (Base 1)	6050 (Base 0) 6051 (Base 1)	7050 (Base 0) 7051 (Base 1)	8050 (Base 0) 8051 (Base 1)	Read/Write	Configurable per port
Receive ISDU Response	5100 (Base 0) 5101 (Base 1)	6100 (Base 0) 6101 (Base 1)	7100 (Base 0) 7101 (Base 1)	8100 (Base 0) 8101 (Base 1)	Read-Only	4 to 125 Words
Transmit ISDU Request	5300 (Base 0) 5301 (Base 1)	6300 (Base 0) 6301 (Base 1)	7300 (Base 0) 7301 (Base 1)	8300 (Base 0) 8301 (Base 1)	Write-Only	4 to 123 Words
<i>Port Information Block (Continuous Block)</i>						232 Words
Vendor Name	5500 (Base 0) 5501 (Base 1)	6500 (Base 0) 6501 (Base 1)	7500 (Base 0) 7501 (Base 1)	8500 (Base 0) 8501 (Base 1)	Read-Only	64 Chars 32 Words
Vendor Text	5532 (Base 0) 5533 (Base 1)	6532 (Base 0) 6533 (Base 1)	7532 (Base 0) 7533 (Base 1)	8532 (Base 0) 8533 (Base 1)	Read-Only	64 Chars 32 Words
Product Name	5564 (Base 0) 5565 (Base 1)	6564 (Base 0) 6565 (Base 1)	7564 (Base 0) 7565 (Base 1)	8564 (Base 0) 8565 (Base 1)	Read-Only	64 Chars 32 Words
Product Id	5596 (Base 0) 5597 (Base 1)	6596 (Base 0) 6597 (Base 1)	7596 (Base 0) 7597 (Base 1)	8596 (Base 0) 8597 (Base 1)	Read-Only	64 Chars 32 Words
Product Text	5628 (Base 0) 5629 (Base 1)	6628 (Base 0) 6629 (Base 1)	7628 (Base 0) 7629 (Base 1)	8628 (Base 0) 8629 (Base 1)	Read-Only	64 Chars 32 Words
Serial Number	5660 (Base 0) 5661 (Base 1)	6660 (Base 0) 6661 (Base 1)	7660 (Base 0) 7661 (Base 1)	8660 (Base 0) 8661 (Base 1)	Read-Only	16 Chars 8 Words
Hardware Revision	5668 (Base 0) 5669 (Base 1)	6668 (Base 0) 6669 (Base 1)	7668 (Base 0) 7669 (Base 1)	8668 (Base 0) 8669 (Base 1)	Read-Only	64 Chars 32 Words
Firmware Revision	5700 (Base 0) 5701 (Base 1)	6700 (Base 0) 6701 (Base 1)	7700 (Base 0) 7701 (Base 1)	8700 (Base 0) 8701 (Base 1)	Read-Only	64 Chars 32 Words
Device PDI Length	5732 (Base 0) 5733 (Base 1)	6732 (Base 0) 6733 (Base 1)	7732 (Base 0) 7733 (Base 1)	8732 (Base 0) 8733 (Base 1)	Read-Only	1 Word
Device PDO Length	5733 (Base 0) 5734 (Base 1)	6733 (Base 0) 6734 (Base 1)	7733 (Base 0) 7734 (Base 1)	8733 (Base 0) 8734 (Base 1)	Read-Only	1 Word

18.3. Multiple Port Process Data (PDI/PDO) Access via Modbus/TCP

The process data has been grouped together in order to minimize the number of Modbus messages required to interface to the IO-Link master. The PDI and PDO data for multiple ports can be received or transmitted by one message.

	Modbus Holding Register Address (Base 1)	Controller Port 1 Access		Controller Port 2 Access		Controller Port 3 Access		Controller Port 4 Access	
		Read (Input)	Write (Output)	Read (Input)	Write (Output)	Read (Input)	Write (Output)	Read (Input)	Write (Output)
Read (Input) Process Data Input	1000 (Port 1)								
	2000 (Port 2)								
	3000 (Port 3)								
	4000 (Port 4)								
Read (Input) Process Data Output	1050 (Port 1)								
	2050 (Port 2)								
	3050 (Port 3)								
	4050 (Port 4)								
Write (Output) Process Data Output	1050 (Port 1)								
	2050 (Port 2)								
	3050 (Port 3)								
	4050 (Port 4)								

	Modbus Holding Register Address (Base 1)	Controller Port 5 Access		Controller Port 6 Access		Controller Port 7 Access		Controller Port 8 Access	
		Read (Input)	Write (Output)	Read (Input)	Write (Output)	Read (Input)	Write (Output)	Read (Input)	Write (Output)
Read (Input) Process Data Input	5000 (Port 5)								
	6000 (Port 6)								
	7000 (Port 7)								
	8000 (Port 8)								
Read (Input) Process Data Output	5050 (Port 5)								
	6050 (Port 6)								
	7050 (Port 7)								
	8050 (Port 8)								
Write (Output) Process Data Output	5050 (Port 5)								
	6050 (Port 6)								
	7050 (Port 7)								
	8050 (Port 8)								

To receive and transmit process data for eight ports, it may be necessary to adjust the size of the PDI/PDO data blocks.

Modbus Read/Write Access *where*:

- All PDI data can be read with one Modbus Read Holding Registers message.
- All PDO data can be read with one Modbus Read Holding Registers read message.
- All PDO data can be written with one Modbus Write Holding Registers message.
- Controller Read access:

- The PDI data from one or more ports may be read with one message. (i.e.: If addressing port 1, at address 1000, ports one to four may be read in one message.)
- The PDO data from one or more ports may be read with one message. (i.e.: If addressing port 1, at address 1050, ports one to four may be read in one message.)
- Partial PDI and PDO data reads are allowed.
- The length of the Read message can range from 1 to the total, configured PDI or PDO length for all ports starting at the addressed port.
- Controller Write (Output) access:
 - Only PDO data may be written.
 - The PDO data for one or more ports may be written with one Write Holding Registers message.
 - Partial PDO data writes are not allowed.
 - The length of the Write message must be equal to the total of the configured PDO lengths for all ports to be written. The one exception is that the data length of the last port to be written must be equal to or greater than the device PDO length for that port.

Chapter 19. Troubleshooting and Technical Support

This chapter provides the following information:

- *Troubleshooting*
- [IOLM LEDs](#) on Page 220
- [Contacting Technical Support](#) on Page 223
- [Using Log Files](#) on Page 224

19.1. Troubleshooting

Before contacting Technical Support, you may want to try the following:


- Check to make sure LEDs are not reporting an issue using [IOLM LEDs](#) on Page 220.
- Verify that the network IP address, subnet mask, and gateway are correct and appropriate for the network. Make sure that the IP address programmed into the IO-Link Master matches the unique reserved IP configured address assigned by the system administrator.
 - If using DHCP, the host system needs to provide the subnet mask. The gateway is optional and is not required for a purely local network.
 - Remember that if the rotary switches on the IOLM 4-EIP and 8-EIP are set to a non-default position, the rotary switches override the lower 3 digits (8 bits) of the static IP address configured in the **Network** page or in PortVision DX.
 - Verify that the Ethernet hub and any other network devices between the system and the IO-Link Master are powered up and operating.
- Verify that you are using the correct types of cables on the correct connectors and that all cables are connected securely.
- Disconnect and re-connect the IO-Link device, or optionally, use the **Configuration | IO-Link** page to **Reset** the port, and then set the **Port Mode** back to **IOLink**.
- Reboot or power cycle the IOLM. Use the **Advanced | Software** page to reboot the IOLM.
- Verify that the **Port Mode** matches the device, for example: IO-Link, Digital In, Digital Out, or Reset (port is disabled).
- If you are receiving an error that indicates a hardware fault, check the **Configuration | IO-Link** page for the port experiencing the fault.
 - Check the settings for the **Automatic Upload Enable** and **Automatic Download Enable** options. If the Vendor ID or Device ID of the attached device does not match, a hardware fault is generated.
 - Make sure if the port contains data storage that the Vendor ID and Device ID match the device attached to the port. If it does not, **CLEAR** the data storage or move the device to another port.
 - Check the Device Validation and Data Validation settings. If the attached device does not meet these settings, a hardware fault is issued.
- Open the IO-Link Master web interface and review the following pages to see if you can locate a problem:
 - **IO-Link Diagnostics**
 - **Digital I/O Diagnostics (IOLM DR-8-EIP)**
 - **EtherNet/IP Diagnostics**
 - **Modbus/TCP Diagnostics**
 - **OPC UA Diagnostics**
- If you have a spare IO-Link Master, try replacing the IO-Link Master.

19.2. IOLM LEDs

The following tables provide LED descriptions:


19.2.1. IOLM 4-EIP

The IOLM 4-EIP (4-port IP67 model) provides these LEDs.

IOLM 4-EIP LEDs	
PWR	A lit green PWR LED indicates that the IO-Link Master is powered.
MOD (Module Status)	<p>The MOD LED provides the following information:</p> <ul style="list-style-type: none"> • Off = No module status • Flashing green and red = Self-test • Flashing green = Standby – not configured • Steady green = Operational • Flashing red = Minor recoverable fault - check the EtherNet/IP Diagnostics page to locate the issue • Steady red = Major unrecoverable fault
NET (Network Status)	<p>The NET LED provides the following information:</p> <ul style="list-style-type: none"> • Off = No IP address • Green/Red/Flashing = Self-test • Green/Flashing = An IP address is configured, but no CIP connections are established, and an Exclusive Owner connection has not timed out • Green/Steady = Active EtherNet/IP or active Modbus connection and no EtherNet/IP connection time-outs • Red/Flashing = One or more EtherNet/IP connection time-outs • Red/Steady = Duplicate IP address on network
1-4 	<p>This LED provides the following information about the IO-Link port.</p> <ul style="list-style-type: none"> • Off: SIO mode - signal is low or disabled • Yellow: SIO mode - signal is high • Red/Blinking: Hardware fault - make sure that configured IO-Link settings on the port do not conflict with the device that is attached: <ul style="list-style-type: none"> - Automatic Upload and/or Download is enabled and it is not the same device. - Device Validation Mode is enabled and it is not the correct device. - Data Validation Mode is enabled but there is an error. • Green/Solid: An IO-Link device is connected and communicating • Green/Blinking: Searching for IO-Link devices
Ports 1-4 DI	<p>The DI LED indicates digital input on DI (Pin 2).</p> <ul style="list-style-type: none"> • Off: DI signal is low or disconnected • Yellow: DI signal is high
EIP 1 EIP 2	<p>The EIP LEDs provide the following information:</p> <ul style="list-style-type: none"> • Green /Blinking = Activity • Green/lit LED = Link established

19.2.2. IOLM 8-EIP

The IOLM 8-EIP (8-port IP67 model) provides these LEDs.

IOLM 8-EIP LEDs	
US	A lit green US LED indicates that the IO-Link Master is powered.
UA	A lit green UA LED indicates that the IO-Link Master is powered.
MS (Module Status)	<p>The MS LED provides the following information:</p> <ul style="list-style-type: none"> • Off = No module status • Flashing green and red = Self-test • Flashing green = Standby – not configured • Steady green = Operational • Flashing red = Minor recoverable fault - check the EtherNet/IP Diagnostics page to locate the issue • Steady red = Major unrecoverable fault
NS (Network)	<p>The NS LED provides the following information:</p> <ul style="list-style-type: none"> • Off = No IP address • Green/Red/Flashing = Self-test • Green/Flashing = An IP address is configured, but no CIP connections are established, and an Exclusive Owner connection has not timed out • Green/Steady = Active EtherNet/IP or Modbus connection and no EtherNet/IP connection time-outs • Red/Flashing = One or more EtherNet/IP connection time-outs • Red/Steady = Duplicate IP address on network
1-8 	<p>This LED provides the following information about the IO-Link port.</p> <ul style="list-style-type: none"> • Off: SIO mode - signal is low or disabled • Yellow: SIO mode - signal is high • Red/Blinking: Hardware fault - make sure that configured IO-Link settings on the port do not conflict with the device that is attached: <ul style="list-style-type: none"> - Automatic Upload and/or Download is enabled and it is not the same device. - Device Validation Mode is enabled and it is not the correct device. - Data Validation Mode is enabled but there is an error. • Green/Solid: An IO-Link device is connected and communicating • Green/Blinking: Searching for IO-Link devices
Port 1-4 DI	<p>The DI LED indicates digital input on DI (Pin 2).</p> <ul style="list-style-type: none"> • Off: DI signal is low or disconnected • Yellow: DI signal is high
ETH 1 ETH 2	<p>The ETH LEDs provide the following information:</p> <ul style="list-style-type: none"> • Green lit LED = Link • Green blinking LED = Activity


19.2.3. IOLM DR-8-EIP

The IOLM DR-8-EIP (8-port IP20 DIN rail model) provides these LEDs.

IOLM DR-8-EIP LEDs	
PWR	A lit green PWR LED indicates that the IO-Link Master is powered.
MS (Module Status)	<p>The MS LED provides the following information:</p> <ul style="list-style-type: none"> • Off = No module status • Flashing green and red = Self-test • Flashing green = Standby – not configured • Steady green = Operational • Flashing red = Minor recoverable fault - check the EtherNet/IP Diagnostics page to locate the issue • Steady red = Major unrecoverable fault
NS (Network Status)	<p>The NS LED provides the following information:</p> <ul style="list-style-type: none"> • Off = No IP address • Green/Red/Flashing = Self-test • Green/Flashing = An IP address is configured, but no CIP connections are established, and an Exclusive Owner connection has not timed out • Green/Steady = Active EtherNet/IP or Modbus connection and no EtherNet/IP connection time-outs • Red/Flashing = One or more EtherNet/IP connection time-outs • Red/Steady = Duplicate IP address on network
Port 1-8	<p>This LED provides the following information about the IO-Link port.</p> <ul style="list-style-type: none"> • Off: SIO mode - signal is low or disabled • Yellow: SIO mode - signal is high • Red/Blinking: Hardware fault - make sure that configured IO-Link settings on the port do not conflict with the device that is attached: <ul style="list-style-type: none"> - Automatic Upload and/or Download is enabled and it is not the same device. - Device Validation Mode is enabled and it is not the correct device. - Data Validation Mode is enabled but there is an error. • Green/Solid: An IO-Link device is connected and communicating • Green/Blinking: Searching for IO-Link devices
D1-4	<p>This LED indicates digital input.</p> <ul style="list-style-type: none"> • Off: DI signal is low or disconnected • On: DI signal is high
Dual Ethernet Ports	<p>The Ethernet LEDs provide the following information:</p> <ul style="list-style-type: none"> • Green/Solid = Link • Yellow/Solid = Activity

19.3. Contacting Technical Support

You may want to access the **Help/SUPPORT** page when you call Technical Support, as they may request the information displayed on the **SUPPORT** page.



Control Technical Support is available from 8:00AM to 6:00PM (CST), Monday through Friday, excluding major USA holidays.

Contact	Information
Phone	763.957.6000
Downloads	ftp://ftp.control.com/html/default.htm http://downloads.control.com/html/default.htm
Web Site	http://www.control.com

19.4. Using Log Files

The IO-Link Master provides four different log files that you can view, export, or clear:

- **Syslog** (system log) displays line-by-line activity records.
- **dmesg** displays Linux kernel messages.
- **top** displays which programs are using most of the memory and CPU.
- **ps** displays the running programs
- All log files start up automatically during the startup cycle. Each log file has a size limit of 100KB.

Note: Typically, log files are intended to be used by Technical Support in the event there is a problem.


You can use the following procedures to:

- [View a Log File](#)
- [Clear a Log File](#) on Page 226
- [Export a Log File](#) on Page 225

19.4.1. View a Log File

Use this procedure to view a log file.


1. Open the IO-Link Master web interface using one of these method:
 - From PortVision DX, highlight the IO-Link Master and click the **Webpage** button or right-click the IO-Link Master in the *Device List* pane and click **Webpage**.
 - Open your browser and enter the IP address of the IO-Link Master.
2. Click **Advanced** and then **LOG FILES**.
3. Select the log file type from the drop-list.
4. Optionally, click the **REFRESH** button to get the latest information.
5. Optionally, [export](#) the log file.



19.4.2. Export a Log File

Use the following procedure to export a log file.

1. Open the IO-Link Master web interface using one of these method:
 - From PortVision DX, highlight the IO-Link Master and click the **Webpage** button or right-click the IO-Link Master in the *Device List* pane and click **Webpage**.
 - Open your browser and enter the IP address of the IO-Link Master.
2. Click **Advanced** and then **LOG FILES**.
3. Select the log file type from the drop-list.
4. Click the **EXPORT** button.
5. Click the **Save** button drop-list and click **Save** to save it to your user folder or **Save as** to browse to or create a new folder in which to place the log file.




6. Depending on your operating system, you may need to close the pop-up window.

19.4.3. Clear a Log File

Use this procedure to clear a log file.

1. Open the IO-Link Master web interface using one of these method:
 - From PortVision DX, highlight the IO-Link Master and click the **Webpage** button or right-click the IO-Link Master in the *Device List* pane and click **Webpage**.
 - Open your browser and enter the IP address of the IO-Link Master.
2. Click **Advanced** and then **LOG FILES**.
3. Optionally, [export](#) the log file.
4. Select the log file type from the drop-list.
5. Click the **CLEAR** button.



The log file automatically starts logging the latest information.