



# PCI Hardware Installation Guide

## Product Overview

---

The RocketPort® PCI series multiport serial card fits into the PCI slot of a personal computer, and uses a 36 MHz processor that is specifically designed to process asynchronous serial communications.

The RocketPort PCI series uses Application Specific Integrated Circuits (ASICs) technology to replace most hardware components, including:

- The processor
- A serial controller
- Bus interface logic and other miscellaneous logic


You can install up to four RocketPort PCI cards in one PC, with up to 128 additional serial ports, and you can install any combination of PCI-bus and ISA-bus RocketPort cards.

**Product List and Pictures**

This *Hardware Installation* document discusses the following serial controllers.

Type	Ports	Interface Type
RJ45	4	This model has four female RJ45 jacks on the mounting bracket for RS-232 serial port connections. Cables are not included.
DB9/DB25 Quadcable	4	Includes a fanout cable with four standard DB25 or DB9 connectors for RS-232 serial port connections. Quadcables have the capability to be 8-port cards with an 8-port interface cable. Some drivers view the 4-port as an 8-port card.
8	8	Requires one 8-port interface module.
RJ11	8	This model has eight female RJ11 jacks on the mounting bracket for RS-232 serial port connections. The RJ11 does not support NT RAS (Remote Access Server), as it lacks the full set of modem control lines. Cables are not included.
DB9/DB25/RJ45 Octacable	8	Includes a fanout cable with eight standard DB25, DB9, or RJ45 connectors for RS-232 serial port connections.
DB25/RM16-RJ45	16	Requires one 16-port DB25 connector interface module, or one RM16-RJ45 Rack Mount interface module for RS-232 serial port connections.
DB25/RM16-RJ45/RM32-RJ45	32	Requires two 16-port DB25 interface modules, or two 16-port RM16-RJ45 Rack Mount interface modules, or one RM32-RJ45 Rack Mount interface module for RS-232 serial port connections.

**Note:** The cables and interface modules shipped with this product are described and illustrated in [RocketPort Interfaces](#) on Page 6.



**Locating Drivers and Software Documentation**

You can download the latest drivers and software installation documents from the web site at <http://support.comtrol.com/Download.asp>.

**RocketPort Terminology**

For the purposes of the following discussions, “RocketPort ISA” cards means any interface type including 4-port RJ45, 8-port RJ11, Quadcable, and Octacable, or 8/16/32-port model.

These products are referred to as “RocketPort PCI” cards:

- RocketPort PCI-bus boards (any interface type including 4-port RJ45, 8-port RJ11, Quadcable, Octacable, and 8/16/32-port models)
- RocketPort *Plus* models
- RocketPort PCI 422 models
- RocketPort Universal PCI-bus boards (any interface type including Quadcable, Octacable, 8-port low profile, 16/32-port models)

**Before Installing the Hardware**

Read this subsection:

- *If* you already have one or more RocketPort ISA cards installed in your system.
- *If* you plan to install a combination of RocketPort ISA and RocketPort PCI cards at this time.

**Existing RocketPort ISA Cards Installed**

You must deconfigure and remove any existing RocketPort ISA cards before installing RocketPort PCI cards. After you have successfully installed the RocketPort PCI cards, reinstall the RocketPort ISA cards.

*Explanation*

The BIOS on your computer automatically handles I/O addressing for RocketPort PCI cards when you first power up the computer after installing the cards.

I/O addresses for RocketPort ISA cards are set manually using DIP switches on the card. If you install an ISA card *before* installing a RocketPort PCI card, the ISA card addressing may interfere with the computer’s ability to recognize the RocketPort PCI card which may prevent the PCI card from functioning properly.

*Additional Considerations*

If you are mixing RocketPort ISA and PCI cards, set the DIP switches on the ISA cards so that the first ISA card that you install is the “first” card for I/O addressing purposes, even if it is physically the second, third, or fourth card that you install.

**Installing the RocketPort Hardware**

Hardware installation consists of installing the card in the system and connecting the interface.

**Card Installation**

Use the following procedure to install the card.

**Note:** *If you are installing PCI and ISA RocketPort cards, install the PCI cards and driver before installing and configuring the ISA cards.*

1. Turn off your computer.
2. Remove the system cover.
3. Select a PCI expansion slot.
4. Remove the slot cover.

**Note:** *You may want to write down the model number and serial number of the card before installation.*

5. Insert the card into the slot and seat it securely.
6. Reinstall the expansion slot retaining screw.
7. If this is not a 4-port RJ45 or 8-port RJ11 (4 RJ45 or 8 RJ11 ports integrated in the card bracket), attach the interface that came with your card using the appropriate procedure:
  - [Installing a Quad/Octacable Interface](#) on Page 4
  - [Installing a Standard or Surge Interface Module for an 8 Port Card](#) on Page 4
  - [Installing a Rack Mount Interface Module](#) on Page 5
  - a. *If this is a 4-port RJ45 or 8-port RJ45*, use the software installation and configuration document for your operating system, with the driver to complete your installation.  
 For the latest software and documentation, go to <http://support.comtrol.com/download.asp>.  
*Note: After installing the hardware, you must install the device driver for your operating system.*
  - b. Verify that the ports are functioning properly and connect your peripheral devices.

### Installing a Quad/Octacable Interface

Use this procedure to complete the Quadcable or Octacable hardware installation.

**Note:** *Quad and Octacable models support RS-232 exclusively.*

1. Attach the male end of the Quadcable or Octacable to the card.
2. Tighten the retaining screws.  
 See [RocketPort Interfaces](#) on Page 6, if you need information about the connectors.
3. Use the software installation and configuration document for your operating system, with the driver to complete your installation.

For the latest software and documentation, go to <http://support.comtrol.com/download.asp>.

**Note:** *After installing the hardware, you must install the device driver for your operating system.*

4. Verify that the ports are functioning properly and connect your peripheral devices.

### Installing a Standard or Surge Interface Module for an 8 Port Card

Use this procedure to complete the installation with a standard interface module.

**Do not connect the RocketPort cable to the card or the interface module when the PC is powered on. This prevents possible damage to the interface module electronics.**



Caution

1. Attach the male end of the RocketPort cable to the card and the female end to the connector labeled **Host** on the interface module.

**Note:** *The male DB25 port labeled **Host** is reserved for Comtrol use and no user accessible signals are present at this port.*

2. Tighten the retaining screws.

**Note:** *If you have a 32-port adapter, the connector labeled **J1** corresponds to Ports 0 through 15 and the connector labeled **J2** (closest to the bus) corresponds to Ports 16 through 31.*

3. *If applicable*, use the slide switches on the interface module to set each port to either RS-232 or RS-422.

- 4. Use the software installation and configuration document for your operating system, with the driver to complete your installation.

For the latest software and documentation, go to <http://support.comtrol.com/download.asp>.

**Note:** After installing the hardware, you must install the device driver for your operating system.

- 5. Verify that the ports are functioning properly and connect your peripheral devices.

**Installing a Rack Mount Interface Module**

The RM16-RJ45 and RM32-RJ45 are sturdy enough to allow you to stack several units on a shelf, or you can mount it directly into a rack.

- 1. Place the unit on a stable surface or attach the L brackets to the interface using the screws supplied with the unit and attach the L bracket into your rack.



**Note:** You can mount the unit facing in either direction.

- 2. Attach the 3-foot cable or the 3-foot and the 10-foot cables together between the interface and the board.



**Note:** The cables are interchangeable. You may connect either or both cables depending upon the distance between the card and the rack. The maximum distance permitted between the interface module and card is 15 feet.

- 3. Optionally, for the RM32-RJ45, attach the two cables to the card and the interface. The connector labeled J1 corresponds to Host A (Ports 0 through 15), and the connector labeled J2 (closest to the bus) corresponds to Host B (Ports 16 through 32).

**Do not connect 16-port cards located in different machines to the RM32-RJ45. It is possible to damage the interface and card if the interface is connected to two PCs using separate line power sources.**

- 4. Use the software installation and configuration document for your operating system, with the driver to complete your installation.

For the latest software and documentation, go to <http://support.comtrol.com/download.asp>.

**Note:** After installing the hardware, you must install the device driver for your operating system.

- 5. Verify that the ports are functioning properly and connect your peripheral devices.



Caution

## RocketPort Interfaces


A cable or interface module may be shipped with RocketPort PCI series. The type of cable or interface module shipped with RocketPort PCI series depends on the product part number. The cables and interface modules are described below:

- Quadcable and Octacable fanout cables with the following configurations:
  - Quadcable DB25 and DB9 male
  - Octacable DB25, DB9 male, and RJ45




*Note: The RJ45 Octacable is not displayed.*

- Standard interface modules with the following configurations:
  - RS-232 mode-only or switch-selectable RS-232/422; both models have female DB25 connectors.
  - Surge interface module that is switch-selectable RS-232/422 with male DB25 connectors.




*Note: RS-422 supports up to 10 multidrop devices.*


- Rack Mount Models are available with RJ45 connectors (back panels shown).
  - 16-Port RS-232 (with red LEDs)
  - 16-Port RS-422 (with red LEDs)




- 16-Port RS-232 with integrated status LEDs. The yellow LEDs show receiving activity. The green LEDs show transmitting activity.



- 32-Port RS-232 with integrated status LEDs. The yellow LEDs show receiving activity. The green LEDs show transmitting activity.



- RocketPort PCI 4-port RJ45 and RocketPort PCI 8-port RJ11.



## Cabling Requirements

Use the appropriate pinout specification provided below for your hardware.


### DB9 Interface Connectors

#### DB9 Pinouts

There are Quadcable and Octacable models available with DB9 connectors on a fanout cable.

The following information and table provide information on the DB9 connectors that are used on the Quadcable and Octacable.


Pin	RS-232 Signal
1	CD
2	RxD
3	TxD
4	DTR
5	Signal GND
6	DSR
7	RTS
8	CTS
9	Not used



#### Building DB9 Female Loopback Plugs


Loopback connectors are plugs, with pins wired together as shown, that are used in conjunction with the RocketPort diagnostic software to test serial ports. This loopback is used with the Quadcable and Octacable. To build a loopback plug for the Quadcable and Octacable, wire the following pins together:

- Pins 1 to 4 to 6
- Pins 2 to 3
- Pins 7 to 8 to 9



## DB25 Interfaces

This section describes the DB25 interface connectors. Standard interface modules use female DB25 connectors, while the Surge interface module, Quadcable, and Octacable fanouts use male connectors.



This table shows connector information for DB25 connectors.

Interface Modules			Quad/Octacable
Pin	RS-232 Signal	RS-422 Signal	RS-232 Signal
1	Not used	Not used	Not used
2	TxD	Not used*	TxD
3	RxD	Not used*	RxD
4	RTS	Not used*	RTS
5	CTS	Not used*	CTS
6	DSR	Not used*	DSR
7	Signal ground	Signal ground*	Signal ground
8	DCD	Not used*	DCD
9 to 14	Not used	Not used	Not used
15	Not used	RxD+	Not used
16	Not used	Not used	Not used
17	Not used	RxD-	Not used
18	Not used	Not used	Not used
19	Not used	TxD+	Not used
20	DTR	Not used*	DTR
21 to 24	Not used	Not used	Not used
25	Not used	TxD-	Not used

\* All RS-232 signals are present in RS-422 mode. The quad / octacables do not support RS-422 mode.

### Building DB25 Female Loopback Plugs



Loopback connectors are plugs, with pins wired together as shown, that are used in conjunction with the RocketPort diagnostic software to test serial ports.

This loopback is used with the Quadcable and Octacable. To build a DB25 loopback plug for an Quadcable or Octacable, wire the following pins together:

- Pins 2 to 3
- Pins 4 to 5 to 22
- Pins 6 to 8 to 20

To build a DB25 loopback plug (surge interface model) for an RS-422 serial connection, wire the following pins together:

- Pins 15 to 19
- Pins 17 to 25



*Building DB25 Male Loopback Plugs*



Loopback connectors are plugs, with pins wired together as shown, that are used in conjunction with the RocketPort diagnostic software to test serial ports.

This loopback plug is used with the standard 8- and 16-port DB25 interface modules. To build a DB25 loopback plug for an RS-232 serial connection, wire the following pins together:

- Pins 2 to 3
- Pins 4 to 5 to 22
- Pins 6 to 8 to 20

To build a DB25 loopback plug for an RS-422 serial connection, wire the following pins together.

- Pins 15 to 19
- Pins 17 to 25



**RJ45 Interfaces**

The RocketPort PCI/4-port RJ45, an Octacable model, and the Rack Mount interface module are available with RJ45 connectors.


*RJ45 Pinouts for the Octacable and Rack Mount Interface Module*

The following figures provide pinout information for the RJ45 connectors used on the Octacable and Rack Mount interface module.

**Note:** Ring indicator is not supported on the RJ45 connector.




RJ45 Jack (Receptacle) Signals




*Pinouts for the RJ45 Interface Module*

The following figures provide pinout information for the RJ45 plug and receptacle for the RJ45 interface module.



**RJ45 Jack (Receptacle) Signals**




*Building RJ45 Loopback Plugs*

*Loopback connectors* are plugs, with pins wired together as shown, that are used in conjunction with the RocketPort diagnostic software to test serial ports.

This RJ45 loopback is used with the Octacable and Rack Mount interfaces. To build an RJ45 loopback plug, wire the following pins together:

- Pins 4 to 5
- Pins 1 to 8
- Pins 2 to 6 to 7




**RJ11 Interface**

The RocketPort PCI/8-port RJ11 features eight standard RJ11 modular connectors, located on the controller board mounting bracket. The ports are numbered 0 through 7, with Port 7 being the connector closest to the bus.


*RJ11 Pinouts*

The following figures provide pinout information for the RJ11 jack plug and receptacle.

RJ11 Plug Signals



RJ11 Jack  
(Receptacle) Signals



*Building RJ11  
Loopback Connectors*

*Loopback connectors* are plugs, with pins wired together as shown, that are used in conjunction with the RocketPort diagnostic software to test serial ports.

To build an RJ11 loopback plug, wire these pins together:

- Pins 3 to 4
- Pins 1 to 5 to 6



## Specifications

The following tables illustrate RocketPort PCI conditions and specifications.

Environmental Condition	Value
<b>Air temperature:</b> System on System off	0 to 40°C -20 to 85°C
<b>Humidity (non-condensing):</b> System on System off	8% to 80% 20% to 80%
<b>Altitude:</b>	0 to 10,000 feet (0 to 3048 meters)

### Electromagnetic Compliance

**Emission:**

Canadian EMC requirements  
CISPR-22/EN55022 Class A\*  
FCC PART 15: Class A\*

**Immunity:**

EN50082: 801-2 ESD, 801-3 RF, 801-4 FT

**Safety:**

UL recognized.

*Class A\*4-port RJ45 model meets FCC Part 15 Class B.*

RocketPort PCI Card	Specification																								
<b>Baud rate:</b> RS-232 DTE (4-port RJ45, 8-port RJ11, Quad/Octacable models)  RS-232/422 (models with interface module)	50 to 460.8K baud (without interface module)  50 to 230.4K baud (with interface module)																								
<i>Note: Baud rate is dependent upon hardware and operating system configuration.</i>																									
<b>Bus interface</b>	PCI																								
<b>Control by device driver:</b> Data bits Parity Stop bits	7 or 8 Odd, Even, None 1 or 2																								
<b>Current consumption:</b> 4-port RJ45 8-port RJ11 Quadcable Octacable RocketPort 8 RocketPort 16 RocketPort 32	<table border="1"> <thead> <tr> <th>+5V</th> <th>+12V</th> <th>-12V</th> </tr> </thead> <tbody> <tr> <td>200 mA</td> <td>50 mA</td> <td>10 mA</td> </tr> <tr> <td>440 mA</td> <td>100 mA</td> <td>160 mA</td> </tr> <tr> <td>410 mA</td> <td>100 mA</td> <td>160 mA</td> </tr> <tr> <td>440 mA</td> <td>100 mA</td> <td>160 mA</td> </tr> <tr> <td>600 mA</td> <td>110 mA</td> <td>160 mA</td> </tr> <tr> <td>940 mA</td> <td>220 mA</td> <td>320 mA</td> </tr> <tr> <td>2.9 A</td> <td>440 mA</td> <td>0</td> </tr> </tbody> </table>	+5V	+12V	-12V	200 mA	50 mA	10 mA	440 mA	100 mA	160 mA	410 mA	100 mA	160 mA	440 mA	100 mA	160 mA	600 mA	110 mA	160 mA	940 mA	220 mA	320 mA	2.9 A	440 mA	0
+5V	+12V	-12V																							
200 mA	50 mA	10 mA																							
440 mA	100 mA	160 mA																							
410 mA	100 mA	160 mA																							
440 mA	100 mA	160 mA																							
600 mA	110 mA	160 mA																							
940 mA	220 mA	320 mA																							
2.9 A	440 mA	0																							

RocketPort PCI Card	Specification
<b>Power consumption:</b> 4-port RJ45 8-port RJ11 Quadcable Octacable RocketPort 8 RocketPort 16 RocketPort 32	1.72 W 5.32 W 5.17 W 5.32 W 6.24 W 11.18 W 18.78 W
<b>Dimensions:</b> 4-port RJ45 8-port RJ11 Quad/Octacable 8/16-Port 32-Port	5.1" by 4.2" 6" by 5" 5.6" by 4.2" 6.875" by 4.21" 7.2" by 4.2"
<b>Heat output:</b> 4-port RJ45 8-port RJ11 Quadcable Octacable 8-Port 16-Port 32-Port	5.87 BTU/Hr. 18.1 BTU/Hr. 17.6 BTU/Hr. 18.2 BTU/Hr. 27.1 BTU/Hr. 49.4 BTU/Hr. 67.4 BTU/Hr.
<b>I/O ports/expansion slot</b>	From 4 to 32
<b>Interfaces:</b> All models except 422  With optional switch-selectable interface module	RS-232  RS-422
<b>Mean time between failures (MTBF):</b> 4-port RJ45 8-port RJ11 Quad/Octacable 8-Port 16-Port 32-Port	103.4 Years 31.8 Years 23.5 Years 60.7 Years 45.6 Years 17.4 Years
<b>RocketPort cards/system</b>	4
<b>Surge protection:</b> 4-port RJ45 and 8-port RJ11 interface, Quadcable and Octacable models  Standard and rack mount interface modules  Surge interface module	Provides ESD surge protection minimum of 15KV @ 200A for a duration of 1 ns.  Provides ESD surge protection minimum of 10KV @ 200A for a duration of 1 ns.  Provides ESD surge protection minimum of 25KV @ 200A for a duration of 1 ns.

<b>Surge Interface Operating Specifications</b>	<b>Limit</b>
Maximum surge current (8x20 $\mu$ S)	100 amps (total)
Capacitance	<350pf
Clamping voltage	30 volts
Clamping response time	<5 nanoseconds
Transient energy (10/1000 MS)	300 mJ
Inductance	<1.5 nh
ESD withstand (surge-protection)	25KV

<b>Interface Module Type</b>	<b>Mounting Dimensions</b>	<b>Overall Dimensions</b>
RS-232 only, 8-port	3.2" x 6.48"	5.8" x 5.35" x 0.65"
RS-232 only, 16-port	3.0" x 6.17"	5.8" x 8.5" x 0.65"
RS-422 with 16-ports (Rack Mount with red LEDs)	19" x 8.0" x 1.74" (with brackets)	17.25" x 8.0" x 1.74" (without brackets)
RS-232 with 16-ports (Rack Mount with integrated yellow and green LEDs)	19" x 8.0" x 1.74" (with brackets)	17.25" x 8.0" x 1.74" (without brackets)
RS-232 with 32-ports (Rack Mount with integrated yellow and green LEDs)	19" x 8.0" x 1.74" (with brackets)	17.25" x 8.0" x 1.74" (without brackets)
RS-232/422 with 4-ports	3.2" x 6.48"	5.8" x 5.35" x 0.65"
RS-232/422 with 8-ports (All models)	3.2" x 6.48"	5.8" x 5.35" x 0.65"
RS-232/422 with 16-ports (All Models)	3.0" x 6.48"	5.8" x 8.5" x 0.65"

---

---

## FCC Notices

---

---

**Radio Frequency Interference (RFI) (FCC 15.105)**

This equipment has been tested and found to comply with the limits for Class A or B (depending on the model) digital devices pursuant to Part 15 of the FCC Rules.

This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Labeling Requirements (FCC 15.19)**

This equipment complies with Part 15 of FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

**Modifications (FCC 15.21)**

Changes or modifications to this equipment not expressly approved by Comtrol Corporation may void the user's authority to operate this equipment.

**Serial Cables (FCC 15.27)**

This equipment is certified for Class A operation when used with shielded cables.

---



---

## Troubleshooting and Running Diagnostics

---



---

This section describes how to diagnose and troubleshoot problems. When a problem occurs, first determine that your RocketPort is functioning properly. Start by creating a bootable diagnostics diskette.

### Creating a Diagnostics Diskette

You need two files to create a bootable floppy diagnostic diskette:

- The **Rawrite** utility that creates a bootable diagnostics diskette.
- The diskette image file (\*.i).

You can find both files on the *Control Software and Documentation CD* or at <ftp://ftp.comtrol.com/RPort>.

This discussion outlines how to create a bootable diagnostics diskette. You can use our Web site <http://support.comtrol.com/bootdiag.asp> to:

- Download the necessary files.
- Easily find specific procedures for your operating system to create the bootable diskette.

### Diagnostics Overview

After you create a bootable diagnostic diskette, you can use the diagnostic program to:

- Confirm that the hardware is functioning.
- Determine resolutions to conflicts during installation.
- Perform stress test on the cards.

For example, you may want to run the diagnostics overnight to evaluate a possible problem. You will need loopback plugs for each port that you want to stress test. If you need additional loopback plugs, you can use the appropriate *Building Loopback Plugs* discussion in this document to build additional loopback plugs.

### Running the Diagnostics

Use the following procedure to run the diagnostics:

1. Insert the diagnostics diskette you created and restart your machine. The diagnostic starts automatically.
2. Verify that the system locates the RocketPort card.
3. Follow the remainder of the online instructions.

If the diagnostics did not pass you may want to use the following discussion to diagnose your problem.

### Resolving Failures

If the diagnostics could not find the card:

- Turn off the power and reseal the card into the slot.
- Check for proper cable connections.
- Check for proper installation of the loopback plug.

Try running the diagnostics again. If they fail again, you may have a bad port, contact Technical Support.

## Technical Support

---



---

Comtrol has a staff of support technicians available to help you. You should review [Troubleshooting and Running Diagnostics](#) on Page 16 before calling Technical Support. In addition, the Web site has [Online Technical Support](#) available. If you call for Technical Support, please have the following information available:

Item	Your System Information
Model number	
Serial number	
Interface type	
Operating system type, release, and service package	
Device driver version	
PC make, model, speed, and single or dual processor	
List other devices in the PC and their addresses	

Comtrol	Headquarters	Europe
Phone	(763) 494-4100	+44 (0)1869 323220
FAX	(763) 494-4199	+44 (0)1869 323211
E-mail	<a href="mailto:support@comtrol.com">support@comtrol.com</a>	<a href="mailto:support@comtrol.co.uk">support@comtrol.co.uk</a>
Web support	<a href="http://support.comtrol.com/">http://support.comtrol.com/</a>	
Downloads	<a href="http://.support.comtrol.com/download.asp">http://.support.comtrol.com/download.asp</a>	
Web site	<a href="http://www.comtrol.com">www.comtrol.com</a>	<a href="http://www.comtrol.co.uk">www.comtrol.co.uk</a>
FTP site	<a href="ftp.comtrol.com">ftp.comtrol.com</a>	

### Trademark Notices

Comtrol and RocketPort are registered trademarks of Comtrol Corporation.

Microsoft and Windows are registered trademarks of Microsoft Corporation in the United States and/or other countries.

Other product names mentioned herein may be trademarks and/or registered trademarks of their respective owners.

Eighth Edition, October 13, 2004

Copyright © 2002 - 2004. Comtrol Corporation.

All Rights Reserved.

Comtrol Corporation makes no representations or warranties with regard to the contents of this document or to the suitability of the Comtrol product for any particular purpose. Specifications subject to change without notice. Some software or features may not be available at the time of publication. Contact your reseller for current product information.