

DeviceMaster MOD | DeviceMaster UP – Modbus Server Versions and PortVision DX

Use the following table to determine which version of PortVision DX you should use to manage your DeviceMaster Gateway depending on the Modbus Server firmware version.

DeviceMaster MOD DeviceMaster UP		Firmware Versions	
Part Number	Model	Use PortVision v3.05	Use PortVision v4.09 or higher
99606-6	DeviceMaster MOD-2101 (1P DB9, DIN Rail)	Not supported	Modbus Server v6.02 or higher with Bootloader v4.00 or higher
99621-7	DeviceMaster MOD-2201 (1P, Screw Terminal, DIN Rail)		
99501-2	DeviceMaster UP 1P DB9 Panel	Modbus Server firmware up to v4.04 with Bootloader up to v3.xx	
99532-6	DeviceMaster MOD-2202† (2P, 1E, Screw Term, DIN Rail)		
99552-4	DeviceMaster MOD-2102† (2P, 1E, DB9)		
99542-5	DeviceMaster MOD-2402† (2P, 2E, Screw Terminal, DIN Rail)	Not supported	
99562-3	DeviceMaster MOD-2302† (2P, 2E, DB9, DIN Rail)		
99612-5	DeviceMaster MOD-2304 (4P, 2E, DIN Rail)	Modbus Server firmware up to v4.04 with Bootloader up to v3.xx	
99521-0	DeviceMaster UP 4P Panel		
99582-1	DeviceMaster UP 16 Panel		
† The following products have been renamed to align with the new DIN naming convention: DeviceMaster UP 2-Port 1E renamed DeviceMaster MOD-2202 DeviceMaster UP 2-Port DB9 1E renamed DeviceMaster MOD-2102 DeviceMaster UP 2-Port 2E renamed DeviceMaster MOD-2402 DeviceMaster UP 2-Port DB9 2E renamed DeviceMaster MOD-2302			