

DeviceMaster PNIO | DeviceMaster UP – PROFINET IO Versions and PortVision DX

Use the following table to determine which version of PortVision DX you should use to manage your DeviceMaster Gateway depending on the PROFINET IO firmware version.

DeviceMaster PNIO DeviceMaster UP		Firmware Versions	
Part Number	Model	Use PortVision v3.05	Use PortVision v4.09 or higher
99604-0	DeviceMaster PNIO-2101 (1P DB9, DIN Rail)	Not supported	PROFINET IO v3.2.9 or higher with Bootloader v4.00 or higher
99622-4	DeviceMaster PNIO-2201 (1P, Screw Terminal, DIN Rail)		
99441-1	DeviceMaster UP 1P DB9 Panel	PROFINET IO firmware up to v2.25 with Bootloader up to v3.xx	
99531-9	DeviceMaster PNIO-2202† (2P, 1E, Screw Term, DIN Rail)		
99551-7	DeviceMaster PNIO-2102† (2P, 1E, DB9)		
99541-8	DeviceMaster PNIO-2402† (2P, 2E, Screw Terminal, DIN Rail)		
99561-6	DeviceMaster PNIO-2302† (2P, 2E, DB9, DIN Rail)		
99613-2	DeviceMaster PNIO-2304 (4P, 2E, DIN Rail)	Not supported	
99447-3	DeviceMaster UP 4P Panel (After S/N: 9447-030000)		
† The following products have been renamed to align with the new DIN naming convention: DeviceMaster UP 2-Port 1E renamed DeviceMaster PNIO-2202 DeviceMaster UP 2-Port DB9 1E renamed DeviceMaster PNIO-2102 DeviceMaster UP 2-Port 2E renamed DeviceMaster PNIO-2402 DeviceMaster UP 2-Port DB9 2E renamed DeviceMaster PNIO-2302			