Driver Location Link

The last **DeviceMaster IPv4-only device driver (v12.02)** resides in the **Legacy** directory. Although the path links to the RTS subdirectory, the drivers in this location also support the DeviceMaster LT, DeviceMaster PRO and DeviceMaster Serial Hub models.

http://downloads.comtrol.com/legacy/dev_mstr/rts/drivers/

Please note that the IPv4/IPv6 driver, which is replacing the IPv4-only driver - does not support these obsolete operating systems:

- Windows Server 2003
- Windows Vista
- Windows XP