

DeviceMaster EIP | MOD | PNIO | DeviceMaster UP Minimum Firmware Versions

DeviceMaster EIP or DeviceMaster UP with EtherNet/IP							
	TLA	Description	New MAC Address Range		Starting S/N	Minimum Bootloader Version	Minimum EtherNet/IP Version
1 Port	99441-1	DeviceMaster UP, DB9M, 5-30VDC,	00 C0 4E 42 00 00	00 C0 4E 42 FF FF	9941-030000	4.00	6.02
	99601-9	EIP-2101 (DB9M)	00 C0 4E 5D 00 00	00 C0 4E 5D FF FF	9601-000001	4.25	6.02
	99620-0	EIP-2201 (Screw Terminal)	00 C0 4E 62 00 00	00 C0 4E 62 FF FF	9620-000001	4.00	6.02
2 Port	99551-7	EIP-2102 (DB9M, 1E)	00 C0 4E 46 00 00	00 C0 4E 46 FF FF	9551-003301	4.25	6.02
	99561-6	EIP-2302 (DB9M, 2E)	00 C0 4E 47 00 00	00 C0 4E 47 FF FF	9561-001101		
	99531-9	EIP-2202 (Screw Terminals, 1E)	00 C0 4E 44 00 00	00 C0 4E 44 FF FF	TBD		
	99541-8	EIP-2402 (Screw Terminals, 2E)	00 C0 4E 45 00 00	00 C0 4E 45 FF FF	TBD		
4 Port	99447-3	DeviceMaster UP, DB9/RJ45, 4P	00 C0 4E 48 00 00	00 C0 4E 48 FF FF	9447-030000	4.02	6.02
	99611-8	EIP-2304 (DB9M, 2E)	00 C0 4E 5C 00 00	00 C0 4E 5C FF FF	9611-000001	4.25	6.02

DeviceMaster MOD or DeviceMaster UP with Modbus									
	TLA	Description	New MAC Address Range		Starting S/N	Minimum Bootloader Version	Minimum Modbus Router Version	Minimum Modbus Server Version	Minimum Modbus TCP Version
1 Port	99501-2	DeviceMaster UP, DB9M, 5-30VDC, 1P, Panel	00 C0 4E 42 00 00	00 C0 4E 42 FF FF	9950-030000	4.00	6.06	6.02	6.03
	99606-6	MOD-2101 (DB9M)	00 C0 4E 5D 00 00	00 C0 4E 5D FF FF	9606-000001	4.25	6.06	6.02	6.03
	99621-7	EIP-2201 (Screw Terminal)	00 C0 4E 62 00 00	00 C0 4E 62 FF FF	9621-000001	4.00	6.06	6.02	6.03
2 Port	99552-4	MOD-2102 (DB9M, 1E)	00 C0 4E 46 00 00	00 C0 4E 46 FF FF	9552-003301	4.25	6.06	6.02	6.03
	99562-3	MOD-2302 (DB9M, 2E)	00 C0 4E 47 00 00	00 C0 4E 47 FF FF	9562-001101	4.25	6.06	6.02	6.03
	99532-6	MOD-2202 (Screw Terminals, 1E)	00 C0 4E 44 00 00	00 C0 4E 44 FF FF	TBD				
	99542-5	MOD-2402 (Screw Terminals, 2E)	00 C0 4E 45 00 00	00 C0 4E 45 FF FF	TBD				
4 Port	99521-0	DeviceMaster UP, DB9/RJ45, 4P	00 C0 4E 48 00 00	00 C0 4E 48 FF FF	9521-030000	4.02	6.06	6.02	6.03
	99612-5	MOD-2304 (DB9M, 2E)	00 C0 4E 5C 00 00	00 C0 4E 5C FF FF	9612-000001	4.25	6.06	6.02	6.03
16 Port	99582-1	DeviceMaster UP, 16P, RJ45	00 C0 4E 40 00 00	00 C0 4E 40 FF FF	9958-030000	4.00	6.06	6.02	6.03

DeviceMaster EIP | MOD | PNIO | DeviceMaster UP Minimum Firmware Versions

DeviceMaster PNIO or DeviceMaster UP with PROFINET IO							
	TLA	Description	New MAC Address Range		Starting S/N	Minimum Bootloader Version	Minimum PROFINET IO Version
1 Port	99441-1	DeviceMaster UP, DB9M, 5-30VDC,	00 C0 4E 42 00 00	00 C0 4E 42 FF FF	9941-030000	4.00	3.2.9
	99604-0	PNIO-2101 (DB9M)	00 C0 4E 5D 00 00	00 C0 4E 5D FF FF	9604-000001	4.25	3.2.9
	99622-4	PNIO-2201 (Screw Terminal)	00 C0 4E 62 00 00	00 C0 4E 62 FF FF	9622-000001	4.00	3.2.9
2 Port	99628-6	PNIO-2102 (DB9M, 1E)	00 C0 4E 46 00 00	00 C0 4E 46 FF FF	9551-003301	4.25	3.2.9
	99633-0	PNIO-2302 (DB9M, 2E)	00 C0 4E 47 00 00	00 C0 4E 47 FF FF	9561-001101		
	99534-0	PNIO-2202 (Screw Terminals, 1E)	00 C0 4E 44 00 00	00 C0 4E 44 FF FF	TBD		
	99544-9	PNIO-2402 (Screw Terminals, 2E)	00 C0 4E 45 00 00	00 C0 4E 45 FF FF	TBD		
4 Port	99447-3	DeviceMaster UP, DB9/RJ45, 4P	00 C0 4E 48 00 00	00 C0 4E 48 FF FF	9447-030000	4.02	3.2.9
	99613-2	PNIO-2304 (DB9M, 2E)	00 C0 4E 5C 00 00	00 C0 4E 5C FF FF	9611-000001	4.25	3.2.9

1/21/2019