<u>DeviceMaster MOD | DeviceMaster UP – Modbus Router Versions and PortVision DX</u>

Use the following table to determine which version of PortVision DX you should use to manage your DeviceMaster Gateway depending on the Modbus Router firmware version.

DeviceMaster MOD DeviceMaster UP		Firmware Versions	
Part Number	Model	Use PortVision v3.05	Use PortVision v4.09 or higher
99606-6	DeviceMaster MOD-2101 (1P DB9, DIN Rail)	Not supported	
99621-7	DeviceMaster MOD-2201 (1P, Screw Terminal, DIN Rail)	Not supported	
99501-2	DeviceMaster UP 1P DB9 Panel		
99532-6	DeviceMaster MOD-2202† (2P, 1E, Screw Term, DIN Rail)		
99552-4	DeviceMaster MOD-2102† (2P, 1E, DB9)	Modbus Router firmware up to v5.11 with	Modbus Router v6.06 or higher with
99542-5	DeviceMaster MOD-2402† (2P, 2E, Screw Terminal, DIN Rail)	Bootloader up to v3.xx	Bootloader v4.00 or higher
99562-3	DeviceMaster MOD-2302† (2P, 2E, DB9, DIN Rail)		
99612-5	DeviceMaster MOD-2304 (4P, 2E, DIN Rail)	Not supported	
99521-0	DeviceMaster UP 4P Panel	Modbus Router firmware	
99582-1	DeviceMaster UP 16 Panel	up to v5.11 with Bootloader up to v3.xx	
† The following products have been renamed to align with the new DIN naming convention:			
DeviceMaster UP 2-Port 1E renamed DeviceMaster MOD-2202			
DeviceMaster UP 2-Port DB9 1E renamed DeviceMaster MOD-2102			
DeviceMaster UP 2-Port 2E renamed DeviceMaster MOD-2402			
DeviceMaster UP 2-Port DB9 2E renamed DeviceMaster MOD-2302			